

## Summary

The Embedded Development Kit (EDK) provides a variety of Xilinx<sup>®</sup> software packages, including drivers, libraries, board support packages, and complete operating systems to help you develop a software platform. This document collection provides information on these and on development of the Board Support Package for the VxWorks and Linux 2.6 operating systems. Complete documentation for other operating systems can be found in their respective reference guides. Device drivers are documented along with the corresponding peripheral documentation. The documentation is listed in the following table; click the name to open the document.

**Table 1: OS and Libraries Document Collection Contents**

Document Name	Summary
<a href="#">LibXil Standard C Libraries</a>	Describes the software libraries available for the embedded processors.
<a href="#">Standalone (v3.08.a)</a>	The Standalone platform is a single-threaded, simple operating system (OS) platform that provides the lowest layer of software modules used to access processor-specific functions. Some typical functions offered by the Standalone platform include setting up the interrupts and exceptions systems, configuring caches, and other hardware specific functions. The Hardware Abstraction Layer (HAL) is described in this document.
<a href="#">Xilkernel (v5.01.a)</a>	Xilkernel is a simple embedded processor kernel that can be customized to a large degree for a given system. Xilkernel has the key features of an embedded kernel such as multi-tasking, priority-driven preemptive scheduling, inter-process communication, synchronization facilities, and interrupt handling. Xilkernel is small, modular, user-customizable, and can be used in different system configurations. Applications link statically with the kernel to form a single executable.
<a href="#">LibXil FATFile System (FATFS) (v1.00.a)</a>	The XilFATFS FAT file system access library provides read and write access to files stored on a Xilinx System ACE <sup>™</sup> compact flash or microdrive device.
<a href="#">LibXil Memory File System (MFS) (v1.00.a)</a>	Describes a simple, memory-based file system that can reside in RAM, ROM, or Flash memory.
<a href="#">lwIP 1.4.0 Library (v1.03.a)</a>	Describes the EDK port of the third party networking library, Light Weight IP (lwIP) for embedded processors.
<a href="#">LibXil Flash (v3.03.a)</a>	Describes the functionality provided in the flash programming library. This library provides access to flash memory devices that conform to the Common Flash Interface (CFI) standard. Intel and AMD CFI devices for some specific part layouts are currently supported.
<a href="#">LibXil Isf (v3.00.a)</a>	Describes the In System Flash hardware library, which enables higher-layer software (such as an application) to communicate with the Isf. LibXil Isf supports the Xilinx In-System Flash and external Serial Flash memories from Atmel (AT45XXXD), Intel (S33), and ST Microelectronics (STM) (M25PXX).
<a href="#">Automatic Generation of Linux 2.6 Board Support Packages</a>	Describes the development of Linux 2.6 BSPs.
<a href="#">Automatic Generation of Wind River VxWorks 6.3 Board Support Packages</a>	Describes the development of Wind River VxWorks 6.3 BSPs.
<a href="#">Automatic Generation of Wind River VxWorks 6.5 Board Support Packages</a>	Describes the development of Wind River VxWorks 6.5 BSPs.
<a href="#">Automatic Generation of Wind River VxWorks 6.7 Board Support Packages</a>	Describes the development of Wind River VxWorks 6.7 BSPs.

## About the Libraries

The Standard C support library consists of the `newlib`, `libc`, which contains the standard C functions such as `stdio`, `stdlib`, and `string` routines. The math library is an enhancement over the `newlib` math library, `libm`, and provides the standard math routines.

The LibXil libraries consist of the following:

- LibXil Driver (Xilinx device drivers)
- LibXil MFS (Xilinx memory file system)
- LibXil Flash (a parallel flash programming library)
- LibXil Isf (a serial flash programming library)

There are two operating system options provided in the Xilinx software package: the Standalone Platform and Xikernel.

The Hardware Abstraction Layer (HAL) provides common functions related to register IO, exception, and cache. These common functions are uniform across MicroBlaze™, PowerPC® 405, and PowerPC 440 processors. The Standalone platform document provides some processor specific functions and macros for accessing the processor-specific features.

Most routines in the library are written in C and can be ported to any platform. The Library Generator (Libgen) configures the libraries for an embedded processor, using the attributes defined in the Microprocessor Software Specification (MSS) file.

User applications must include appropriate headers and link with required libraries for proper compilation and inclusion of required functionality. These libraries and their corresponding `include` files are created in the processor `\lib` and `\include` directories, under the current project, respectively. The `-I` and `-L` options of the compiler being used should be leveraged to add these directories to the search paths. Libgen tailors the compilation of each software component. Refer to the “Libgen” and “Microprocessor Software Specification” chapters in the *Embedded Systems Tools Reference Manual (UG111)* for more information. See [“Additional Resources,” page 3](#) for a link to the document.

## Library Organization

The organization of the libraries is illustrated in the figure below. As shown, your application can interface with the components in a variety of ways. The libraries are independent of each other, with the exception of some interactions. For example, Xilkernel uses the Standalone platform internally. The LibXil Drivers and the Standalone form the lowermost hardware abstraction layer. The library and OS components rely on standard C library components. The math library, `libm.a` is also available for linking with the user applications.

**Note:** “LibXil Drivers” are the device drivers included in the software platform to provide an interface to the peripherals in the system. These drivers are provided along with EDK and are configured by Libgen. This document collection contains a section that briefly discusses the concept of device drivers and the way they integrate with the board support package in EDK.

Taking into account some restrictions and implications, which are described in the reference guides for each component, you can mix and match the component libraries.




Figure 1: Library Organization

## Additional Resources

### Xilinx Resources

- *Xilinx Design Tools: Installation and Licensing Guide (UG798):*  
[http://www.xilinx.com/support/documentation/sw\\_manuals/xilinx14\\_4/iil.pdf](http://www.xilinx.com/support/documentation/sw_manuals/xilinx14_4/iil.pdf)
- *Xilinx Design Tools: Release Notes Guide (UG631):*  
[http://www.xilinx.com/support/documentation/sw\\_manuals/xilinx14\\_4/irn.pdf](http://www.xilinx.com/support/documentation/sw_manuals/xilinx14_4/irn.pdf)
- **Xilinx® Documentation:**  
<http://www.xilinx.com/support/documentation.htm>
- **Xilinx Glossary:**  
[http://www.xilinx.com/support/documentation/sw\\_manuals/glossary](http://www.xilinx.com/support/documentation/sw_manuals/glossary)
- **Xilinx Support:** <http://www.xilinx.com/support.htm>

## EDK Documentation

The following documents are available online at:

[http://www.xilinx.com/ise/embedded/edk\\_docs.htm](http://www.xilinx.com/ise/embedded/edk_docs.htm).

Individual documents are linked below.

- *EDK Concepts, Tools, and Techniques (UG683)*:  
[http://www.xilinx.com/support/documentation/sw\\_manuals/xilinx14\\_4/edk\\_ctt.pdf](http://www.xilinx.com/support/documentation/sw_manuals/xilinx14_4/edk_ctt.pdf)
- *Embedded System Tools Reference Manual (UG111)*:  
[http://www.xilinx.com/support/documentation/sw\\_manuals/xilinx14\\_4/est\\_rm.pdf](http://www.xilinx.com/support/documentation/sw_manuals/xilinx14_4/est_rm.pdf)
- *Platform Specification Format Reference Manual (UG642)*:  
[http://www.xilinx.com/support/documentation/sw\\_manuals/xilinx14\\_4/psf\\_rm.pdf](http://www.xilinx.com/support/documentation/sw_manuals/xilinx14_4/psf_rm.pdf)
- *EDK Profiling Guide (UG448)*:  
[http://www.xilinx.com/support/documentation/sw\\_manuals/xilinx14\\_4/edk\\_prof.pdf](http://www.xilinx.com/support/documentation/sw_manuals/xilinx14_4/edk_prof.pdf)
- *PowerPC 405 Processor Block Reference Guide (UG018)*:  
[http://www.xilinx.com/support/documentation/user\\_guides/ug018.pdf](http://www.xilinx.com/support/documentation/user_guides/ug018.pdf)
- *PowerPC 405 Processor Reference Guide (UG011)*:  
[http://www.xilinx.com/support/documentation/user\\_guides/ug011.pdf](http://www.xilinx.com/support/documentation/user_guides/ug011.pdf)
- *PowerPC 440 Embedded Processor Block in Virtex®-5 FPGAs (UG200)*:  
[http://www.xilinx.com/support/documentation/user\\_guides/ug200.pdf](http://www.xilinx.com/support/documentation/user_guides/ug200.pdf)
- *MicroBlaze Processor User Guide (UG081)*:  
[http://www.xilinx.com/support/documentation/sw\\_manuals/xilinx14\\_4/mb\\_ref\\_guide.pdf](http://www.xilinx.com/support/documentation/sw_manuals/xilinx14_4/mb_ref_guide.pdf)
- SDK Help:  
[http://www.xilinx.com/support/documentation/sw\\_manuals/xilinx14\\_4/SDK\\_Doc/index.html](http://www.xilinx.com/support/documentation/sw_manuals/xilinx14_4/SDK_Doc/index.html)
- XPS Help:  
[http://www.xilinx.com/support/documentation/sw\\_manuals/xilinx14\\_4/platform\\_studio/platform\\_studio\\_start.htm](http://www.xilinx.com/support/documentation/sw_manuals/xilinx14_4/platform_studio/platform_studio_start.htm)

## Revision History

The following table lists the revision history of the OS and Libraries Document Collection

Date	Version	Revision
04/24/2012	14.1	<ul style="list-style-type: none"> <li>• New Standalone version (v3.05.a).</li> <li>• New version of LibXil Flash (v3.01.a)</li> </ul>
07/25/2012	14.2	<ul style="list-style-type: none"> <li>• New version of LibXil Flash (v3.02.a)</li> <li>• New version of LibXil ISF (v3.00.a)</li> <li>• New version of lwIP (1.4.0 v1.02.a)</li> <li>• New version of Standalone (v3.06.a)</li> </ul>
07/27/2012	14.2	<ul style="list-style-type: none"> <li>• Updated links to additional resource documents on page 4.</li> </ul>
10/16/2012	14.3	<ul style="list-style-type: none"> <li>• New version of lwIP (1.4.0 v1.03.a)</li> <li>• New version of Standalone (v3.07.a)</li> </ul>
12/18/2012	14.4	<ul style="list-style-type: none"> <li>• New version of Standalone (v3.08.a)</li> <li>• New version of LibXil Flash (v3.03.a)</li> </ul>

## Overview

The Xilinx<sup>®</sup> Embedded Development Kit (EDK) libraries and device drivers provide standard C library functions, as well as functions to access peripherals. The EDK libraries are automatically configured by Libgen for every project based on the Microprocessor Software Specification (MSS) file. These libraries and include files are saved in the current project `lib` and `include` directories, respectively. The `-I` and `-L` options of `mb-gcc` are used to add these directories to its library search paths.

## Additional Resources

- *MicroBlaze Processor Reference Guide (UG081)*  
[http://www.xilinx.com/ise/embedded/mb\\_ref\\_guide.pdf](http://www.xilinx.com/ise/embedded/mb_ref_guide.pdf)
- *Embedded System Tools Reference Manual (UG111):*  
[http://www.xilinx.com/support/documentation/sw\\_manuals/xilinx14\\_2/est\\_rm.pdf](http://www.xilinx.com/support/documentation/sw_manuals/xilinx14_2/est_rm.pdf)

## Standard C Library (libc.a)

The standard C library, `libc.a`, contains the standard C functions compiled for the MicroBlaze<sup>™</sup> processor or the PowerPC<sup>®</sup> processor. You can find the header files corresponding to these C standard functions in `<XILINX_EDK>/gnu/<processor>/<platform>/<processor-lib>/include`, where:

- `<XILINX_EDK>` is the `<Installation directory>`
- `<processor>` is `powerpc-eabi` or `microblaze`
- `<platform>` is `sol`, `nt`, or `lin`
- `<processor-lib>` is `powerpc-eabi` or `microblaze-xilinx-elf`

The `lib.c` directories and functions are:

<code>_ansi.h</code>	<code>fastmath.h</code>	<code>machine/</code>	<code>reent.h</code>	<code>stdlib.h</code>	<code>utime.h</code>
<code>_syslist.h</code>	<code>fcntl.h</code>	<code>malloc.h</code>	<code>regdef.h</code>	<code>string.h</code>	<code>utmp.h</code>
<code>ar.h</code>	<code>float.h</code>	<code>math.h</code>	<code>setjmp.h</code>	<code>sys/</code>	
<code>assert.h</code>	<code>grp.h</code>	<code>paths.h</code>	<code>signal.h</code>	<code>termios.h</code>	
<code>ctype.h</code>	<code>ieeefp.h</code>	<code>process.h</code>	<code>stdarg.h</code>	<code>time.h</code>	
<code>dirent.h</code>	<code>limits.h</code>	<code>pthread.h</code>	<code>stddef.h</code>	<code>unctrl.h</code>	
<code>errno.h</code>	<code>locale.h</code>	<code>pwd.h</code>	<code>stdio.h</code>	<code>unistd.h</code>	

Programs accessing standard C library functions must be compiled as follows:

For MicroBlaze processors:

```
mb-gcc <C files>
```

For PowerPC processors:

```
powerpc-eabi-gcc <C files>
```

The `libc` library is included automatically.

For programs that access `libm` math functions, specify the `lm` option.

Refer to the “MicroBlaze Application Binary Interface (ABI)” section in the *MicroBlaze Processor Reference Guide (UG081)* for information on the C Runtime Library. “[Additional Resources](#),” [page 1](#) contains a link to the document.

## Xilinx C Library (libxil.a)

The Xilinx C library, `libxil.a`, contains the following object files for the MicroBlaze processor embedded processor:

```
_exception_handler.o
_interrupt_handler.o
_program_clean.o
_program_init.o
```

Default exception and interrupt handlers are provided. The `libxil.a` library is included automatically.

Programs accessing Xilinx C library functions must be compiled as follows:

```
mb-gcc <C files>
```

## Input/Output Functions

The EDK libraries contains standard C functions for I/O, such as `printf` and `scanf`. These functions are large and might not be suitable for embedded processors.

The prototypes for these functions are in `stdio.h`.

**Note:** The C standard I/O routines such as `printf`, `scanf`, `vfprintf` are, by default, line buffered. To change the buffering scheme to no buffering, you must call `setvbuf` appropriately. For example:

```
setvbuf (stdout, NULL, _IONBF, 0);
```

These Input/Output routines require that a newline is terminated with both a CR and LF. Ensure that your terminal CR/LF behavior corresponds to this requirement.

Refer to the “Microprocessor Software Specification (MSS)” chapter in the *Embedded System Tools Reference Manual (UG111)* for information on setting the standard input and standard output devices for a system. “[Additional Resources](#),” [page 1](#) contains a link to the document.

In addition to the standard C functions, the EDK processors (MicroBlaze processor and PowerPC 405 processor) library provides the following smaller I/O functions:

---

```
void print (char *)
```

This function prints a string to the peripheral designated as standard output in the Microprocessor Software Specification (MSS) file. This function outputs the passed string as is and there is no interpretation of the string passed. For example, a “\n” passed is interpreted as a new line character and not as a carriage return and a new line as is the case with ANSI C `printf` function.

---

```
void putnum (int)
```

This function converts an integer to a hexadecimal string and prints it to the peripheral designated as standard output in the MSS file.

---

```
void xil_printf (const *char ctrl1,...)
```

`xil_printf` is a light-weight implementation of `printf`. It is much smaller in size (only 1 kB). It does not have support for floating point numbers. `xil_printf` also does not support printing of long (such as 64-bit) numbers.

**Note:** About Format String Support:

The format string is composed of zero or more directives: ordinary characters (not %), which are copied unchanged to the output stream; and conversion specifications, each of which results in fetching zero or more subsequent arguments. Each conversion specification is introduced by the character %, and ends with a conversion specifier. In between there can be (in order) zero or more flags, an optional minimum field width and an optional precision. Supported flag characters are:

The character % is followed by zero or more of the following flags:

- 0 The value should be zero padded. For `d`, `x` conversions, the converted value is padded on the left with zeros rather than blanks.  
If the 0 and - flags both appear, the 0 flag is ignored.
- The converted value is to be left adjusted on the field boundary.  
(The default is right justification.) Except for `n` conversions, the converted value is padded on the right with blanks, rather than on the left with blanks or zeros. A - overrides a 0 if both are given.

**Note:** About Supported Field Widths:

Field widths are represented with an optional decimal digit string (with a nonzero in the first digit) specifying a minimum field width. If the converted value has fewer characters than the field width, it is padded with spaces on the left (or right, if the left-adjustment flag has been given). The supported conversion specifiers are:

- `d` The `int` argument is converted to signed decimal notation.
- `l` The `int` argument is converted to a signed long notation.
- `x` The `unsigned int` argument is converted to unsigned hexadecimal notation. The letters `abcdef` are used for `x` conversions.
- `c` The `int` argument is converted to an unsigned char, and the resulting character is written.
- `s` The `const char*` argument is expected to be a pointer to an array of character type (pointer to a string). Characters from the array are written up to (but not including) a terminating `NULL` character; if a precision is specified, no more than the number specified are written. If a precision `s` given, no null character need be present; if the precision is not specified, or is greater than the size of the array, the array must contain a terminating `NULL` character.

## Memory Management Functions

The MicroBlaze processor and PowerPC processor C libraries support the standard memory management functions such as `malloc()`, `calloc()`, and `free()`. Dynamic memory allocation provides memory from the program heap. The heap pointer starts at low memory and grows toward high memory. The size of the heap cannot be increased at runtime. Therefore an appropriate value must be provided for the heap size at compile time. The `malloc()` function requires the heap to be at least 128 bytes in size to be able to allocate memory dynamically (even if the dynamic requirement is less than 128 bytes). The return value of `malloc` must always be checked to ensure that it could actually allocate the memory requested.

## Arithmetic Operations

Software implementations of integer and floating point arithmetic is available as library routines in `libgcc.a` for both processors. The compiler for both the processors inserts calls to these routines in the code produced, in case the hardware does not support the arithmetic primitive with an instruction.

### MicroBlaze Processor

#### Integer Arithmetic

By default, integer multiplication is done in software using the library function `__mulsi3`. Integer multiplication is done in hardware if the `mb-gcc` option, `-mno-xl-soft-mul`, is specified.

Integer divide and mod operations are done in software using the library functions `__divsi3` and `__modsi3`. The MicroBlaze processor can also be customized to use a hard divider, in which case the `div` instruction is used in place of the `__divsi3` library routine.

Double precision multiplication, division and mod functions are carried out by the library functions `__mulldi3`, `__divldi3`, and `__modldi3`, respectively.

The unsigned version of these operations correspond to the signed versions described above, but are prefixed with an `__u` instead of `__`.

#### Floating Point Arithmetic

All floating point addition, subtraction, multiplication, division, and conversions are implemented using software functions in the C library.

### PowerPC Processor

#### Integer Arithmetic

Integer addition and subtraction operations are provided in hardware; no specific software library is available for the PowerPC processor.

#### Floating Point Arithmetic

The PowerPC processor supports all floating point arithmetic implemented in the standard C library.

## Thread Safety

The standard C library provided with EDK is not built for a multi-threaded environment. `STDIO` functions like `printf()`, `scanf()` and memory management functions like `malloc()` and `free()` are common examples of functions that are not thread-safe. When using the C library in a multi-threaded environment, proper mutual exclusion techniques must be used to protect thread unsafe functions.



## Summary

Standalone is the lowest layer of software modules used to access processor specific functions. Standalone is used when an application accesses board/processor features directly and is below the operating system layer.

This document contains the following sections:

- [MicroBlaze Processor API](#)
- [PowerPC 405 Processor API](#)
- [PowerPC 440 Processor API](#)
- [Cortex A9 Processor API](#)
- [Xilinx Hardware Abstraction Layer](#)
- [Program Profiling](#)
- [Configuring the Standalone OS](#)
- [MicroBlaze MMU Example](#)

## MicroBlaze Processor API

The following list is a summary of the MicroBlaze™ processor API sections. You can click on a link to go directly to the function section.

- [MicroBlaze Processor Interrupt Handling](#)
- [MicroBlaze Processor Exception Handling](#)
- [MicroBlaze Processor Instruction Cache Handling](#)
- [MicroBlaze Processor Data Cache Handling](#)
- [MicroBlaze Processor Fast Simplex Link \(FSL\) Interface Macros](#)
- [MicroBlaze Processor FSL Macro Flags](#)
- [MicroBlaze Processor Pseudo-asm Macro Summary](#)
- [MicroBlaze Processor Version Register \(PVR\) Access Routine and Macros](#)
- [MicroBlaze Processor File Handling](#)
- [MicroBlaze Processor Errno](#)

### MicroBlaze Processor Interrupt Handling

The interrupt handling functions help manage interrupt handling on MicroBlaze processor devices. To use these functions you must include the header file `mb_interface.h` in your source code.

#### MicroBlaze Processor Interrupt Handling Function Descriptions

---

```
void microblaze_enable_interrupts(void)
```

Enable interrupts on the MicroBlaze processor. When the MicroBlaze processor starts up, interrupts are disabled. Interrupts must be explicitly turned on using this function.

```
void microblaze_disable_interrupts(void)
```

Disable interrupts on the MicroBlaze processor. This function can be called when entering a critical section of code where a context switch is undesirable.

---

```
void microblaze_register_handler(XInterruptHandler  
    Handler, void *DataPtr)
```

Register the interrupt handler for the MicroBlaze processor. This handler is invoked in turn, by the first level interrupt handler that is present in Standalone.

The first level interrupt handler saves and restores registers, as necessary for interrupt handling, so that the function you register with this handler can be dedicated to the other aspects of interrupt handling, without the overhead of saving and restoring registers.

## MicroBlaze Processor Exception Handling

This section describes the exception handling functionality available on the MicroBlaze processor. This feature and the corresponding interfaces are not available on versions of the MicroBlaze processor older than v3.00.a.

**Note:** These functions work correctly only when the parameters that determine hardware exception handling are configured appropriately in the MicroBlaze Microprocessor Hardware Specification (MHS) hardware block. For example, you can register a handler for divide by zero exceptions only if hardware divide by zero exceptions are enabled on the MicroBlaze processor. Refer to the *MicroBlaze Processor Reference Guide (UG081)* for information on how to configure these cache parameters. A link to that document can be found in [“MicroBlaze Processor API,” page 1](#).

### MicroBlaze Processor Exception Handler Function Descriptions

The following functions help manage exceptions on the MicroBlaze processor. You must include the `mb_interface.h` header file in your source code to use these functions.

---

```
void microblaze_disable_exceptions(void)
```

Disable hardware exceptions from the MicroBlaze processor. This routine clears the appropriate “exceptions enable” bit in the model-specific register (MSR) of the processor.

---

```
void microblaze_enable_exceptions(void)
```

Enable hardware exceptions from the MicroBlaze processor. This routine sets the appropriate “exceptions enable” bit in the MSR of the processor.

---

```
void microblaze_register_exception_handler(Xuint8  
    ExceptionId, XExceptionHandler Handler, void *DataPtr)
```

Register a handler for the specified exception type. *Handler* is the function that handles the specified exception.

*DataPtr* is a callback data value that is passed to the exception handler at run-time. By default the exception ID of the corresponding exception is passed to the handler.

Table 1 describes the valid exception IDs, which are defined in the `microblaze_exceptions_i.h` file.

Table 1: Valid Exception IDs

Exception ID	Value	Description
XEXC_ID_FSL	0	FSL bus exceptions.
XEXC_ID_UNALIGNED_ACCESS	1	Unaligned access exceptions.
XEXC_ID_<BUS>_EXCEPTION(1)	2	Exception due to a timeout from the Instruction side system bus. <b>Note:</b> <i>BUS</i> can be OPB or PLB
XEXC_ID_ILLEGAL_OPCODE	3	Exception due to an attempt to execute an illegal opcode.
XEXC_ID_D<BUS>_EXCEPTION(1)	4	Exception due to a timeout on the Data side system bus. <i>BUS</i> can be OPB or PLB
XEXC_ID_DIV_BY_ZERO	5	Divide by zero exceptions from the hardware divide.
XEXC_ID_FPU	6	Exceptions from the floating point unit on the MicroBlaze processor. <b>Note:</b> This exception is valid only on v4.00.a and later versions of the MicroBlaze processor.
XEXC_ID_MMU	7	Exceptions from the MicroBlaze processor MMU. All possible MMU exceptions are vectored to the same handler. <b>Note:</b> This exception is valid only on v7.00.a and later versions of the MicroBlaze processor.

By default, Standalone provides empty, no-op handlers for all the exceptions *except* unaligned exceptions. A default, fast, unaligned access exception handler is provided by Standalone.

An unaligned exception can be handled by making the corresponding aligned access to the appropriate bytes in memory. Unaligned access is transparently handled by the default handler. However, software that makes a significant amount of unaligned accesses will see the performance effects of this at run-time. This is because the software exception handler takes much longer to satisfy the unaligned access request as compared to an aligned access.

In some cases you might want to use the provision for unaligned exceptions to just trap the exception, and to be aware of what software is causing the exception. In this case, you should set breakpoints at the unaligned exception handler, to trap the dynamic occurrence of such an exception or register your own custom handler for unaligned exceptions.

**Note:** The lowest layer of exception handling, always provided by Standalone, stores volatile and temporary registers on the stack; consequently, your custom handlers for exceptions must take into consideration that the first level exception handler will have saved some state on the stack, before invoking your handler.

Nested exceptions are allowed by the MicroBlaze processor. The exception handler, in its prologue, re-enables exceptions. Thus, exceptions within exception handlers are allowed and handled. When the `predecode_fpu_exceptions` parameter is set to `true`, it causes the low-level exception handler to:

- Decode the faulting floating point instruction
- Determine the operand registers
- Store their values into two global variables

You can register a handler for floating point exceptions and retrieve the values of the operands from the global variables. You can use the `microblaze_getfpex_operand_a()` and `microblaze_getfpex_operand_b()` macros.

**Note:** These macros return the operand values of the last floating point (FP) exception. If there are nested exceptions, you cannot retrieve the values of outer exceptions. An FP instruction might have one of the source registers being the same as the destination operand. In this case, the faulting instruction overwrites the input operand value and it is again irrecoverable.

## MicroBlaze Processor Instruction Cache Handling

The following functions help manage instruction caches on the MicroBlaze processor. You must include the `mb_interface.h` header file in your source code to use these functions.

**Note:** These functions work correctly only when the parameters that determine the caching system are configured appropriately in the MicroBlaze Microprocessor Hardware Specification (MHS) hardware block. Refer to the *MicroBlaze Reference Guide (UG081)* for information on how to configure these cache parameters. “[MicroBlaze Processor API](#),” page 1 contains a link to this document.

### MicroBlaze Processor Instruction Cache Handling Function Descriptions

---

```
void microblaze_enable_icache(void)
```

Enable the instruction cache on the MicroBlaze processor. When the MicroBlaze processor starts up, the instruction cache is disabled. The instruction cache must be explicitly turned on using this function.

---

```
void microblaze_disable_icache(void)
```

Disable the instruction cache on the MicroBlaze processor.

---

```
void microblaze_invalidate_icache()
```

Invalidate the instruction icache.

**Note:** For MicroBlaze processors prior to version v7.20.a:

The cache and interrupts are disabled before invalidation starts and restored to their previous state after invalidation.

---

```
void microblaze_invalidate_icache_range(unsigned int
    cache_addr, unsigned int cache_size)
```

Invalidate the specified range in the instruction icache. This function can be used for invalidating all or part of the instruction icache.

The parameter `cache_addr` indicates the beginning of the cache location to be invalidated. The `cache_size` represents the number of bytes from the `cache_addr` to invalidate.

Note that *cache lines* are invalidated starting from the cache line to which `cache_addr` belongs and ending at the cache line containing the address (`cache_addr + cache_size - 1`).

For example, `microblaze_invalidate_icache_range(0x00000300, 0x100)` invalidates the instruction cache region from 0x300 to 0x3ff (0x100 bytes of cache memory is cleared starting from 0x300).

**Note:** For MicroBlaze processors prior to version v7.20.a: The cache and interrupts are disabled before invalidation starts and restored to their previous state after invalidation.

## MicroBlaze Processor Data Cache Handling

The following functions help manage data caches on the MicroBlaze processor. You must include the header file `mb_interface.h` in your source code to use these functions.

**Note:** These functions work correctly only when the parameters that determine the caching system are configured appropriately in the MicroBlaze MHS hardware block. Refer to the *MicroBlaze Processor Reference Guide (UG081)* for information on how to configure these cache parameters. “[MicroBlaze Processor API](#),” page 1 contains a link to this document.

### Data Cache Handling Functions

---

```
void microblaze_enable_dcache(void)
```

Enable the data cache on the MicroBlaze processor. When the MicroBlaze processor starts up, the data cache is disabled. The data cache must be explicitly turned on using this function.

---

```
void microblaze_disable_dcache(void)
```

Disable the data cache on the MicroBlaze processor. If writeback caches are enabled in the MicroBlaze processor hardware, this function also flushes the dirty data in the cache back to external memory and invalidates the cache. For write through caches, this function does not do any extra processing other than disabling the cache.

---

```
void microblaze_flush_dcache()
```

Flush the entire data cache. This function can be used when write-back caches are turned on in the MicroBlaze processor hardware. Executing this function ensures that the dirty data in the cache is written back to external memory and the contents invalidated.

- The cache is disabled before the flush starts and is restored to its previous state after the flush is complete.
  - Interrupts are disabled while the cache is being flushed and restored to their previous state after the flush is complete.
- 

```
void microblaze_flush_dcache_range(unsigned int  
    cache_addr, unsigned int cache_len)
```

Flush the specified data cache range. This function can be used when write-back caches are enabled in the MicroBlaze processor hardware. Executing this function ensures that the dirty data in the cache range is written back to external memory and the contents of the cache range are invalidated. Note that *cache lines* will be flushed starting from the cache line to which *cache\_addr* belongs and ending at the cache line containing the address (*cache\_addr* + *cache\_size* - 1).

For example, `microblaze_flush_dcache_range (0x00000300, 0x100)` flushes the data cache region from 0x300 to 0x3ff (0x100 bytes of cache memory is flushed starting from 0x300).

---

```
void microblaze_invalidate_dcache()
```

Invalidate the instruction data cache.

**Note:** For MicroBlaze processors prior to version v7.20.a:

The cache and interrupts are disabled before invalidation starts and restored to their previous state after invalidation.

```
void microblaze_invalidate_dcache_range(unsigned int
    cache_addr, unsigned int cache_size)
```

Invalidate the data cache. This function can be used for invalidating all or part of the data cache. The parameter *cache\_addr* indicates the beginning of the cache location and *cache\_size* represents the size from *cache\_addr* to invalidate.

Note that *cache lines* will be invalidated starting from the cache line to which *cache\_addr* belongs and ending at the cache line containing the address (*cache\_addr* + *cache\_size* - 1).

**Note:** For MicroBlaze processors prior to version v7.20.a:

The cache and interrupts are disabled before invalidation starts and restored to their previous state after invalidation.

For example, `microblaze_invalidate_dcache_range (0x00000300, 0x100)` invalidates the data cache region from 0x300 to 0x3ff (0x100 bytes of cache memory is cleared starting from 0x300).

## Software Sequence for Initializing Instruction and Data Caches

Typically, before using the cache, your program must perform a particular sequence of cache operations to ensure that invalid/dirty data in the cache is not being used by the processor. This would typically happen during repeated program downloads and executions.

The following example snippets show the necessary software sequence for initializing instruction and data caches in your program.

```
/* Initialize ICache */
microblaze_invalidate_icache();
microblaze_enable_icache ();

/* Initialize DCache */
microblaze_invalidate_dcache();
microblaze_enable_dcache ();
```

At the end of your program, you should also put in a sequence similar to the example snippet below. This ensures that the cache and external memory are left in a valid and clean state.

```
/* Clean up DCache. For writeback caches, the disable_dcache routine
   internally does the flush and invalidate. For write through caches,
   an explicit invalidation must be performed on the entire cache. */

#if XPAR_MICROBLAZE_DCACHE_USE_WRITEBACK == 0
microblaze_invalidate_dcache();
#endif

microblaze_disable_dcache();

/* Clean up ICache */
microblaze_invalidate_icache();
microblaze_disable_icache();
```

## MicroBlaze Processor Fast Simplex Link (FSL) Interface Macros

Standalone includes macros to provide convenient access to accelerators connected to the MicroBlaze Fast Simplex Link (FSL) Interfaces.

## MicroBlaze Processor Fast Simplex Link (FSL) Interface Macro Summary

The following is a list of the available macros. Click on a macro name to go to the description of the active macros.

<a href="#">getfslx(val,id,flags)</a>	<a href="#">putdfslx(val,id,flags)</a>
<a href="#">putfslx(val,id,flags)</a>	<a href="#">tgetdfslx(val,id,flags)</a>
<a href="#">tgetfslx(val,id,flags)</a>	<a href="#">tputdfslx(val,id,flags)</a>
<a href="#">getdfslx(val,id,flags)</a>	<a href="#">fsl_isinvalid(invalid)</a>
	<a href="#">fsl_iserror(error)</a>

## MicroBlaze Processor FSL Macro Descriptions

The following macros provide access to all of the functionality of the MicroBlaze FSL feature in one simple and parameterized interface. Some capabilities are available on MicroBlaze v7.00.a and later only, as noted in the descriptions.

In the macro descriptions, *val* refers to a variable in your program that can be the source or sink of the FSL operation.

**Note:** *id* must be an integer *literal* in the basic versions of the macro (`getfslx`, `putfslx`, `tgetfslx`, `tputfslx`) and can be an integer literal or an integer variable in the dynamic versions of the macros (`getdfslx`, `putdfslx`, `tgetdfslx`, `tputdfslx`.)

You must include `fsl.h` in your source files to make these macros available.

---

### **getfslx**(*val*, *id*, *flags*)

Performs a get function on an input FSL of the MicroBlaze processor; *id* is the FSL identifier and is a literal in the range of 0 to 7 (0 to 15 for MicroBlaze v7.00.a and later). The semantics of the instruction is determined by the valid FSL macro flags, which are listed in [Table 2, page 9](#).

---

### **putfslx**(*val*, *id*, *flags*)

Performs a put function on an input FSL of the MicroBlaze processor; *id* is the FSL identifier and is a literal in the range of 0 to 7 (0 to 15 for MicroBlaze processor v7.00.a and later).

The semantics of the instruction is determined by the valid FSL macro flags, which are listed in [Table 2, page 9](#).

---

### **tgetfslx**(*val*, *id*, *flags*)

Performs a test get function on an input FSL of the MicroBlaze processor; *id* is the FSL identifier and is a literal in the ranging of 0 to 7 (0 to 15 for MicroBlaze v7.00.a and later). This macro can be used to test reading a single value from the FSL. The semantics of the instruction is determined by the valid FSL macro flags, which are listed in [Table 2, page 9](#).

---

**tputfslx**(*val*, *id*, *flags*)

Performs a put function on an input FSL of the MicroBlaze processor; *id* is the FSL identifier and is a literal in the range of 0 to 7 (0 to 15 for MicroBlaze processor v7.00.a and later). This macro can be used to test writing a single value to the FSL. The semantics of the put instruction is determined by the valid FSL macro flags, which are listed in [Table 2, page 9](#).

---

**getd fslx**(*val*, *id*, *flags*)

Performs a get function on an input FSL of the MicroBlaze processor; *id* is the FSL identifier and is an integer value or variable in the range of 0 to 15. The semantics of the instruction is determined by the valid FSL macro flags, which are listed in [Table 2, page 9](#). This macro is available on MicroBlaze processor v7.00.a and later only.

---

**putdfslx**(*val*, *id*, *flags*)

Performs a put function on an input FSL of the MicroBlaze processor; *id* is the FSL identifier and is an integer value or variable in the range of 0 to 15. The semantics of the instruction is determined by the valid FSL macro flags, which are listed in [Table 2, page 9](#). This macro is available on MicroBlaze processor v7.00.a and later only.

---

**tgetdfslx**(*val*, *id*, *flags*)

Performs a test get function on an input FSL of the MicroBlaze processor; *id* is the FSL identifier and is an integer or variable in the range of 0 to 15. This macro can be used to test reading a single value from the FSL. The semantics of the instruction is determined by the valid FSL macro flags, listed in [Table 2](#). This macro is available on MicroBlaze processor v7.00.a and later only.

---

**tputdfslx**(*val*, *id*, *flags*)

Performs a put function on an input FSL of the MicroBlaze processor; *id* is the FSL identifier and is an integer or variable in the range of 0 to 15. This macro can be used to test writing a single value to the FSL. The semantics of the instruction is determined by the valid FSL macro flags, listed in [Table 2](#). This macro is available on MicroBlaze processor v7.00.a and later only.

---

**fsl\_isinvalid**(*invalid*)

Checks if the last FSL operation returned valid data. This macro is applicable after invoking a non-blocking FSL put or get instruction. If there was no data on the FSL channel on a get, or if the FSL channel was full on a put, *invalid* is set to 1; otherwise, it is set to 0.

---

**fsl\_iserror**(*error*)

This macro is used to check if the last FSL operation set an error flag. This macro is applicable after invoking a control FSL put or get instruction. If the control bit was set *error* is set to 1; otherwise, it is set to 0.



## MicroBlaze Processor FSL Macro Flags

Table 2 lists the available FSL Macro flags.

Table 2: FSL Macro Flags

Flag	Description
FSL_DEFAULT	Blocking semantics (on MicroBlaze processor v7.00.a and later this mode is interruptible).
FSL_NONBLOCKING	Non-blocking semantics. <sup>1</sup>
FSL_EXCEPTION	Generate exceptions on control bit mismatch. <sup>2</sup>
FSL_CONTROL	Control semantics.
FSL_ATOMIC	Atomic semantics. A sequence of FSL instructions cannot be interrupted.
FSL_NONBLOCKING_EXCEPTION	Combines non-blocking and exception semantics.
FSL_NONBLOCKING_CONTROL	Combines non-blocking and control semantics.
FSL_NONBLOCKING_ATOMIC	Combines non-blocking and atomic semantics.
FSL_EXCEPTION_CONTROL	Combines exception and control semantics.
FSL_EXCEPTION_ATOMIC	Combines exception and atomic semantics.
FSL_CONTROL_ATOMIC	Combines control and atomic semantics.
FSL_NONBLOCKING_EXCEPTION_CONTROL	Combines non-blocking, exception, and control semantics. <sup>2</sup>
FSL_NONBLOCKING_EXCEPTION_ATOMIC	Combines non-blocking, exception, and atomic semantics.
FSL_NONBLOCKING_CONTROL_ATOMIC	Combines non-blocking, atomic, and control semantics.
FSL_EXCEPTION_CONTROL_ATOMIC	Combines exception, atomic, and control semantics.
FSL_NONBLOCKING_EXCEPTION_CONTROL_ATOMIC	Combines non-blocking, exception, control, and atomic semantics.

1. When non-blocking semantics are not applied, blocking semantics are implied.

2. This combination of flags is available only on MicroBlaze processor v7.00.a and later versions.

## Deprecated MicroBlaze Processor Fast Simplex Link (FSL) Macros

The following macros are deprecated:

---

### **getfsl**(*val*, *id*) (deprecated)

Performs a blocking data get function on an input FSL of the MicroBlaze processor; *id* is the FSL identifier in the range of 0 to 7. This macro is uninterruptible.

---

### **putfsl**(*val*, *id*) (deprecated)

Performs a blocking data put function on an output FSL of the MicroBlaze processor; *id* is the FSL identifier in the range of 0 to 7. This macro is uninterruptible.

---

**ngetfsl**(*val*, *id*) (deprecated)

Performs a non-blocking data get function on an input FSL of the MicroBlaze processor; *id* is the FSL identifier in the range of 0 to 7.

---

**nputfsl**(*val*, *id*) (deprecated)

Performs a non-blocking data put function on an output FSL of the MicroBlaze processor; *id* is the FSL identifier in the range of 0 to 7.

---

**cgetfsl**(*val*, *id*) (deprecated)

Performs a blocking control get function on an input FSL of the MicroBlaze processor; *id* is the FSL identifier in the range of 0 to 7. This macro is uninterruptible.

---

**cputfsl**(*val*, *id*) (deprecated)

Performs a blocking control put function on an output FSL of the MicroBlaze processor; *id* is the FSL identifier in the range of 0 to 7. This macro is uninterruptible.

---

**ncgetfsl**(*val*, *id*) (deprecated)

Performs a non-blocking control get function on an input FSL of the MicroBlaze processor; *id* is the FSL identifier in the range of 0 to 7.

---

**ncputfsl**(*val*, *id*) (deprecated)

Performs a non-blocking control put function on an output FSL of the MicroBlaze processor; *id* is the FSL identifier in the range of 0 to 7.

---

**getfsl\_interruptible**(*val*, *id*) (deprecated)

Performs repeated non-blocking data get operations on an input FSL of the MicroBlaze processor until valid data is actually fetched; *id* is the FSL identifier in the range of 0 to 7. Because the FSL access is non-blocking, interrupts will be serviced by the processor.

---

**putfsl\_interruptible**(*val*, *id*) (deprecated)

Performs repeated non-blocking data put operations on an output FSL of the MicroBlaze processor until valid data is sent out; *id* is the FSL identifier in the range of 0 to 7. Because the FSL access is non-blocking, interrupts will be serviced by the processor.

---

---

**cgetfsl\_interruptible**(*val*, *id*) (deprecated)

Performs repeated non-blocking control get operations on an input FSL of the MicroBlaze processor until valid data is actually fetched; *id* is the FSL identifier in the range of 0 to 7. Because the FSL access is non-blocking, interrupts are serviced by the processor.

---

**cputfsl\_interruptible**(*val*, *id*) (deprecated)

Performs repeated non-blocking control put operations on an output FSL of the MicroBlaze processor until valid data is sent out; *id* is the FSL identifier in the range of 0 to 7. Because the FSL access is non-blocking, interrupts are serviced by the processor.

## MicroBlaze Processor Pseudo-asm Macros

Standalone includes macros to provide convenient access to various registers in the MicroBlaze processor. Some of these macros are very useful within exception handlers for retrieving information about the exception. To use these macros, you must include the `mb_interface.h` header file in your source code.

### MicroBlaze Processor Pseudo-asm Macro Summary

The following is a summary of the MicroBlaze processor pseudo-asm macros. Click on the macro name to go to the description.

[mfgpr\(rn\)](#)  
[mfmsr\( \)](#)  
[mfesr\( \)](#)  
[mfear\( \)](#)  
[mffsr\( \)](#)  
[mtmsr\(v\)](#)  
[mtgpr\(rn,v\)](#)  
[microblaze\\_getfpex\\_operand\\_a\( \)](#)  
[microblaze\\_getfpex\\_operand\\_b\( \)](#)  
[clz\(v\)](#)  
[mbar\(mask\)](#)  
[mb\\_swapb\(v\)](#)  
[mb\\_swaph\(v\)](#)  
[mb\\_sleep](#)

### MicroBlaze Processor Pseudo-asm Macro Descriptions

---

**mfgpr** ( *rn* )

Return value from the general purpose register (GPR) *rn*.

---

**mfmsr** ( )

Return the current value of the MSR.

---

**mfesr** ( )

Return the current value of the Exception Status Register (ESR).

---

**mfear** ( )

Return the current value of the Exception Address Register (EAR).

---

---

**mffsr** ( )

Return the current value of the Floating Point Status (FPS).

---

**mtmsr** ( *v* )

Move the value *v* to MSR.

---

**mtgpr** ( *rn*, *v* )

Move the value *v* to GPR *rn*.

---

**microblaze\_getfpex\_operand\_a** ( )

Return the saved value of operand A of the last faulting floating point instruction.

---

**microblaze\_getfpex\_operand\_b** ( )

Return the saved value of operand B of the last faulting floating point instruction.

**Note:** Because of the way some of these macros have been written, they cannot be used as parameters to function calls and other such constructs.

---

**clz** ( *v* )

Counts the number of leading zeros in the data specified by *v*

---

**mbar** ( *mask* )

This instruction ensures that outstanding memory accesses on memory interfaces are completed before any subsequent instructions are executed. *mask* value of 1 specifies data side barrier, *mask* value of 2 specifies instruction side barrier and *mask* value of 16 specifies to put the processor in sleep.

---

**mb\_swapb** ( *v* )

Swaps the bytes in the data specified by *v*. This converts the bytes in the data from little endian to big endian or vice versa. So *v* contains a value of 0x12345678, the macro will return a value of 0x78563412.

---

**mb\_swaph** ( *v* )

Swaps the half words in the data specified by *v*. So if *v* has a value of 0x12345678, the macro will return a value of 0x56781234.

---

**mb\_sleep**

Puts the processor in sleep.

---

## MicroBlaze Processor Version Register (PVR) Access Routine and Macros

MicroBlaze processor v5.00.a and later versions have configurable Processor Version Registers (PVRs). The contents of the PVR are captured using the `pvr_t` data structure, which is defined as an array of 32-bit words, with each word corresponding to a PVR register on hardware. The number of PVR words is determined by the number of PVRs configured in the hardware. You should not attempt to access PVR registers that are not present in hardware, as the `pvr_t` data structure is resized to hold only as many PVRs as are present in hardware.

To access information in the PVR:

1. Use the `microblaze_get_pvr()` function to populate the PVR data into a `pvr_t` data structure.
2. In subsequent steps, you can use any one of the PVR access macros list to get individual data stored in the PVR.

**Note:** The PVR access macros take a parameter, which must be of type `pvr_t`.

### PVR Access Routine

The following routine is used to access the PVR. You must include `pvr.h` file to make this routine available.

---

```
int microblaze_get_pvr(pvr_t *pvr)
```

Populate the PVR data structure to which `pvr` points with the values of the hardware PVR registers. This routine populates only as many PVRs as are present in hardware and the rest are zeroed. This routine is not available if `C_PVR` is set to `NONE` in hardware.

### PVR Macros

The following processor macros are used to access the PVR. You must include `pvr.h` file to make these macros available.

[Table 3](#) lists the MicroBlaze processor PVR macros and descriptions.

**Table 3: PVR Access Macros**

Macro	Description
<code>MICROBLAZE_PVR_IS_FULL(pvr)</code>	Return non-zero integer if PVR is of type FULL, 0 if basic.
<code>MICROBLAZE_PVR_USE_BARREL(pvr)</code>	Return non-zero integer if hardware barrel shifter present.
<code>MICROBLAZE_PVR_USE_DIV(pvr)</code>	Return non-zero integer if hardware divider present.
<code>MICROBLAZE_PVR_USE_HW_MUL(pvr)</code>	Return non-zero integer if hardware multiplier present.
<code>MICROBLAZE_PVR_USE_FPU(pvr)</code>	Return non-zero integer if hardware floating point unit (FPU) present.
<code>MICROBLAZE_PVR_USE_FPU2(pvr)</code>	Return non-zero integer if hardware floating point conversion and square root instructions are present.
<code>MICROBLAZE_PVR_USE_ICACHE(pvr)</code>	Return non-zero integer if I-cache present.
<code>MICROBLAZE_PVR_USE_DCACHE(pvr)</code>	Return non-zero integer if D-cache present.

Table 3: PVR Access Macros (Cont'd)

Macro	Description
MICROBLAZE_PVR_MICROBLAZE_VERSION (pvr)	Return MicroBlaze processor version encoding. Refer to the <i>MicroBlaze Processor Reference Guide (UG081)</i> for mappings from encodings to actual hardware versions. <a href="#">“MicroBlaze Processor API,” page 1</a> contains a link to this document.
MICROBLAZE_PVR_USER1 (pvr)	Return the USER1 field stored in the PVR.
MICROBLAZE_PVR_USER2 (pvr)	Return the USER2 field stored in the PVR.
MICROBLAZE_PVR_INTERCONNECT (pvr)	Return non-zero if MicroBlaze processor has PLB interconnect; otherwise return zero.
MICROBLAZE_PVR_D_PLB (pvr)	Return non-zero integer if Data Side PLB interface is present.
MICROBLAZE_PVR_D_OPB (pvr)	Return non-zero integer if Data Side On-chip Peripheral Bus (OPB) interface present.
MICROBLAZE_PVR_D_LMB (pvr)	Return non-zero integer if Data Side Local Memory Bus (LMB) interface present.
MICROBLAZE_PVR_I_PLB (pvr)	Return non-zero integer if Instruction Side PLB interface is present.
MICROBLAZE_PVR_I_OPB (pvr)	Return non-zero integer if Instruction side OPB interface present.
MICROBLAZE_PVR_I_LMB (pvr)	Return non-zero integer if Instruction side LMB interface present.
MICROBLAZE_PVR_INTERRUPT_IS_EDGE (pvr)	Return non-zero integer if interrupts are configured as edge-triggered.
MICROBLAZE_PVR_EDGE_IS_POSITIVE (pvr)	Return non-zero integer if interrupts are configured as positive edge triggered.
MICROBLAZE_PVR_USE_MUL64 (pvr)	Return non-zero integer if MicroBlaze processor supports 64-bit products for multiplies.
MICROBLAZE_PVR_OPCODE_0x0_ILLEGAL (pvr)	Return non-zero integer if opcode 0x0 is treated as an illegal opcode.
MICROBLAZE_PVR_UNALIGNED_EXCEPTION (pvr)	Return non-zero integer if unaligned exceptions are supported.
MICROBLAZE_PVR_ILL_OPCODE_EXCEPTION (pvr)	Return non-zero integer if illegal opcode exceptions are supported.
MICROBLAZE_PVR_IOPB_EXCEPTION (pvr)	Return non-zero integer if I-OPB exceptions are supported.
MICROBLAZE_PVR_DOPB_EXCEPTION (pvr)	Return non-zero integer if D-OPB exceptions are supported.
MICROBLAZE_PVR_IPLB_EXCEPTION (pvr)	Return non-zero integer if I-PLB exceptions are supported.
MICROBLAZE_PVR_DPLB_EXCEPTION (pvr)	Return non-zero integer if D-PLB exceptions are supported.
MICROBLAZE_PVR_DIV_ZERO_EXCEPTION (pvr)	Return non-zero integer if divide by zero exceptions are supported.

Table 3: PVR Access Macros (Cont'd)

Macro	Description
MICROBLAZE_PVR_FPU_EXCEPTION(pvr)	Return non-zero integer if FPU exceptions are supported.
MICROBLAZE_PVR_FSL_EXCEPTION(pvr)	Return non-zero integer if FSL exceptions are present.
MICROBLAZE_PVR_DEBUG_ENABLED(pvr)	Return non-zero integer if debug is enabled.
MICROBLAZE_PVR_NUM_PC_BRK(pvr)	Return the number of hardware PC breakpoints available.
MICROBLAZE_PVR_NUM_RD_ADDR_BRK(pvr)	Return the number of read address hardware watchpoints supported.
MICROBLAZE_PVR_NUM_WR_ADDR_BRK(pvr)	Return the number of write address hardware watchpoints supported.
MICROBLAZE_PVR_FSL_LINKS(pvr)	Return the number of FSL links present.
MICROBLAZE_PVR_ICACHE_BASEADDR(pvr)	Return the base address of the I-cache.
MICROBLAZE_PVR_ICACHE_HIGHADDR(pvr)	Return the high address of the I-cache.
MICROBLAZE_PVR_ICACHE_ADDR_TAG_BITS(pvr)	Return the number of address tag bits for the I-cache.
MICROBLAZE_PVR_ICACHE_USE_FSL(pvr)	Return non-zero if I-cache uses FSL links.
MICROBLAZE_PVR_ICACHE_ALLOW_WR(pvr)	Return non-zero if writes to I-caches are allowed.
MICROBLAZE_PVR_ICACHE_LINE_LEN(pvr)	Return the length of each I-cache line in bytes.
MICROBLAZE_PVR_ICACHE_BYTE_SIZE(pvr)	Return the size of the D-cache in bytes.
MICROBLAZE_PVR_DCACHE_BASEADDR(pvr)	Return the base address of the D-cache.
MICROBLAZE_PVR_DCACHE_HIGHADDR(pvr)	Return the high address of the D-cache.
MICROBLAZE_PVR_DCACHE_ADDR_TAG_BITS(pvr)	Return the number of address tag bits for the D-cache.
MICROBLAZE_PVR_DCACHE_USE_FSL(pvr)	Return non-zero if the D-cache uses FSL links.
MICROBLAZE_PVR_DCACHE_ALLOW_WR(pvr)	Return non-zero if writes to D-cache are allowed.
MICROBLAZE_PVR_DCACHE_LINE_LEN(pvr)	Return the length of each line in the D-cache in bytes.
MICROBLAZE_PVR_DCACHE_BYTE_SIZE(pvr)	Return the size of the D-cache in bytes.
MICROBLAZE_PVR_TARGET_FAMILY(pvr)	Return the encoded target family identifier.

Table 3: PVR Access Macros (Cont'd)

Macro	Description
<code>MICROBLAZE_PVR_MSR_RESET_VALUE</code>	Refer to the <i>MicroBlaze Processor Reference Guide (UG081)</i> for mappings from encodings to target family name strings. <a href="#">“MicroBlaze Processor API,” page 1</a> contains a link to this document.
<code>MICROBLAZE_PVR_MMU_TYPE(pvr)</code>	Returns the value of <code>C_USE_MMU</code> . Refer to the <i>MicroBlaze Processor Reference Guide (UG081)</i> for mappings from MMU type values to MMU function. <a href="#">“MicroBlaze Processor API,” page 1</a> contains a link to this document.

## MicroBlaze Processor File Handling

The following routine is included for file handling:

---

```
int fcntl(int fd, int cmd, long arg);
```

A dummy implementation of `fcntl( )`, which always returns 0, is provided. `fcntl` is intended to manipulate file descriptors according to the command specified by *cmd*. Because Standalone does not provide a file system, this function is included for completeness only.

## MicroBlaze Processor Errno

The following routine provides the error number value:

---

```
int errno( );
```

Return the global value of `errno` as set by the last C library call.

## PowerPC 405 Processor API

Standalone for the PowerPC® 405 processor contains boot code, cache, file and memory management, configuration, exception handling, time and processor-specific include functions.

The following is a list of the PowerPC 405 processor API sections. To go the function description, click the function name in the summary.

- [“PowerPC 405 Processor Boot Code”](#)
- [“PowerPC 405 Processor Cache Functions”](#)
- [“PowerPC 405 Processor Exception Handling Function Summary”](#)
- [“PowerPC 405 Processor Files”](#)
- [“PowerPC 405 Processor Errno”](#)
- [“PowerPC 405 Processor Memory Management”](#)
- [“PowerPC 405 Processing Functions”](#)
- [“PowerPC 405 Processor-Specific Include Files”](#)
- [“PowerPC 405 Processor Time Functions”](#)
- [“PowerPC 405 Processor Fast Simplex Link Interface Macros”](#)
- [“PowerPC 405 Processor Pseudo-asm Macro Summary”](#)
- [“PowerPC 405 Macros for APU FCM User-Defined Instructions”](#)



## PowerPC 405 Processor Boot Code

The `boot.S` file contains a minimal set of code for transferring control from the processor's reset location to the start of the application. Code in the `boot.S` consists of the two sections `boot` and `boot0`. The `boot` section contains only one instruction that is labeled with `_boot`. During the link process, this instruction is mapped to the reset vector and the `_boot` label marks the application's entry point. The `boot` instruction is a jump to the `_boot0` label. The `_boot0` label must reside within a  $\pm 23$ -bit address space of the `_boot` label. It is defined in the `boot0` section. The code in the `boot0` section calculates the 32-bit address of the `_start` label and jumps to that address.

## PowerPC 405 Processor Cache Functions

The `xcache_1.c` file and corresponding `xcache_1.h` include file provide access to the following cache and cache-related operations

### PowerPC 405 Processor Cache Function Summary

The following are links to the function descriptions. Click on the name to go to that function.

[void XCache\\_WriteCCR0\(unsigned int val\)](#)  
[void XCache\\_EnableDCache\(unsigned int regions\)](#)  
[void XCache\\_DisableDCache\(void\)](#)  
[void XCache\\_FlushDCacheLine\(unsigned int adr\)](#)  
[void XCache\\_InvalidateDCacheLine\(unsigned int adr\)](#)  
[void XCache\\_FlushDCacheRange\(unsigned int adr, unsigned len\)](#)  
[void XCache\\_InvalidateDCacheRange\(unsigned int adr, unsigned len\)](#)  
[void XCache\\_StoreDCacheLine\(unsigned int adr\);](#)  
[void XCache\\_EnableICache\(unsigned int regions\);](#)  
[void XCache\\_DisableICache\(void\);](#)  
[void XCache\\_InvalidateICache\(void\);](#)  
[void XCache\\_InvalidateICacheLine\(unsigned int adr\)](#)

### PowerPC 405 Processor Cache Function Descriptions

---

```
void XCache_WriteCCR0(unsigned int val)
```

Writes an integer value to the CCR0 register. Below is a sample code sequence. Before writing to this register, the instruction cache must be enabled to prevent a lockup of the processor core. After writing the CCR0, the instruction cache can be disabled, if not needed.

```

XCache_EnableICache(0x80000000) /* enable instruction cache for first 128
MB memory region */
XCache_WriteCCR0(0x2700E00) /* enable 8 word pre-fetching */
XCache_DisableICache() /* disable instruction cache */

```

---

```
void XCache_EnableDCache(unsigned int regions)
```

Enables the data cache for a specific memory region. Each bit in the *regions* parameter represents 128 MB of memory.

A value of `0x80000000` enables the data cache for the first 128 MB of memory (`0 - 0x07FFFFFF`). A value of `0x1` enables the data cache for the last 128 MB of memory (`0xF8000000 - 0xFFFFFFFF`).

---

```
void XCache_DisableDCache(void)
```

Disables the data cache for all memory regions.

---

```
void XCache_FlushDCacheLine(unsigned int adr)
```

Flushes and invalidates the data cache line that contains the address specified by the *adr* parameter. A subsequent data access to this address results in a cache miss and a cache line refill.

---

```
void XCache_InvalidateDCacheLine(unsigned int adr)
```

Invalidates the data cache line that contains the address specified by the *adr* parameter. If the cache line is currently dirty, the modified contents are lost and are **not** written to system memory. A subsequent data access to this address results in a cache miss and a cache line refill.

---

```
void XCache_FlushDCacheRange(unsigned int adr, unsigned len)
```

Flushes and invalidates the data cache lines that are described by the address range starting from *adr* and *len* bytes long. A subsequent data access to any address in this range results in a cache miss and a cache line refill.

---

```
void XCache_InvalidateDCacheRange(unsigned int adr,  
    unsigned len)
```

Invalidates the data cache lines that are described by the address range starting from *adr* and *len* bytes long. If a cache line is currently dirty, the modified contents are lost and are *not* written to system memory. A subsequent data access to any address in this range results in a cache miss and a cache line refill.

---

```
void XCache_StoreDCacheLine(unsigned int adr);
```

Stores in memory the data cache line that contains the address specified by the *adr* parameter. A subsequent data access to this address results in a cache hit if the address was already cached; otherwise, it results in a cache miss and cache line refill.

---

```
void XCache_EnableICache(unsigned int regions);
```

Enables the instruction cache for a specific memory region. Each bit in the *regions* parameter represents 128 MB of memory.

A value of 0x80000000 enables the instruction cache for the first 128 MB of memory (0 - 0x07FFFFFF). A value of 0x1 enables the instruction cache for the last 128 MB of memory (0xF8000000 - 0xFFFFFFFF).

---

```
void XCache_DisableICache(void);
```

Disables the instruction cache for all memory regions.

---

```
void XCache_InvalidateICache(void);
```

Invalidates the whole instruction cache. Subsequent instructions produce cache misses and cache line refills.

---

```
void XCACHE_InvalidateICacheLine(unsigned int adr)
```

Invalidates the instruction cache line that contains the address specified by the *adr* parameter. A subsequent instruction to this address produces a cache miss and a cache line refill.

## PowerPC 405 Processor Exception Handling

An exception handling API is provided in Standalone. For an in-depth explanation on how exceptions and interrupts work on the PowerPC processor, refer to the chapter “Exceptions and Interrupts” in the *PowerPC Processor Reference Guide (UG011)*. A link to this document is provided in “[MicroBlaze Processor API](#),” page 1.

**Note:** Exception handlers do not automatically reset (disable) the wait state enable bit in the MSR when returning to user code. You can force exception handlers to reset the Wait-Enable bit to zero on return from all exceptions by compiling Standalone with the preprocessor symbol `PPC405_RESET_WE_ON_RFI` defined. You can add this to the compiler flags associated with the libraries. This pre-processor define turns the behavior on.

The exception handling API consists of a set of the files `xvectors.S`, `xexception_l.c`, and the corresponding header file `xexception_l.h`.

For additional information on interrupt handling, refer to the “Interrupt Management” appendix in the *Embedded System Tools Reference Manual (UG111)*, available in the `/doc` directory of your EDK installation.

## PowerPC 405 Processor Exception Handling Function Summary

The following are links to the function descriptions. Click on the name to go to that function.

```
void XExc\_Init\(void\)
void XExc\_RegisterHandler\(Xuint8 ExceptionId, XExceptionHandler Handler, void \*DataPtr\)
void XExc\_RemoveHandler\(Xuint8 ExceptionId\)
void XExc\_mEnableExceptions\(EnableMask\)
void XExc\_mDisableExceptions\(DisableMask\)
```

## PowerPC 405 Processor Exception Handling Function Descriptions

---

```
void XExc_Init(void)
```

Sets up the interrupt vector table and registers a “do nothing” function for each exception. This function has no parameters and does not return a value.

This function must be called before registering any exception handlers or enabling any interrupts. When using the exception handler API, this function should be called at the beginning of your `main( )` routine.

**IMPORTANT:** If you are not using the default linker script, you need to reserve memory space for storing the vector table in your linker script. The memory space must begin on a 64 k boundary.

The linker script entry should look like this example:

```
.vectors :
{
    . = ALIGN(64k);
    *(.vectors)
}
```

For further information on linker scripts, refer to the Linker documentation.

```
void XExc_RegisterHandler(Xuint8 ExceptionId,
                          XExceptionHandler Handler, void *DataPtr)
```

Registers an exception handler for a specific exception; does not return a value. Refer to the following table for a list of exception types and their values.

The parameters are:

- *ExceptionId* is of parameter type `Xuint8`, and is the exception to which this handler should be registered. The type and the values are defined in the `xexception_1.h` header file. The following table lists the exception types and possible values.
- *Handler* is an `XExceptionHandler` parameter which is the pointer to the exception handling function.
- *DataPtr* is of parameter type `void *` and is the user value to be passed when the handling function is called.

**Table 4: Registered Exception Types and Values**

Exception Type	Value
XEXC_ID_MACHINE_CHECK	1
XEXC_ID_CRITICAL_INT	2
XEXC_ID_DATA_STORAGE_INT	3
XEXC_ID_INSTRUCTION_STORAGE_INT	4
XEXC_ID_NON_CRITICAL_INT	5
XEXC_ID_ALIGNMENT_INT	6
XEXC_ID_PROGRAM_INT	7
XEXC_ID_FPU_UNAVAILABLE_INT	8
XEXC_ID_SYSTEM_CALL	9
XEXC_ID_APU_AVAILABLE	10
XEXC_ID_PIT_INT	11
XEXC_ID_FIT_INT	12
XEXC_ID_WATCHDOG_TIMER_INT	13
XEXC_ID_DATA_TLB_MISS_INT	14
XEXC_ID_INSTRUCTION_TLB_MISS_INT	15
XEXC_ID_DEBUG_INT	16

The function provided as the *Handler* parameter must have the following function prototype:

```
typedef void (*XExceptionHandler)(void * DataPtr);
```

This prototype is declared in the `xexception_1.h` header file.

When this exception handler function is called, the parameter *DataPtr* contains the same value as you provided when you registered the handler.

---

```
void XExc_RemoveHandler(Xuint8 ExceptionId)
```

De-register a handler function for a given exception. For possible values of parameter *ExceptionId*, refer to [Table 7, page 38](#).

---

```
void XExc_mEnableExceptions (EnableMask)
```

Enable exceptions. This macro must be called after initializing the vector table with function `exception_Init` and registering exception handlers with function `XExc_RegisterHandler`. The parameter `EnableMask` is a bitmask for exceptions to be enabled. The `EnableMask` parameter can have the values `XEXC_CRITICAL`, `XEXC_NON_CRITICAL`, or `XEXC_ALL`.

---

```
void XExc_mDisableExceptions (DisableMask)
```

Disable exceptions. The parameter `DisableMask` is a bitmask for exceptions to be disabled. The `DisableMask` parameter can have the values `XEXC_CRITICAL`, `XEXC_NON_CRITICAL`, or `XEXC_ALL`.

---

## PowerPC 405 Processor Files

File support is limited to the `stdin` and `stdout` streams; consequently, the following functions are not necessary:

- `open()` (in `open.c`)
- `close()` (in `close.c`)
- `fstat()` (in `fstat.c`)
- `unlink()` (in `unlink.c`)
- `lseek()` (in `lseek.c`)

These files are included for completeness and because they are referenced by the C library.

---

```
int read(int fd, char *buf, int nbytes)
```

The `read()` function in `read.c` reads `nbytes` bytes from the standard input by calling `inbyte()`. It blocks until all characters are available, or the end of line character is read. The `read()` function returns the number of characters read. The `fd` parameter is ignored.

---

```
int write(int fd, char *buf, int nbytes)
```

Writes `nbytes` bytes to the standard output by calling `outbyte()`. It blocks until all characters have been written. The `write()` function returns the number of characters written. The `fd` parameter is ignored.

---

```
int isatty(int fd)
```

Reports if a file is connected to a tty. This function always returns 1, Because only the `stdin` and `stdout` streams are supported.

---

```
int fcntl(int fd, int cmd, long arg);
```

A dummy implementation of `fcntl`, which always returns 0. `fcntl` is intended to manipulate file descriptors according to the command specified by `cmd`. Because Standalone does not provide a file system, this function is not used.

---

---

## PowerPC 405 Processor Errno

---

```
int errno()
```

Returns the global value of `errno` as set by the last C library call.

---

## PowerPC 405 Processor Memory Management

---

```
char *sbrk(int nbytes)
```

Allocates *nbytes* of heap and returns a pointer to that piece of memory. This function is called from the memory allocation functions of the C library.

---

## PowerPC 405 Processing Functions

The functions `getpid( )` in `getpid.c` and `kill( )` in `kill.c` are included for completeness and because they are referenced by the C library.

---

## PowerPC 405 Processor-Specific Include Files

The `xreg405.h` include file contains the register numbers and the register bits for the PowerPC 405 processor.

The `xpseudo-asm.h` include file contains the definitions for the most often used inline assembler instructions, available as macros. These can be very useful for tasks such as setting or getting special purpose registers, synchronization, or cache manipulation.

These inline assembler instructions can be used from drivers and user applications written in C.

---

## PowerPC 405 Processor Time Functions

The `xtime_1.c` file and corresponding `xtime_1.h` include file provide access to the 64-bit time base counter inside the PowerPC core. The counter increases by one at every processor cycle.

The `sleep.c` file and corresponding `sleep.h` include file implement sleep functions. Sleep functions are implemented as busy loops

## PowerPC 405 Processor Time Function Summary

The following are links to the function descriptions. Click on the name to go to that function.

```

typedef unsigned long long XTime
void XTime_SetTime(XTime xtime)
void XTime_GetTime(XTime *xtime)
void XTime_TSRClearStatusBits(unsigned long Bitmask)
void XTime_PITSetInterval(unsigned long interval)
void XTime_PITEnableInterrupt(void)
void XTime_PITDisableInterrupt(void)
void XTime_PITEnableAutoReload(void)
void XTime_PITDisableAutoReload(void)
void XTime_PITClearInterrupt(void)
void XTime_FITEnableInterrupt(void)
void XTime_FITDisableInterrupt(void)
void XTime_FITClearInterrupt(void)
void XTime_FITSetPeriod(unsigned long Period)
void XTime_WDTEnableInterrupt(void)
void XTime_WDTDisableInterrupt(void)
void XTime_WDTClearInterrupt(void)
void XTime_WDTSetPeriod(unsigned long Period)
void XTime_WDTResetControl(unsigned long ControlVal)
void XTime_WDTEnableNextWatchdog(void)
void XTime_WDTClearResetStatus(void)
unsigned int usleep(unsigned int _useconds)
unsigned int sleep(unsigned int _seconds)
int nanosleep(const struct timespec *rqtp, struct timespec *rmtp)

```

## PowerPC 405 Processor Time Function Descriptions

---

```

typedef unsigned long long XTime

```

The `XTime` type in `xtime_1.h` represents the Time Base register. This struct consists of the Time Base Low (TBL) and Time Base High (TBH) registers, each of which is a 32-bit wide register.

The definition of `XTime` is as follows:

```

typedef unsigned long long XTime;

```

---

```

void XTime_SetTime(XTime xtime)

```

Sets the time base register to the value in `xtime`.

```
void XTime_GetTime(XTime *xtime)
```

Writes the current value of the time base register to variable *xtime*.

```
void XTime_TSRClearStatusBits(unsigned long Bitmask)
```

Clears bits in the Timer Status Register (TSR). The parameter *Bitmask* designates the bits to be cleared. A value of 1 in any position of the Bitmask parameter clears the corresponding bit in the TSR. This function does not return a value.

**Example:**

```
XTime_TSRClearStatusBits(TSR_CLEAR_ALL);
```

Table 5 contains the values for the Bitmask parameters which are specified in the `xreg405.h` header file.

**Table 5: Bitmask Parameter Values**

Name	Value	Description
XREG_TSR_WDT_ENABLE_NEXT_WATCHDOG	0x80000000	Clearing this bit disables the watchdog timer event
XREG_TSR_WDT_INTERRUPT_STATUS	0x40000000	Clears the Watchdog Timer Interrupt Status bit. This bit is set after a watchdog interrupt occurs
XREG_TSR_WDT_RESET_STATUS_11	0x30000000	Clears the Watchdog Timer Reset Status bits. These bits specify the type of reset that occurred as a result of a watchdog timer event
XREG_TSR_PIT_INTERRUPT_STATUS	0x08000000	Clears the Programmable Interval Timer (PIT) Status bit. This bit is set after a PIT interrupt occurrence
XREG_TSR_FIT_INTERRUPT_STATUS	0x04000000	Clears the Fixed Interval Timer Status (FIT) bit. This bit is set after a FIT interrupt has occurred
XREG_TSR_CLEAR_ALL	0xFFFFFFFF	Clears all bits in the TSR. After a Reset, the content of the TSR is not specified. Use this Bitmask to clear all bits in the TSR

```
void XTime_PITSetInterval(unsigned long interval)
```

Loads a new value into the Programmable-Interval Timer Register. This register is a 32-bit decrementing counter clocked at the same frequency as the time-base register. Depending on the AutoReload setting the PIT is automatically reloaded with the last written value or must be reloaded manually. This function does not return a value.

**Example:**

```
XTime_PITSetInterval(0x00ffffff);
```



```
void XTime_PITEnableInterrupt(void)
```

Enables the generation of PIT interrupts. An interrupt occurs when the PIT register contains a value of 1, and is then decremented. This function does not return a value. `XExc_Init( )` must be called, the PIT interrupt handler must be registered, and exceptions must be enabled before calling this function.

**Example:**

```
XTime_PITEnableInterrupt();
```

---

```
void XTime_PITDisableInterrupt(void)
```

Disables the generation of PIT interrupts. It does not return a value.

**Example:**

```
XTime_PITDisableInterrupt();
```

---

```
void XTime_PITEnableAutoReload(void)
```

Enables the auto-reload function of the PIT Register. When auto-reload is enabled the PIT Register is automatically reloaded with the last value loaded by calling the `XTime_PITSetInterval( )` function when the PIT Register contains a value of 1 and is decremented. When auto-reload is enabled, the PIT Register never contains a value of 0. This function does not return a value.

**Example:**

```
XTime_PITEnableAutoReload();
```

---

```
void XTime_PITDisableAutoReload(void)
```

Disables the auto-reload feature of the PIT Register. When auto-reload is disabled the PIT decrements from 1 to 0. If it contains a value of 0 it stops decrementing until it is loaded with a non-zero value. This function does not return a value.

**Example:**

```
XTime_PITDisableAutoReload();
```

---

```
void XTime_PITClearInterrupt(void)
```

Clears PIT-Interrupt-Status bit in the Timer-Status Register. This bit specifies whether a PIT interrupt occurred. You must call this function in your interrupt-handler to clear the Status bit, otherwise another PIT interrupt occurs immediately after exiting the interrupt handler function. This function does not return a value. Calling this function is equivalent to calling `XTime_TSRClearStatusBits(XREG_TSR_PIT_INTERRUPT_STATUS)`.

**Example:**

```
XTime_PITClearInterrupt();
```

```
void XTime_FITEnableInterrupt(void)
```

Enable Fixed Interval Timer (FIT) interrupts.

**Example:**

```
XTime_FITEnableInterrupt();
```

---

```
void XTime_FITDisableInterrupt(void)
```

Disable Fixed Interval Timer (FIT) interrupts.

**Example:**

```
XTime_FITDisableInterrupt();
```

---

```
void XTime_FITClearInterrupt(void)
```

Clear Fixed Interval Timer (FIT) interrupt status bit. This function is equivalent to calling `XTime_TSRClearStatusBits(XREG_TSR_FIT_INTERRUPT_STATUS)`.

**Example:**

```
XTime_FITDisableInterrupt();
```

---

```
void XTime_FITSetPeriod(unsigned long Period)
```

Set the Fixed Interval Timer (FIT) *Period* value. This value can be one of the following:

- `XREG_TCR_FIT_PERIOD_11` ( $2^{21}$  clocks)
- `XREG_TCR_FIT_PERIOD_10` ( $2^{17}$  clocks)
- `XREG_TCR_FIT_PERIOD_01` ( $2^{13}$  clocks)
- `XREG_TCR_FIT_PERIOD_00` ( $2^9$  clocks)

These values are defined in `xreg405.h`

**Example:**

```
XTime_FITSetPeriod(XREG_TCR_FIT_PERIOD_11);
```

---

```
void XTime_WDTEnableInterrupt(void)
```

Enable Watchdog Timer (WDT) interrupts.

**Example:**

```
XTime_WDTEnableInterrupt();
```

---

```
void XTime_WDTDisableInterrupt(void)
```

Disable Watchdog Timer (WDT) interrupts.

**Example:**

```
XTime_WDTDisableInterrupt();
```

```
void XTime_WDTClearInterrupt(void)
```

Clear Watchdog Timer (WDT) interrupt status bit. Calling this function is equivalent to calling `XTime_TSRClearStatusBits(XREG_TSR_WDT_INTERRUPT_STATUS)`.

**Example:**

```
XTime_WDTClearInterrupt();
```

---

```
void XTime_WDTSetPeriod(unsigned long Period)
```

Set the period for a Watchdog Timer (WDT) event.

**Example:**

```
XTime_WDTSetPeriod(0x10000);
```

---

```
void XTime_WDTResetControl(unsigned long ControlVal)
```

Specify the type of reset that occurs as a result of a Watchdog Timer (WDT) event.

The control value may be one of the following:

- `XREG_WDT_RESET_CONTROL_11` (System reset)
- `XREG_WDT_RESET_CONTROL_10` (Chip reset)
- `XREG_WDT_RESET_CONTROL_01` (processor reset)
- `XREG_WDT_RESET_CONTROL_00` (no reset)

These values are defined in `xreg405.h`

**Example:**

```
XTime_WDTResetControl (XREG_WDT_RESET_CONTROL_11);
```

---

```
void XTime_WDTEnableNextWatchdog(void)
```

Enables Watchdog Timer (WDT) event.

**Example:**

```
XTime_WDTEnableNextWatchdog ();
```

---

```
void XTime_WDTClearResetStatus(void)
```

Clear Watchdog Timer (WDT) reset status bits.

**Example:**

```
XTime_WDTClearResetStatus ();
```

```
unsigned int usleep(unsigned int _useconds)
```

Delays the execution of a program by *\_\_useconds* microseconds. It always returns zero. This function requires that the processor frequency (in Hz) is defined. The default value of this variable is 400 MHz. This value can be overwritten in the Microprocessor Software Specification (MSS) file as follows:

```
BEGIN PROCESSOR
PARAMETER HW_INSTANCE = PPC405_i
PARAMETER DRIVER_NAME = cpu_ppc405
PARAMETER DRIVER_VER = 1.00.a
PARAMETER CORE_CLOCK_FREQ_HZ = 20000000
END
```

The `xparameters.h` file can be modified with the correct value also, as follows:

```
#define XPAR_CPU_PPC405_CORE_CLOCK_FREQ_HZ 20000000
```

---

```
unsigned int sleep(unsigned int _seconds)
```

Delays the execution of a program by what is specified in *\_seconds*. It always returns zero. This function requires that the processor frequency (in Hz) is defined. The default value of this variable is 400 MHz. This value can be overwritten in the Microprocessor Software Specification (MSS) file as follows:

```
BEGIN PROCESSOR
PARAMETER HW_INSTANCE = PPC405_i
PARAMETER DRIVER_NAME = cpu_ppc405
PARAMETER DRIVER_VER = 1.00.a
PARAMETER CORE_CLOCK_FREQ_HZ = 20000000
END
```

The file `xparameters.h` can also be modified with the correct value, as follows:

```
#define XPAR_CPU_PPC405_CORE_CLOCK_FREQ_HZ 20000000
```

---

```
int nanosleep(const struct timespec *rqtp, struct timespec *rmtp)
```

The `nanosleep( )` function in `sleep.c` is not implemented. It is a placeholder for linking applications against the C library, and returns zero.

## PowerPC 405 Processor Fast Simplex Link Interface Macros

Standalone includes macros to provide convenient access to accelerators connected to the PowerPC 405 processor Auxiliary Processing Unit (APU) over the FSL interfaces.

### PowerPC 405 Processor Fast Simplex Link Interface Macro Summary

The following is a linked list the macros; click on a macro name to go to the description.

<a href="#">getfsl(val, id)</a>	<a href="#">ncputfsl(val, id)</a>
<a href="#">putfsl(val, id)</a>	<a href="#">getfsl_interruptible(val, id)</a>
<a href="#">ngetfsl(val, id)</a>	<a href="#">putfsl_interruptible(val, id)</a>
<a href="#">nputfsl(val, id)</a>	<a href="#">cgetfsl_interruptible(val, id)</a>
<a href="#">cgetfsl(val, id)</a>	<a href="#">cputfsl_interruptible(val, id)</a>
<a href="#">cputfsl(val, id)</a>	<a href="#">fsl_isinvalid(invalid)</a>
<a href="#">ncgetfsl(val, id)</a>	<a href="#">fsl_iserror(error)</a>

## PowerPC 405 Processor FSL Interface Macro Descriptions

In the macros, *val* refers to a variable in your program that can be the source or sink of the FSL operation. You must include the `fsl.h` header file in your source files to make these macros available.

---

### **getfsl**(*val*, *id*)

Performs a blocking data get function on an input FSL interface; *id* is the FSL identifier in the range of 0 to 31. This macro is interruptible.

---

### **putfsl**(*val*, *id*)

Performs a blocking data put function on an output FSL interface; *id* is the FSL identifier in the range of 0 to 31. This macro is interruptible.

---

### **ngetfsl**(*val*, *id*)

Performs a non-blocking data get function on an input FSL interface; *id* is the FSL identifier in the range of 0 to 31.

---

### **nputfsl**(*val*, *id*)

Performs a non-blocking data put function on an output FSL interface; *id* is the FSL identifier in the range of 0 to 31.

---

### **cgetfsl**(*val*, *id*)

Performs a blocking control get function on an input FSL interface; *id* is the FSL identifier in the range of 0 to 31. This macro is interruptible.

---

### **cputfsl**(*val*, *id*)

Performs a blocking control put function on an output FSL interface; *id* is the FSL identifier in the range of 0 to 31. This macro is interruptible.

---

### **ncgetfsl**(*val*, *id*)

Performs a non-blocking control get function on an input FSL interface; *id* is the FSL identifier in the range of 0 to 31.

---

### **ncputfsl**(*val*, *id*)

This macro performs a non-blocking data control function on an output FSL interface; *id* is the FSL identifier in the range of 0 to 31.

---

### **getfsl\_interruptible**(*val*, *id*)

This macro is aliased to `getfsl(val, id)`.

**putfsl\_interruptible**(*val*, *id*)

This macro is aliased to `putfsl(val, id)`.

---

**cgetfsl\_interruptible**(*val*, *id*)

This macro is aliased to `cgetfsl(val, id)`.

---

**cputfsl\_interruptible**(*val*, *id*)

This macro is aliased to `cputfsl(val, id)`.

---

**fsl\_isinvalid**(*invalid*)

Checks to determine if the last FSL operation returned valid data. This macro is applicable after invoking a non-blocking FSL put or get instruction. If there was no data on the FSL channel on a get, or if the FSL channel was full on a put, then *invalid* is set to 1; otherwise, *invalid* is set to 0.

---

**fsl\_iserror**(*error*)

Checks to determine if the last FSL operation set an error flag. This macro is applicable after invoking a control FSL put or get instruction. If the control bit was set *error* is set to 1; otherwise, it is set to 0.

## PowerPC 405 Processor Pseudo-asm Macro

Standalone includes macros to provide convenient access to various registers on the PowerPC 405 processor. You must include the header file `xpseudo_asm.h` in your source code to use these APIs.

### PowerPC 405 Processor Pseudo-asm Macro Summary

The following is a linked list of the Pseudo-asm Macros; click on a macro name to go to the description.

<a href="#">mfgpr(rn)</a>	<a href="#">icbi(adr)</a>	<a href="#">lbz(adr)</a>
<a href="#">mfspr(rn)</a>	<a href="#">icbt(adr)</a>	<a href="#">lhz(adr)</a>
<a href="#">mfmsr()</a>	<a href="#">isync</a>	<a href="#">lwz(adr)</a>
<a href="#">mfdcr(rn)</a>	<a href="#">dccc(adr)</a>	<a href="#">stb(adr, val)</a>
<a href="#">mtdcr(rn, v)</a>	<a href="#">dcbi(adr)</a>	<a href="#">sth(adr, val)</a>
<a href="#">mtevpr(addr)</a>	<a href="#">dcbst(adr)</a>	<a href="#">stw(adr, val)</a>
<a href="#">mtspr(rn, v)</a>	<a href="#">dcbf(adr)</a>	<a href="#">lhbrx(adr)</a>
<a href="#">mtgpr(rn, v)</a>	<a href="#">dcread(adr)</a>	<a href="#">lwbrx(adr)</a>
<a href="#">iccci</a>	<a href="#">eieio</a>	<a href="#">sthbrx(adr, val)</a>
	<a href="#">sync</a>	<a href="#">stwbrx(adr, val)</a>

### PowerPC 405 Processor Pseudo-asm Macro Descriptions

---

**mfgpr**(*rn*)

Return value from GPR *rn*.

**mf spr** (*rn*)Return the current value of the special purpose register (SPR) *rn*.**mfmsr** ( )

Return value from MSR.

**mf dcr** (*rn*)Return value from the device control register (DCR) *rn*.**mt dcr** (*rn*, *v*)Move the value *v* to DCR *rn*.**mt evpr** (*addr*)Move the value *addr* to the exception vector prefix register (EVPR).**mt spr** (*rn*, *v*)Move the value *v* to SPR *rn*.**mt gpr** (*rn*, *v*)Move the value *v* to GPR *rn*.**iccci**

Invalidate the instruction cache congruence class (entire cache).

**icbi** (*adr*)Invalidate the instruction cache block at effective address *adr*.**icbt** (*adr*)Touch the instruction cache block at effective address *adr*.**isync**Execute the `isync` instruction.**dccci** (*adr*)Invalidate the data cache congruence class represented by effective address *adr*.**dcbi** (*adr*)Invalidate the data cache block at effective address *adr*.

**dcbst** (*adr*)

Store the data cache block at effective address *adr*.

---

**dcbf** (*adr*)

Flush the data cache block at effective address *adr*.

---

**dcread** (*adr*)

Read from data cache address *adr*.

---

**eieio**

Execute the `eieio` instruction.

---

**sync**

Execute the `sync` instruction.

---

**lbz** (*adr*)

Execute a load and return the byte value from address *adr*.

---

**lhz** (*adr*)

Execute a load and return the word half-word value from address *adr*.

---

**lwz** (*adr*)

Execute a load and return the word value from address *adr*.

---

**stb** (*adr*, *val*)

Store the byte value in *val* into address *adr*.

---

**sth** (*adr*, *val*)

Store the half-word value in *val* into address *adr*.

---

**stw** (*adr*, *val*)

Store the word value in *val* into address *adr*.

---

**lhbrx** (*adr*)

Execute a Load Halfword Byte-Reversed Indexed instruction on effective address *adr* and return the value.



**lwbrx** (*adr*)

Execute a Load Word Byte-Reversed Indexed instruction on effective address *adr* and return the value.

**sthbrx** (*adr, val*)

Execute a Store Halfword Byte-Reversed Indexed instruction on effective address *adr*, on value *val*.

**stwbrx** (*adr, val*)

Execute a Store Word Byte-Reversed Indexed instruction on effective address *adr*, on value *val*.

## PowerPC 405 Macros for APU FCM User-Defined Instructions

Macros are provided for using the user-defined instructions supported by the PowerPC 405 APU Fabric Coprocessor Module (FCM). There are a total of 16 user-defined instruction mnemonics provided: eight for instructions that modify the Condition Register (CR) and eight for the instructions that do not modify the CR. Because the meaning of the operands that these instructions take can be dynamically redefined, macros are provided for all combinations of operands. The user program must use the macros appropriately, in conjunction with higher level program flow.

**UDI<n>FCM** (*a, b, c, fmt*)

Inserts the mnemonic for user-defined fcm instruction *n* (that does not modify CR) into the user program. The user defined instruction, has *a, b, c* as operands to it in that order. The way the operands are interpreted by the compiler, is determined by the format specifier given by *fmt*. The format specifier is explained further below. *n* can range from 0 to 7. The mnemonic inserted is, **udi<n>fcm**.

**UDI<n>FCMCR** (*a, b, c, fmt*)

Inserts the mnemonic for user-defined fcm instruction (that modifies CR) *n* into the user program. The user-defined instruction has *a, b, c* as operands to it in that order. The way the operands are interpreted by the compiler, is determined by the format specifier *fmt*. [Table 6](#) lists the format specifier identifiers and descriptions. The value for <*n*> has a range of 0 to 7. The mnemonic syntax is **udi<n>fcm**. (note the period at the end).

**Table 6: Format Specifier for UDI Instructions**

Identifier	Meaning
FMT_GPR_GPR_GPR	Operands <i>a, b</i> , and <i>c</i> are general purpose registers
FMT_GPR_GPR_IMM	Operands <i>a</i> and <i>b</i> are general purpose registers. Operand <i>c</i> is an immediate value representing an immediate constant or an FCM register
FMT_GPR_IMM_IMM	Operand <i>a</i> is a general purpose register. Operands <i>b</i> and <i>c</i> are immediate values representing an immediate constant or an FCM register
FMT_IMM_GPR_GPR	Operands <i>b</i> and <i>c</i> are general purpose registers. Operand <i>a</i> is an immediate value representing an immediate constant or an FCM register.

Table 6: Format Specifier for UDI Instructions (*Cont'd*)

Identifier	Meaning
FMT_IMM_IMM_GPR	Operand <i>c</i> is a general purpose register. Operands <i>a</i> and <i>b</i> are immediate values representing an immediate constant or an FCM register.
FMT_IMM_IMM_IMM	All three operands are immediate values representing an immediate constant or an FCM register.

## PowerPC 440 Processor API

Standalone contains boot code, cache, file and memory management, configuration, exception handling, time and processor-specific include functions.

The following lists the PowerPC 440 processor API sections. To go to a function section, click the name.

- [PowerPC 440 Processor Boot Code](#)
- [PowerPC 440 Processor Cache Functions](#)
- [PowerPC 440 Processor Exception Handling](#)
- [PowerPC 440 Processor Errno Function](#)
- [PowerPC 440 Processor Memory Management](#)
- [PowerPC 440 Process Functions](#)
- [PowerPC 440 Processor-Specific Include Files](#)
- [PowerPC 440 Processor Time Functions](#)

The following subsections describe the PowerPC 440 processor functions by type.

### PowerPC 440 Processor Boot Code

The `boot.S` file contains a minimal set of code for transferring control from the processor's reset location to the start of the application. Code in the `boot.S` consists of the two sections `boot` and `boot0`.

The `boot` section contains only one instruction that is labeled with `_boot`. During the link process, this instruction is mapped to the reset vector and the `_boot` label marks the entry point of the application. The `boot` instruction is a jump to the `_boot0` label, and it is defined in the `boot0` section.

Upon reset of the 440 core, only the 4 kB program memory page, located at the end of the 32-bit effective address space (which starts at `0xFFFFF000`), is mapped into the MMU of the processor.

The `.boot0` section contains instructions that initialize the TLBs in the MMU such that the entire 4 GB address space is mapped transparently for both I and D side:

- The I-side TLB entries have address space identifier set to 0.
- The D-side TLB entries have address space identifier set to 1.

The `.boot0` section is located at address `0xFFFFF000` which is within the initially mapped region of memory.

Apart from mapping TLBs, the code in `boot0` also invalidates the I and D caches. Other core registers such as `CCR01`, `CCR1`, and `MSR` are initialized. `MSR[DS]` is set to 1 to partition data side translations to address space 1. Finally, the code in the `boot0` section calculates the 32-bit address of the `_start` label and jumps to that address.

## PowerPC 440 Processor Cache Functions

The `xcache_1.c` file and the corresponding `xcache_1.h` include file provide access to the following cache and cache-related operations.

### PowerPC 440 Processor Cache Function Summary

The following are links to the function descriptions. Click on the name to go to that function.

[void XCache\\_WriteCCR0\(unsigned int val\)](#)  
[void XCache\\_EnableDCache\(unsigned int regions\)](#)  
[void XCache\\_DisableDCache\(void\)](#)  
[void XCache\\_FlushDCacheLine\(unsigned int adr\)](#)  
[void XCache\\_InvalidateDCacheLine\(unsigned int adr\)](#)  
[void XCache\\_FlushDCacheRange\(unsigned int adr, unsigned len\)](#)  
[void XCache\\_InvalidateDCacheRange\(unsigned int adr, unsigned len\)](#)  
[void XCache\\_StoreDCacheLine\(unsigned int adr\)](#)  
[void XCache\\_EnableICache\(unsigned int regions\)](#)  
[void XCache\\_DisableICache\(void\)](#)  
[void XCache\\_InvalidateICache\(void\)](#)  
[void XCache\\_InvalidateICacheLine\(unsigned int adr\)](#)  
[void XCache\\_TouchICacheBlock\(unsigned int adr\)](#)

### PowerPC 440 Processor Cache Function Descriptions

---

**void XCache\_WriteCCR0**(unsigned int *val*)

Writes an integer value to the CCR0 register. Below is a sample code sequence. Before writing to this register, the instruction cache must be enabled to prevent a lockup of the processor core. After writing the CCR0, the instruction cache can be disabled, if not needed.

```

XCache_EnableICache(0x80000000) /* enable instruction cache for first 256
MB memory region */
XCache_WriteCCR0(0x00100000) /* Disable APU instruction broadcast */
XCache_DisableICache() /* disable instruction cache */

```

---

**void XCache\_EnableDCache**(unsigned int *regions*)

Enables the data cache for a specific memory region. Each pair of adjacent bits in the *regions* parameter represents 256 MB of memory. Setting either bit in the pair to **1** will enable caching for a particular 256 MB memory region.

For example:

- A value of 0x80000000 or 0x40000000 or 0xC0000000 enables the data cache for the first 256 MB of memory (0 - 0x07FFFFFF).
- A value of 0x1 or 0x2 or 0x3 enables the data cache for the last 256 MB of memory (0xF0000000 - 0xFFFFFFFF).

**Note:** if you are migrating software from a PowerPC 405 processor design, be aware that each bit enables 128 MB more of memory for caching.

---

**void XCache\_DisableDCache**(void)

Disables the data cache for all memory regions.

---

```
void XCache_FlushDCacheLine(unsigned int adr)
```

Flushes and invalidates the data cache line that contains the address specified by the *adr* parameter. A subsequent data access to this address results in a cache miss and a cache line refill.

---

```
void XCache_InvalidateDCacheLine(unsigned int adr)
```

Invalidates the data cache line that contains the address specified by the *adr* parameter. If the cache line is currently dirty, the modified contents are lost and are **not** written to system memory. A subsequent data access to this address results in a cache miss and a cache line refill.

---

```
void XCache_FlushDCacheRange(unsigned int adr, unsigned len)
```

Flushes and invalidates the data cache lines that are described by the address range starting from *adr* and *len* bytes long. A subsequent data access to any address in this range results in a cache miss and a cache line refill.

---

```
void XCache_InvalidateDCacheRange(unsigned int adr,  
    unsigned len)
```

Invalidates the data cache lines that are described by the address range starting from *adr* and *len* bytes long. If a cache line is currently dirty, the modified contents are lost and are *not* written to system memory. A subsequent data access to any address in this range results in a cache miss and a cache line refill.

---

```
void XCache_StoreDCacheLine(unsigned int adr)
```

Stores in memory the data cache line that contains the address specified by the *adr* parameter. A subsequent data access to this address results in a cache hit if the address was already cached; otherwise, it results in a cache miss and cache line refill.

---

```
void XCache_EnableICache(unsigned int regions)
```

Enables the instruction cache for a specific memory region. Each pair of adjacent bits in the *regions* parameter represents 256 MB of memory. Setting either bit in the pair to 1 will enable caching for a particular 256 MB memory region. For example, a value of 0x80000000 or 0x40000000 or 0xC0000000 enables the instruction cache for the first 256 MB of memory (0 - 0xFFFFFFFF). A value of 0x1 or 0x2 or 0x3 enables the instruction cache for the last 256 MB of memory (0xF0000000 - 0xFFFFFFFF).

**Note:** If you are migrating software from PowerPC 405, be aware that each bit enables 128 MB more of memory for caching.

---

```
void XCache_DisableICache(void)
```

Disables the instruction cache for all memory regions.

---

```
void XCache_InvalidateICache(void)
```

Invalidates the whole instruction cache. Subsequent instructions produce cache misses and cache line refills.

---

```
void XCache_InvalidateICacheLine(unsigned int adr)
```

Invalidates the instruction cache line that contains the address specified by the *adr* parameter. A subsequent instruction to this address produces a cache miss and a cache line refill.

---

```
void XCache_TouchICacheBlock(unsigned int adr)
```

Fetches an instruction cache block(line) into the cache, if the input address points to a cacheable instruction region.

## PowerPC 440 Processor Exception Handling

An exception handling API is provided in Standalone.

Exception handlers do not automatically reset (disable) the wait state enable bit in the MSR when returning to user code. You can force exception handlers to reset the Wait-Enable bit to zero on return from all exceptions by compiling Standalone with the preprocessor symbol `PPC440_RESET_WE_ON_RFI` defined. You can add this to the compiler flags associated with the libraries. This pre-processor define turns the behavior on.

The exception handling API consists of a set of the files `xvectors.S`, `xexception_l.c`, and the corresponding header file `xexception_l.h`.

For additional information on interrupt handling, refer to the “Interrupt Management” appendix in the *Embedded System Tools Reference Manual (UG111)*, available in the `/doc` directory of your EDK installation.

### PowerPC 440 Processor Exception Handling Function Summary

The following table provides a summary of the PowerPC 440 exception handling functions. Click on a function name to go to the description.

```
void XExc_Init(void)
void XExc_RegisterHandler(Xuint8 ExceptionId, XExceptionHandler Handler, void *DataPtr)
void XExc_RemoveHandler(Xuint8 ExceptionId)
void XExc_mEnableExceptions (EnableMask)
void XExc_mDisableExceptions (DisableMask)
```

### PowerPC 440 Processor Exception Handling Function Descriptions

---

```
void XExc_Init(void)
```

Sets up the interrupt vector table and registers a “do nothing” function for each exception. This function has no parameters and does not return a value.

This function must be called before registering any exception handlers or enabling any interrupts. When using the exception handler API, this function should be called at the beginning of your `main( )` routine.

```
void XExc_RegisterHandler(Xuint8 ExceptionId,
                          XExceptionHandler Handler, void *DataPtr)
```

Registers an exception handler for a specific exception; does not return a value. Refer to [Table 7, page 38](#) for a list of exception types and their values. The parameters are as follows:

- *ExceptionId* is of parameter type Xuint8, and is the exception to which this handler should be registered. The type and the values are defined in the `xexception_1.h` header file.
- *Handler* is an XExceptionHandler parameter which is the pointer to the exception handling function
- *DataPtr* is of parameter type `void *` and is the user value to be passed when the handling function is called

**Table 7: Registered Exception Types and Values**

Exception Type	Value
XEXC_ID_CRITICAL_INT	0
XEXC_ID_MACHINE_CHECK	1
XEXC_ID_DATA_STORAGE_INT	2
XEXC_ID_INSTRUCTION_STORAGE_INT	3
XEXC_ID_NON_CRITICAL_INT	4
XEXC_ID_ALIGNMENT_INT	5
XEXC_ID_PROGRAM_INT	6
XEXC_ID_FPU_UNAVAILABLE_INT	7
XEXC_ID_SYSTEM_CALL	8
XEXC_ID_APU_AVAILABLE	9
XEXC_ID_DEC_INT	10
XEXC_ID_FIT_INT	11
XEXC_ID_WATCHDOG_TIMER_INT	12
XEXC_ID_DATA_TLB_MISS_INT	13
XEXC_ID_INSTRUCTION_TLB_MISS_INT	14
XEXC_ID_DEBUG_INT	15

The function provided as the *Handler* parameter must have the following function prototype:

```
typedef void (*XExceptionHandler)(void * DataPtr);
```

This prototype is declared in the `xexception_1.h` header file.

When this exception handler function is called, the parameter *DataPtr* contains the same value as you provided when you registered the handler.

---

```
void XExc_RemoveHandler(Xuint8 ExceptionId)
```

De-register a handler function for a given exception. For possible values of parameter *ExceptionId*, refer to [Table 7, page 38](#).

---

```
void XExc_mEnableExceptions (EnableMask)
```

Enable exceptions. This macro must be called after initializing the vector table with the `XExc_Init` function and registering exception handlers with the `XExc_RegisterHandler` function.

The parameter `EnableMask` is a bitmask for exceptions to be enabled. The `EnableMask` parameter can have the following values: `XEXC_CRITICAL`, `XEXC_NON_CRITICAL`, `XEXC_DEBUG`, `XEXC_MACHINE_CHECK`, or `XEXC_ALL`.

---

```
void XExc_mDisableExceptions (DisableMask)
```

Disable exceptions. The parameter `DisableMask` is a bitmask for exceptions to be disabled. The `DisableMask` parameter can have the following values: `XEXC_CRITICAL`, `XEXC_NON_CRITICAL`, `XEXC_DEBUG`, `XEXC_MACHINE_CHECK`, or `XEXC_ALL`.

---

## PowerPC 440 Processor File Support

File support is limited to the `stdin` and `stdout` streams; consequently, the following functions are not necessary:

- `open( )` (in `open.c`)
- `close( )` (in `close.c`)
- `fstat( )` (in `fstat.c`)
- `unlink( )` (in `unlink.c`)
- `lseek( )` (in `lseek.c`)

These files are included for completeness and because they are referenced by the C library.

## PowerPC 440 Processor File Support Function Descriptions

---

```
int read(int fd, char *buf, int nbytes)
```

The `read( )` function in `read.c` reads `nbytes` bytes from the standard input by calling `inbyte( )`. It blocks until all characters are available, or the end of line character is read. The `read( )` function returns the number of characters read. The `fd` parameter is ignored.

---

```
int write(int fd, char *buf, int nbytes)
```

Writes `nbytes` bytes to the standard output by calling `outbyte( )`. It blocks until all characters have been written. The `write( )` function returns the number of characters written. The `fd` parameter is ignored.

---

```
int isatty(int fd)
```

Reports if a file is connected to a `tty`. This function always returns 1, Because only the `stdin` and `stdout` streams are supported.

---

```
int fcntl (int fd, int cmd, -long arg)
```

A dummy implementation of `fcntl`, which always returns 0. `fcntl` is intended to manipulate file descriptors according to the command specified by `cmd`. Because Standalone does not provide a file system, this function is not used.

---

---

## PowerPC 440 Processor Errno Function

---

```
int errno( )
```

Returns the global value of `errno` as set by the last C library call.

---

## PowerPC 440 Processor Memory Management

---

```
char *sbrk(int nbytes)
```

Allocates `nbytes` of heap and returns a pointer to that piece of memory. This function is called from the memory allocation functions of the C library.

---

## PowerPC 440 Process Functions

The functions `getpid( )` in `getpid.c` and `kill( )` in `kill.c` are included for completeness and because they are referenced by the C library.

---

## PowerPC 440 Processor-Specific Include Files

The `xreg440.h` include file contains the register numbers and the register bits for the PowerPC 440 processor.

The `xpseudo-asm.h` include file contains the definitions for the most often used inline assembler instructions, available as macros. These can be very useful for tasks such as setting or getting special purpose registers, synchronization, or cache manipulation.

These inline assembler instructions can be used from drivers and user applications written in C.

---

## PowerPC 440 Processor Time Functions

The `xtime_1.c` file and corresponding `xtime_1.h` include file provide access to the 64-bit time base counter as well as the decremter, FIT and WDT timers inside the PowerPC 440 core. The 64-bit time base counter increases by one at every processor cycle.

The `sleep.c` file and corresponding `sleep.h` include file implement sleep functions. Sleep functions are implemented as busy loops.



## PowerPC 440 Processor Time Function Summary

The PowerPC 440 processor time functions are summarized in the following table. Click on the function name to go to the description.

```
typedef unsigned long long XTime
void XTime_SetTime(XTime xtime)
void XTime_GetTime(XTime *xtime)
void XTime_TSRClearStatusBits(unsigned long Bitmask)
void XTime_DECSetInterval(unsigned long interval);
void XTime_DECEnableInterrupt(void);
void XTime_DECDisableInterrupt(void)
void XTime_DECEnableAutoReload(void)
void XTime_DECDisableAutoReload(void)
void XTime_DECClearInterrupt(void)
void XTime_FITEnableInterrupt(void)
void XTime_FITDisableInterrupt(void)
void XTime_FITClearInterrupt(void)
void XTime_FITSetPeriod(unsigned long Period)
void XTime_WDTEnableInterrupt(void)
void XTime_WDTDisableInterrupt(void)
void XTime_WDTClearInterrupt(void)
void XTime_WDTSetPeriod(unsigned long Period)
void XTime_WDTResetControl(unsigned long ControlVal)
void XTime_WDTEnableNextWatchdog(void)
void XTime_WDTClearResetStatus(void)
unsigned int usleep(unsigned int _useconds)
unsigned int sleep(unsigned int _seconds)
int nanosleep(const struct timespec *rqtp, struct timespec *rmtp)
```

## PowerPC 440 Processor Time Function Descriptions

---

```
typedef unsigned long long XTime
```

The **xtime** type in `xtime_1.h` represents the Time Base register. This struct consists of the Time Base Low (TBL) and Time Base High (TBH) registers, each of which is a 32-bit wide register.

The definition of **XTime** is as follows:

```
typedef unsigned long long XTime;
```

---

```
void XTime_SetTime(XTime xtime)
```

Sets the time base register to the value in *xtime*.

---

```
void XTime_GetTime(XTime *xtime)
```

Writes the current value of the time base register to variable *xtime*.

```
void XTime_TSRClearStatusBits(unsigned long Bitmask)
```

Clears bits in the Timer Status Register (TSR). The parameter *Bitmask* designates the bits to be cleared. A value of 1 in any position of the Bitmask parameter clears the corresponding bit in the TSR. This function does not return a value.

**Example:**

```
XTime_TSRClearStatusBits(XREG_TSR_CLEAR_ALL);
```

Table 8 contains the values for the bitmask parameters that are specified in the `xreg440.h` header file.

**Table 8: Bitmask Parameter Values**

Name	Value	Description
XREG_TSR_WDT_ENABLE_NEXT_WATCHDOG	0x80000000	Clearing this bit disables the watchdog timer event.
XREG_TSR_WDT_INTERRUPT_STATUS	0x40000000	Clears the Watchdog Timer Interrupt Status bit. This bit is set after a watchdog interrupt occurs.
XREG_TSR_WDT_RESET_STATUS_00	0x00000000	Clears the Watchdog Timer Reset Status bits. The bit combination specifies the type of reset that occurred as a result of a watchdog timer event.
XREG_TSR_WDT_RESET_STATUS_01	0x10000000	Clears the Watchdog Timer Reset Status bits. The bit combination specifies the type of reset that occurred as a result of a watchdog timer event.
XREG_TSR_WDT_RESET_STATUS_10	0x20000000	Clears the Watchdog Timer Reset Status bits. The bit combination specifies the type of reset that occurred as a result of a watchdog timer event.
XREG_TSR_WDT_RESET_STATUS_11	0x30000000	Clears the Watchdog Timer Reset Status bits. The bit combination specifies the type of reset that occurred as a result of a watchdog timer event.
XREG_TSR_DEC_INTERRUPT_STATUS	0x08000000	Clears the Decrementer (DEC) Status bit. This bit is set after a decrementer interrupt occurrence.
XREG_TSR_FIT_INTERRUPT_STATUS	0x04000000	Clears the Fixed Interval Timer Status (FIT) bit. This bit is set after a FIT interrupt has occurred.
XREG_TSR_CLEAR_ALL	0xFFFFFFFF	Clears all bits in the TSR. After a Reset, the content of the TSR is not specified. Use this bitmask to clear all bits in the TSR.

```
void XTime_DECSetInterval(unsigned long interval);
```

Loads a new value into the Decrementer Register. This register is a 32-bit decrementing counter clocked at the same frequency as the time-base register. Depending on the AutoReload setting the Decrementer is automatically reloaded with the last written value or must be reloaded manually. This function does not return a value.

**Example:**

```
XTime_DECSetInterval(0x00ffffff);
```

---

```
void XTime_DECEnableInterrupt(void);
```

Enables the generation of Decrementer interrupts. An interrupt occurs when the DEC register contains a value of 1, and is then decremented. This function does not return a value.

XExc\_Init( ) must be called, the Decrementer interrupt handler must be registered, and exceptions must be enabled before calling this function.

**Example:**

```
XTime_DECEnableInterrupt();
```

---

```
void XTime_DECDisableInterrupt(void)
```

Disables the generation of Decrementer interrupts. It does not return a value.

**Example:**

```
XTime_DECDisableInterrupt();
```

---

```
void XTime_DECEnableAutoReload(void)
```

Enables the auto-reload function of the Decrementer Register. When auto-reload is enabled the Decrementer Register is automatically reloaded with the last value loaded by calling the XTime\_DECSetInterval( ) function when the Decrementer Register contains a value of 1 and is decremented. When auto-reload is enabled, the Decrementer Register never contains a value of 0. This function does not return a value.

**Example:**

```
XTime_DECEnableAutoReload();
```

---

```
void XTime_DECDisableAutoReload(void)
```

Disables the auto-reload feature of the Decrementer Register. When auto-reload is disabled the Decrementer decrements from 1 to 0. If it contains a value of 0 it stops decrementing until it is loaded with a non-zero value. This function does not return a value.

**Example:**

```
XTime_DECDisableAutoReload();
```

```
void XTime_DECClearInterrupt(void)
```

Clears Decrementer Interrupt-Status bit in the Timer-Status Register. This bit specifies whether a Decrementer interrupt occurred. You must call this function in your interrupt-handler to clear the Status bit, otherwise another Decrementer interrupt occurs immediately after exiting the interrupt handler function.

This function does not return a value. Calling this function is equivalent to calling `XTime_TSRClearStatusBits(XREG_TSR_DEC_INTERRUPT_STATUS)`.

**Example:**

```
XTime_DECClearInterrupt();
```

---

```
void XTime_FITEnableInterrupt(void)
```

Enable Fixed Interval Timer (FIT) interrupts.

**Example:**

```
XTime_FITEnableInterrupt();
```

---

```
void XTime_FITDisableInterrupt(void)
```

Disable Fixed Interval Timer (FIT) interrupts.

**Example:**

```
XTime_FITDisableInterrupt();
```

---

```
void XTime_FITClearInterrupt(void)
```

Clear Fixed Interval Timer (FIT) interrupt status bit. This function is equivalent to calling `XTime_TSRClearStatusBits(XREG_TSR_FIT_INTERRUPT_STATUS)`.

**Example:**

```
XTime_FITDisableInterrupt();
```

---

```
void XTime_FITSetPeriod(unsigned long Period)
```

Set the Fixed Interval Timer (FIT) *Period* value. This value can be one of the following:

- XREG\_TCR\_FIT\_PERIOD\_11 (2<sup>21</sup> clocks)
- XREG\_TCR\_FIT\_PERIOD\_10 (2<sup>17</sup> clocks)
- XREG\_TCR\_FIT\_PERIOD\_01 (2<sup>13</sup> clocks)
- XREG\_TCR\_FIT\_PERIOD\_00 (2<sup>9</sup> clocks)

These values are defined in `xreg440.h`

**Example:**

```
XTime_FITSetPeriod(XREG_TCR_FIT_PERIOD_11);
```

```
void XTime_WDTEnableInterrupt(void)
```

Enable Watchdog Timer (WDT) interrupts.

**Example:**

```
XTime_WDTEnableInterrupt();
```

---

```
void XTime_WDTDisableInterrupt(void)
```

Disable Watchdog Timer (WDT) interrupts.

**Example:**

```
XTime_WDTDisableInterrupt();
```

---

```
void XTime_WDTClearInterrupt(void)
```

Clear Watchdog Timer (WDT) interrupt status bit. Calling this function is equivalent to calling `XTime_TSRClearStatusBits(XREG_TSR_WDT_INTERRUPT_STATUS)`.

**Example:**

```
XTime_WDTClearInterrupt();
```

---

```
void XTime_WDTSetPeriod(unsigned long Period)
```

Set the period for a Watchdog Timer (WDT) event.

**Example:**

```
XTime_WDTSetPeriod(0x10000);
```

---

```
void XTime_WDTResetControl(unsigned long ControlVal)
```

Specify the type of reset that occurs as a result of a Watchdog Timer (WDT) event.

The control value may be one of the following:

- `XREG_WDT_RESET_CONTROL_11` (System reset)
- `XREG_WDT_RESET_CONTROL_10` (Chip reset)
- `XREG_WDT_RESET_CONTROL_01` (processor reset)
- `XREG_WDT_RESET_CONTROL_00` (no reset)

These values are defined in `xreg440.h`.

**Example:**

```
XTime_WDTResetControl (XREG_WDT_RESET_CONTROL_11);
```

---

```
void XTime_WDTEnableNextWatchdog(void)
```

Enables Watchdog Timer (WDT) event.

**Example:**

```
XTime_WDTEnableNextWatchdog ();
```

```
void XTime_WDTClearResetStatus(void)
```

Clear Watchdog Timer (WDT) reset status bits.

**Example:**

```
XTime_WDTClearResetStatus ();
```

```
unsigned int usleep(unsigned int _useconds)
```

Delays the execution of a program by *\_\_useconds* microseconds. It always returns zero. This function requires that the processor frequency (in Hz) is defined. The default value of this variable is 400 MHz. This value can be overwritten in the Microprocessor Software Specification (MSS) file as follows:

```
BEGIN PROCESSOR
PARAMETER HW_INSTANCE = PPC440_i
PARAMETER DRIVER_NAME = cpu_ppc440
PARAMETER DRIVER_VER = 1.00.a
PARAMETER CORE_CLOCK_FREQ_HZ = 20000000
END
```

The `xparameters.h` file can be modified with the correct value also, as follows:

```
#define XPAR_CPU_PPC440_CORE_CLOCK_FREQ_HZ 20000000
```

```
unsigned int sleep(unsigned int _seconds)
```

Delays the execution of a program by what is specified in *\_seconds*. It always returns zero. This function requires that the processor frequency (in Hz) is defined. The default value of this variable is 400 MHz.

This value can be overwritten in the Microprocessor Software Specification (MSS) file as follows:

```
BEGIN PROCESSOR
PARAMETER HW_INSTANCE = PPC440_i
PARAMETER DRIVER_NAME = cpu_ppc440
PARAMETER DRIVER_VER = 1.00.a
PARAMETER CORE_CLOCK_FREQ_HZ = 20000000
END
```

The file `xparameters.h` can also be modified with the correct value, as follows:

```
#define XPAR_CPU_PPC440_CORE_CLOCK_FREQ_HZ 20000000
```

```
int nanosleep(const struct timespec *rqtp, struct timespec *rmtp)
```

The `nanosleep( )` function in `sleep.c` is not implemented. It is a placeholder for linking applications against the C library, and returns zero.

## Cortex A9 Processor API

Standalone BSP contains boot code, cache, exception handling, file and memory management, configuration, time and processor-specific include functions. It supports gcc compilers.

The following lists the Cortex A9 Processor API sections. You can click on a link to go directly to the function section.

- [Cortex A9 Processor Boot Code](#)
- [Cortex A9 Processor Cache Functions](#)
- [Cortex A9 Processor Exception Handling](#)
- [Cortex A9 Processor File Support](#)
- [Cortex A9 gcc Errno Function](#)
- [Cortex A9 gcc Memory Management](#)
- [Cortex A9 gcc Process Functions](#)
- [Cortex A9 Processor-Specific Include Files](#)
- [Cortex A9 Time Functions](#)

The following subsections describe the functions by type.

### Cortex A9 Processor Boot Code

The boot.S file contains a minimal set of code for transferring control from the processor's reset location to the start of the application. It performs the following tasks.

- Invalidate L1 caches, TLBs, Branch Predictor Array, etc.
- Invalidate L2 caches and initialize L2 Cache Controller
- Enable caches and MMU
- Load MMU translation table base address into the TTB registers
- Enable NEON coprocessor

The boot code also starts the Cycle Counter and initializes the Static Memory Controller.

### Cortex A9 Processor Cache Functions

The xil\_cache.c file and the corresponding xil\_cache.h header file provide access to the following cache and cache-related operations.

#### Cache Function Summary

The following are links to the function descriptions. Click on the name to go to that function.

[void Xil\\_DCacheEnable\(void\)](#)

[void Xil\\_DCacheInvalidate\(void\)](#)

[void Xil\\_DCacheInvalidateLine\(unsigned int adr\)](#)

[void Xil\\_DCacheInvalidateRange\(unsigned int adr, unsigned len\)](#)

[void Xil\\_DCacheFlush\(void\)](#)

[void Xil\\_DCacheFlushLine\(unsigned int adr\)](#)

[void Xil\\_DCacheFlushRange\(unsigned int adr, unsigned len\)](#)

[void Xil\\_DCacheStoreLine\(unsigned int adr\)](#)

[void Xil\\_ICacheEnable\(void\)](#)

[void Xil\\_ICacheDisable\(void\)](#)

```
void Xil_ICacheInvalidate(void)
void Xil_ICacheInvalidateLine(unsigned int adr)
void Xil_ICacheInvalidateRange(unsigned int adr, unsigned len)
void Xil_L1DCacheEnable(void)
void Xil_L1DCacheDisable(void)
void Xil_L1DCacheInvalidate(void)
void Xil_L1DCacheInvalidateLine(unsigned int adr)
void Xil_L2CacheInvalidateRange(unsigned int adr, unsigned len)
void Xil_L1DCacheFlush(void)
void Xil_L1DCacheFlushLine(unsigned int adr)
void Xil_L1DCacheFlushRange(unsigned int adr, unsigned len)
void Xil_L1DCacheStoreLine(unsigned int adr)
void Xil_L1ICacheEnable(void)
void Xil_ICacheDisable(void)
void Xil_ICacheInvalidate(void)
void Xil_L1ICacheInvalidateLine(unsigned int adr)
void Xil_L1ICacheInvalidateRange(unsigned int adr, unsigned len)
void Xil_L2CacheEnable(void)
void Xil_L2CacheDisable(void)
void Xil_L2CacheInvalidate(void)
void Xil_L2CacheInvalidateLine(unsigned int adr)
void Xil_L2CacheInvalidateRange(unsigned int adr, unsigned len)
void Xil_L2CacheFlush(void)
void Xil_L2CacheFlushLine(unsigned int adr)
void Xil_L2CacheFlushRange(unsigned int adr, unsigned len)
void Xil_L2CacheStoreLine(unsigned int adr)
```

### Cache Function Descriptions

---

```
void Xil_DCACHEEnable(void)
```

Enable the data caches.

---

```
void Xil_DCACHEInvalidate(void)
```

Invalidate the entire data cache.



---

```
void Xil_DCacheInvalidateLine(unsigned int adr)
```

Invalidate a data cache line. If the byte specified by *adr* is cached by the data cache, the cacheline containing that byte is invalidated. If the cacheline is modified (dirty), the modified contents are lost and are not written to system memory before the line is invalidated. A subsequent data access to this address results in a cache miss and a cache line refill.

---

```
void Xil_DCacheInvalidateRange(unsigned int adr, unsigned  
    len)
```

Invalidates the data cache lines that are described by the address range starting from *adr* and *len* bytes long. A subsequent data access to any address in this range results in a cache miss and a cache line refill.

---

```
void Xil_DCacheFlush(void)
```

Flush the entire Data cache.

---

```
void Xil_DCacheFlushLine(unsigned int adr)
```

Flush a Data cache line. If the byte specified by the address (*adr*) is cached by the data cache, the cacheline containing that byte is invalidated. If the cacheline is modified (dirty), the entire contents of the cacheline are written to system memory before the line is invalidated. . A subsequent data access to this address results in a cache miss and a cache line refill.

---

```
void Xil_DCacheFlushRange(unsigned int adr, unsigned len)
```

Flushes the data cache lines that are described by the address range starting from *adr* and *len* bytes long. A subsequent data access to any address in this range results in a cache miss and a cache line refill.

---

```
void Xil_DCacheStoreLine(unsigned int adr)
```

Store a Data cache line. If the byte specified by the *adr* is cached by the data cache and the cacheline is modified (dirty), the entire contents of the cacheline are written to system memory. After the store completes, the cacheline is marked as unmodified (not dirty).

---

```
void Xil_ICacheEnable(void)
```

Enable the instruction caches.

---

```
void Xil_ICacheDisable(void)
```

Disable the instruction caches.

---

```
void Xil_ICacheInvalidate(void)
```

Invalidate the entire instruction cache.

---

---

```
void Xil_ICacheInvalidateLine(unsigned int adr)
```

Invalidate an instruction cache line. If the instruction specified by the parameter *adr* is cached by the instruction cache, the cacheline containing that instruction is invalidated.

---

```
void Xil_ICacheInvalidateRange(unsigned int adr, unsigned  
    len)
```

Invalidate the instruction cache for the given address range. If the bytes specified by the *adr* are cached by the data cache, the cacheline containing that byte is invalidated. If the cacheline is modified (dirty), the modified contents are lost and are not written to system memory before the line is invalidated.

---

```
void Xil_L1DCacheEnable(void)
```

Enable the level 1 data cache.

---

```
void Xil_L1DCacheDisable(void)
```

Disable the level 1 data cache.

---

```
void Xil_L1DCacheInvalidate(void)
```

Invalidate the level 1 data cache.

---

```
void Xil_L1DCacheInvalidateLine(unsigned int adr)
```

Invalidate a level 1 data cache line. If the byte specified by the *adr* is cached by the data cache, the cacheline containing that byte is invalidated. If the cacheline is modified (dirty), the modified contents are lost and are not written to system memory before the line is invalidated.

---

```
void Xil_L1DCacheInvalidateRange(unsigned int adr,  
    unsigned len)
```

Invalidate the level 1 data cache for the given address range. If the bytes specified by the *adr* are cached by the data cache, the cacheline containing that byte is invalidated. If the cacheline is modified (dirty), the modified contents are lost and are not written to system memory before the line is invalidated.

---

```
void Xil_L1DCacheFlush(void)
```

Flush the level 1 data cache.

---

```
void Xil_L1DCacheFlushLine(unsigned int adr)
```

Flush a level 1 data cache line. If the byte specified by the *adr* is cached by the data cache, the cacheline containing that byte is invalidated. If the cacheline is modified (dirty), the entire contents of the cacheline are written to system memory before the line is invalidated.

---

```
void Xil_L1DCacheFlushRange(unsigned int adr, unsigned  
    len)
```

Flush the level 1 data cache for the given address range. If the bytes specified by the *adr* are cached by the data cache, the cacheline containing that byte is invalidated. If the cacheline is modified (dirty), the written to system memory first before the before the line is invalidated.

---

```
void Xil_L1DCacheStoreLine(unsigned int adr)
```

Store a level 1 data cache line. If the byte specified by the *adr* is cached by the data cache and the cacheline is modified (dirty), the entire contents of the cacheline are written to system memory. After the store completes, the cacheline is marked as unmodified (not dirty).

---

```
void Xil_L1ICacheEnable(void)
```

Enable the level 1 instruction cache.

---

```
void Xil_L1ICacheDisable(void)
```

Disable level 1 the instruction cache.

---

```
void Xil_L1ICacheInvalidate(void)
```

Invalidate the entire level 1 instruction cache.

---

```
void Xil_L1ICacheInvalidateLine(unsigned int adr)
```

Invalidate a level 1 instruction cache line. If the instruction specified by the parameter *adr* is cached by the instruction cache, the cacheline containing that instruction is invalidated.

---

```
void Xil_L1ICacheInvalidateRange(unsigned int adr,  
    unsigned len)
```

Invalidate the level 1 instruction cache for the given address range. If the bytes specified by the *adr* are cached by the data cache, the cacheline containing that byte is invalidated. If the cacheline is modified (dirty), the modified contents are lost and are not written to system memory before the line is invalidated.

---

```
void Xil_L2CacheEnable(void)
```

Enable the L2 cache.

---

```
void Xil_L2CacheDisable(void)
```

Disable the L2 cache.

---

```
void Xil_L2CacheInvalidate(void)
```

Invalidate the L2 cache. If the byte specified by the *adr* is cached by the data cache, the cacheline containing that byte is invalidated. If the cacheline is modified (dirty), the modified contents are lost and are not written to system memory before the line is invalidated.

---

```
void Xil_L2CacheInvalidateLine(unsigned int adr)
```

Invalidate a level 2 cache line. If the byte specified by the *adr* is cached by the Data cache, the cacheline containing that byte is invalidated. If the cacheline is modified (dirty), the modified contents are lost and are not written to system memory before the line is invalidated.

---

```
void Xil_L2CacheInvalidateRange(unsigned int adr, unsigned  
    len)
```

Invalidate the level 2 cache for the given address range. If the bytes specified by the *adr* are cached by the data cache, the cacheline containing that byte is invalidated. If the cacheline is modified (dirty), the modified contents are lost and are not written to system memory before the line is invalidated.

---

```
void Xil_L2CacheFlush(void)
```

Flush the L2 cache. If the byte specified by the *adr* is cached by the data cache, the cacheline containing that byte is invalidated. If the cacheline is modified (dirty), the entire contents of the cacheline are written to system memory before the line is invalidated.

---

```
void Xil_L2CacheFlushLine(unsigned int adr)
```

Flush a level 1 cache line. If the byte specified by the *adr* is cached by the data cache, the cacheline containing that byte is invalidated. If the cacheline is modified (dirty), the entire contents of the cacheline are written to system memory before the line is invalidated.

---

```
void Xil_L2CacheFlushRange(unsigned int adr, unsigned len)
```

Flush the level 2 cache for the given address range. If the bytes specified by the *adr* are cached by the data cache, the cacheline containing that byte is invalidated. If the cacheline is modified (dirty), the written to system memory first before the before the line is invalidated.

---

```
void Xil_L2CacheStoreLine(unsigned int adr)
```

Store a level 2 cache line. If the byte specified by the *adr* is cached by the data cache and the cacheline is modified (dirty), the entire contents of the cacheline are written to system memory. After the store completes, the cacheline is marked as unmodified (not dirty).

---

```
void XL2cc_EventCtrInit(int Event0, int Event1)
```

This function initializes the event counters in L2 Cache controller with a set of event codes specified by the user. Use the event codes defined by `XL2CC_*` in `xl2cc_counter.h` to specify the events *Event0* and *Event1*.

---

```
void XL2cc_EventCtrStart(void)
```

This function starts the event counters in L2 Cache controller.

---

```
void XL2cc_EventCtrStop(u32 *EveCtr0, u32 *EveCtr1)
```

This function disables the event counters in L2 Cache controller, saves the counter values to address pointed to by *EveCtr0* and *EveCtr1* and resets the counters.

---

## Cortex A9 Processor MMU Handling

The standalone BSP MMU handling API is implemented in file `xil_mmu.c` and the corresponding header file `xil_mmu.h`.

### MMU Handling Function Summary

The following function describes the available MMU handling API.

---

```
void Xil_SetTlbAttributes(u32 addr, u32 attrib)
```

This function changes the MMU attribute of the 1 MB address range in which the passed memory address "addr" falls.

The new MMU attribute is passed as an argument "attrib" to this API.

This API can be used to change attributes such as cacheability and shareability of a specified memory region.

## Cortex A9 Processor Exception Handling

The Standalone BSP provides an exception handling API. For details about the exceptions and interrupts on ARM Cortex-A9 processor, refer to "Exceptions" under the chapter "The System Level Programmers' Model" in the ARM Architecture Reference Manual ARMv7-A and ARMv-7R edition.

The exception handling API is implemented in a set of the files - `asm_vectors.S`, `vectors.c`, `xil_exception.c`, and the corresponding header files `vectors.h` and `xil_exception.h`.

### Exception Handling Function Summary

The following are links to the function descriptions. Click on the name to go to that function.

[void Xil\\_ExceptionInit\(void\)](#)

[void Xil\\_ExceptionRegisterHandler \(Xuint8 ExceptionId, XExceptionHandler Handler, void \\*DataPtr\)](#)

[void Xil\\_ExceptionRemoveHandler \(u32 Id\)](#)

[void Xil\\_ExceptionEnableMask\(Mask\)](#)

[void Xil\\_ExceptionEnable\(void\)](#)

[void Xil\\_ExceptionDisableMask\(Mask\)](#)

[void Xil\\_ExceptionDisable\(void\)](#)

### Exception Handling Function Descriptions

---

```
void Xil_ExceptionInit(void)
```

Sets up the interrupt vector table and registers a "do nothing" function for each exception. This function has no parameters and does not return a value. This function must be called before registering any exception handlers or enabling any interrupts.

---

```
void Xil_ExceptionRegisterHandler (Xuint8 ExceptionId,  
    XExceptionHandler Handler, void *DataPtr)
```

Registers an exception handler for a specific exception; does not return a value. Refer to Table 1, for a list of exception types and their values.

The parameters are:

- **ExceptionId** is of parameter type u8, and is the exception to which this handler should be registered. The type and the values are defined in the xil\_exception.h header file.
- **Handler** is an Xil\_ExceptionHandler parameter that is the pointer to the exception handling function.

The function provided as the Handler parameter must have the following function prototype:

```
typedef void (*Xil_ExceptionHandler)(void * DataPtr);
```

This prototype is declared in the xil\_exception.h header file.

- **DataPtr** is of parameter type void \* and is the user value to be passed when the Handler is called.

When this Handler function is called, the parameter DataPtr contains the same value provided, when the Handler was registered.

Table 9: Registered Exception Types and Values

Exception Type	Value
XIL_EXCEPTION_ID_RESET	0
XIL_EXCEPTION_ID_UNDEFINED_INT	1
XIL_EXCEPTION_ID_SWI_INT	2
XIL_EXCEPTION_ID_PREFETCH_ABORT_INT	3
XIL_EXCEPTION_ID_DATA_ABORT_INT	4
XIL_EXCEPTION_ID_IRQ_INT	5
XIL_EXCEPTION_ID_FIQ_INT	6

---

```
void Xil_ExceptionRemoveHandler (Xuint8 ExceptionId)
```

De-register a handler function for a given exception. For possible values of parameter ExceptionId, refer to Table 1.

---

```
void Xil_ExceptionEnableMask (Mask)
```

Enable exceptions specified by Mask. The parameter Mask is a bitmask for exceptions to be enabled. The Mask parameter can have the values XIL\_EXCEPTION\_IRQ, XIL\_EXCEPTION\_FIQ, or XIL\_EXCEPTION\_ALL.

---

```
void Xil_ExceptionEnable (void)
```

Enable the IRQ exception.

These macros must be called after initializing the vector table with function Xil\_exceptionInit and registering exception handlers with function Xil\_ExceptionRegisterHandler.

---

```
void Xil_ExceptionDisableMask (Mask)
```

Disable exceptions specified by Mask. The parameter Mask is a bitmask for exceptions to be disabled. The Mask parameter can have the values XIL\_EXCEPTION\_IRQ, XIL\_EXCEPTION\_FIQ, or XIL\_EXCEPTION\_ALL.

---

---

```
void Xil_ExceptionDisable(void)
```

Disable the IRQ exception.

## Cortex A9 Processor File Support

The following links take you directly to the gcc file support function. Click the link to go to the description:

```
int read(int fd, char *buf, int nbytes)
int write(int fd, char *buf, int nbytes)
int isatty(int fd)
int fcntl(int fd, int cmd, long arg);
```

File support is limited to the stdin and stdout streams; consequently, the following functions are not necessary:

### gcc

- `open( )` (in gcc/open.c)
- `close( )` (in gcc/close.c)
- `fstat( )` (in gcc/fstat.c)
- `unlink( )` (in gcc/unlink.c)
- `lseek( )` (in gcc/lseek.c)

These files are included for completeness and because they are referenced by the C library.

## Cortex A9 gcc File Support Function Descriptions

---

```
int read(int fd, char *buf, int nbytes)
```

The `read( )` function in gcc/read.c reads nbytes bytes from the standard input by calling `inbyte( )`. It blocks until all characters are available, or the end of line character is read. The `read( )` function returns the number of characters read. The `fd` parameter is ignored.

---

```
int write(int fd, char *buf, int nbytes)
```

Writes nbytes bytes to the standard output by calling `outbyte( )`. It blocks until all characters have been written. The `write( )` function returns the number of characters written. The `fd` parameter is ignored.

---

```
int isatty(int fd)
```

Reports if a file is connected to a tty. This function always returns 1, because only the stdin and stdout streams are supported.

---

```
int fcntl (int fd, int cmd, long arg)
```

A dummy implementation of `fcntl`, which always returns 0. `fcntl` is intended to manipulate file descriptors according to the command specified by `cmd`. Because Standalone does not provide a file system, this function is not used.

## Cortex A9 gcc Errno Function

---

```
int errno( )
```

Returns the global value of errno as set by the last C library call.

## Cortex A9 gcc Memory Management

---

```
char *sbrk(int nbytes)
```

Allocates nbytes of heap and returns a pointer to that piece of memory. This function is called from the memory allocation functions of the C library.

## Cortex A9 gcc Process Functions

The functions getpid() in getpid.c and kill() in kill.c are included for completeness and because they are referenced by the C library.

## Cortex A9 Processor-Specific Include Files

The xreg\_cortexa9.h include file contains the register numbers and the register bits for the ARM Cortex-A9 processor.

The xpseudo\_asm.h include file contains the definitions for the most often used inline assembler instructions, available as macros. These can be very useful for tasks such as setting or getting special purpose registers, synchronization, or cache manipulation. These inline assembler instructions can be used from drivers and user applications written in C.

## Cortex A9 Time Functions

The xtime\_l.c file and corresponding xtime\_l.h include file provide access to the 64-bit Global Counter in the PMU. This counter increases by one at every 2 processor cycles. The sleep.c file and corresponding sleep.h include file implement sleep functions. Sleep functions are implemented as busy loops.

## Cortex A9 Time Function Summary

The time functions are summarized below. Click on the function name to go to the description.

```
typedef unsigned long long XTime
void XTime_SetTime(XTime xtime)
void XTime_GetTime(XTime *xtime)
unsigned int usleep(unsigned int useconds)
unsigned int sleep(unsigned int _seconds)
void nanosleep(unsigned int nanoseconds)
```

## Cortex A9 Time Function Descriptions

---

```
typedef unsigned long long XTime
```

The XTime type in xtime\_l.h is a 64-bit value, which represents the Global Counter.

---

```
void XTime_SetTime(XTime xtime)
```

Sets the global timer to the value in xtime.



```
void XTime_GetTime(XTime *xtime)
```

Writes the current value of the Global Timer to variable xtime.

---

```
unsigned int usleep(unsigned int useconds)
```

Delays the execution of a program by useconds microseconds. It returns zero if the delay can be achieved or -1 if the delay can't be achieved. This function requires that the processor frequency (in Hz) is defined in xparameters.h.

---

```
unsigned int sleep(unsigned int _seconds)
```

Delays the execution of a program by what is specified in seconds. It always returns zero. This function requires that the processor frequency (in Hz) is defined in xparameters.h.

---

```
void nanosleep(unsigned int nanoseconds)
```

The nanosleep( ) function in usleep.c is not implemented. It is a placeholder for linking applications against the C library.

### Cortex A9 Event Counters

xpm\_counter.c and xpm\_counter.h provide APIs for configuring and controlling the Cortex-A9 Performance Monitor Events. Cortex-A9 Performance Monitor has 6 event counters which can be used to count a variety of events described in Cortex-A9 TRM.

xpm\_counter.h defines configurations(XPM\_CNTRCFGx) which specifies the event counters to count a set of events.

### Cortex A9 Event Counters Function Summary

The Event Counters functions are summarized below. Click on the function name to go to the description.

```
void Xpm_SetEvents(int PmcrCfg)
```

```
void Xpm_GetEventCounters(u32 *PmCtrValue)
```

### Cortex A9 Event Counters Function Description

---

```
void Xpm_SetEvents(int PmcrCfg)
```

This function configures the Cortex A9 event counters controller, with the event codes, in a configuration selected by the user and enables the counters.

PmcrCfg is configuration value based on which the event counters are configured.

Use XPM\_CNTRCFG\* values defined in xpm\_counter.h to define a configuration which specify the event counters to count a set of events.

---

```
void Xpm_GetEventCounters(u32 *PmCtrValue)
```

This function disables the event counters and returns the counter values.

PmCtrValue returns the counter values.

## Xilinx Hardware Abstraction Layer

The following sections describe the Xilinx® Hardware Abstraction Layer API. It contains the following sections:

- [Types \(xil\\_types\)](#)
- [Register IO \(xil\\_io\)](#)
- [Exception \(xil\\_exception\)](#)
- [Cache \(xil\\_cache\)](#)
- [Assert \(xil\\_assert\)](#)
- [Extra Header File](#)
- [Test Memory \(xil\\_testmem\)](#)
- [Test Register IO \(xil\\_testio\)](#)
- [Test Cache \(xil\\_testcache\)](#)
- [Hardware Abstraction Layer Migration Tips](#)

### Types (xil\_types)

#### Header File

```
#include "xil_types.h"
```

#### Typedef

```
typedef unsigned char u8
typedef unsigned short u16
typedef unsigned long u32
typedef unsigned long long u64
typedef char s8
typedef short s16
typedef long s32
typedef long long s64
```

#### Macros

Macro	Value
#define TRUE	1
#define FALSE	0
#define NULL	0
#define XIL_COMPONENT_IS_READY	0x11111111
#define XIL_COMPONENT_IS_STARTED	0x22222222

### Register IO (xil\_io)

#### Header File

```
#include "xil_io.h"
```

## Common API

The following is a linked summary of register IO functions. They can run on MicroBlaze, PowerPC 405, PowerPC 440, and Cortex A9 processors.

u8 Xil\_In8(u32 Addr)  
u16 Xil\_EndianSwap16 (u16 Data)  
u16 Xil\_Htons(u16 Data)  
u16 Xil\_In16(u32 Addr)  
u16 Xil\_In16BE(u32 Addr)  
u16 Xil\_In16LE(u32 Addr)  
u16 Xil\_Ntohs(u16 Data)  
u32 Xil\_EndianSwap32 u32 Data)  
u32 Xil\_Htonl(u32 Data)  
u32 Xil\_In32(u32 Addr)  
u32 Xil\_In32BE(u32 Addr)  
u32 Xil\_In32LE(u32 Addr)  
u32 Xil\_Ntohs(u32 Data)  
void Xil\_Out8(u32 Addr, u8 Value)  
void Xil\_Out16(u32 Addr, u16 Value)  
void Xil\_Out16BE(u32 Addr, u16 Value)  
void Xil\_Out16LE(u32 Addr, u16 Value)  
void Xil\_Out32(u32 Addr, u32 Value)  
void Xil\_Out32BE(u32 Addr, u32 Value)  
void Xil\_Out32LE(u32 Addr, u32 Value)

---

u8 **Xil\_In8**(u32 Addr)

Perform an input operation for an 8-bit memory location by reading from the specified address and returning the value read from that address.

Parameters:

Addr contains the address at which to perform the input operation.

Returns:

The value read from the specified input address.

---

u16 **Xil\_EndianSwap16** (u16 Data)

Perform a 16-bit endian swapping.

Parameters:

Data contains the value to be swapped.

Returns:

Endian swapped value.

---

u16 **Xil\_Htons**(u16 Data)

Convert a 16-bit number from host byte order to network byte order.

Parameters:

Data the 16-bit number to be converted.

Returns:

The converted 16-bit number in network byte order.

---

u16 **Xil\_In16**(u32 Addr)

Perform an input operation for a 16-bit memory location by reading from the specified address and returning the value read from that address.

Parameters:

Addr contains the address at which to perform the input operation.

Returns:

The value read from the specified input address.

---

u16 **Xil\_In16BE**(u32 Addr)

Perform a big-endian input operation for a 16-bit memory location by reading from the specified address and returning the value read from that address.

Parameters:

Addr contains the address at which to perform the input operation.

Returns:

The value read from the specified input address with the proper endianness. The return value has the same endianness as that of the processor. For example, if the processor is little-endian, the return value is the byte-swapped value read from the address.

---

u16 **Xil\_In16LE**(u32 Addr)

Perform a little-endian input operation for a 16-bit memory location by reading from the specified address and returning the value read from that address.

Parameters:

Addr contains the address at which to perform the input operation.

Returns:

The value read from the specified input address with the proper endianness. The return value has the same endianness as that of the processor. For example, if the processor is big-endian, the return value is the byte-swapped value read from the address.

---

u16 **Xil\_Ntohs**(u16 Data)

Convert a 16-bit number from network byte order to host byte order.

Parameters:

Data the 16-bit number to be converted.

Returns:

The converted 16-bit number in host byte order.

u32 **Xil\_EndianSwap32** (u32 Data)

Perform a 32-bit endian swapping.

Parameters:

Data contains the value to be swapped.

Returns:

Endian swapped value.

---

u32 **Xil\_Htonl** (u32 Data)

Convert a 32-bit number from host byte order to network byte order.

Parameters:

Data the 32-bit number to be converted.

Returns:

The converted 32-bit number in network byte order.

---

u32 **Xil\_In32** (u32 Addr)

Perform an input operation for a 32-bit memory location by reading from the specified address and returning the value read from that address.

Parameters:

Addr contains the address at which to perform the input operation.

Returns:

The value read from the specified input address.

---

u32 **Xil\_In32BE** (u32 Addr)

Perform a big-endian input operation for a 32-bit memory location by reading from the specified address and returning the value read from that address.

Parameters:

Addr contains the address at which to perform the input operation.

Returns:

The value read from the specified input address with the proper endianness. The return value has the same endianness as that of the processor. For example, if the processor is little-endian, the return value is the byte-swapped value read from the address.

```
u32 Xil_In32LE(u32 Addr)
```

Perform a little-endian input operation for a 32-bit memory location by reading from the specified address and returning the value read from that address.

Parameters:

`Addr` contains the address at which to perform the input operation.

Returns:

The value read from the specified input address with the proper endianness. The return value has the same endianness as that of the processor. For example, if the processor is big-endian, the return value is the byte-swapped value read from the address.

---

```
u32 Xil_Ntohs(u32 Data)
```

Convert a 32-bit number from network byte order to host byte order.

Parameters:

`Data` the 32-bit number to be converted.

Returns:

The converted 32-bit number in host byte order.

---

```
void Xil_Out8(u32 Addr, u8 Value)
```

Perform an output operation for an 8-bit memory location by writing the specified value to the specified address.

Parameters:

`Addr` contains the address at which to perform the output operation.

`Value` contains the value to be output at the specified address.

---

```
void Xil_Out16(u32 Addr, u16 Value)
```

Perform an output operation for a 16-bit memory location by writing the specified value to the specified address.

Parameters:

`Addr` contains the address at which to perform the output operation.

`Value` contains the value to be output at the specified address.

---

```
void Xil_Out16BE(u32 Addr, u16 Value)
```

Perform a big-endian output operation for a 16-bit memory location by writing the specified value to the specified address.

Parameters:

`Addr` contains the address at which to perform the output operation.

`Value` contains the value to be output at the specified address. The value has the same endianness as that of the processor. For example, if the processor is little-endian, the byte-swapped value is written to the address.

```
void Xil_Out16LE(u32 Addr, u16 Value)
```

Perform a little-endian output operation for a 16-bit memory location by writing the specified value to the specified address.

Parameters:

`Addr` contains the address at which to perform the output operation.

`Value` contains the value to be output at the specified address. The value has the same endianness as that of the processor. For example, if the processor is big-endian, the byte-swapped value is written to the address.

---

```
void Xil_Out32(u32 Addr, u32 Value)
```

Perform an output operation for a 32-bit memory location by writing the specified value to the specified address.

Parameters:

`Addr` contains the address at which to perform the output operation.

`Value` contains the value to be output at the specified address.

---

```
void Xil_Out32BE(u32 Addr, u32 Value)
```

Perform a big-endian output operation for a 32-bit memory location by writing the specified value to the specified address.

Parameters:

`Addr` contains the address at which to perform the output operation.

`Value` contains the value to be output at the specified address. The value has the same endianness as that of the processor. For example, if the processor is little-endian, the byte-swapped value is written to the address.

---

```
void Xil_Out32LE(u32 Addr, u32 Value)
```

Perform a little-endian output operation for a 32-bit memory location by writing the specified value to the specified address.

Parameters:

`Addr` contains the address at which to perform the output operation.

`Value` contains the value to be output at the specified address. The value has the same endianness as that of the processor. For example, if the processor is big-endian, the byte-swapped value is written to the address.

## Exception (xil\_exception)

### Header File

```
#include "xil_exception.h"
```

### Typedef

```
typedef void(* Xil_ExceptionHandler)(void *Data)
```

This typedef is the exception handler function pointer.

## Common API

The following are exception functions. They can run on MicroBlaze, PowerPC 405, and PowerPC 440 processors.

---

```
void Xil_ExceptionDisable()
```

Disable Exceptions. On PowerPC 405 and PowerPC 440 processors, this function only disables non-critical exceptions.

---

```
void Xil_ExceptionEnable()
```

Enable Exceptions. On PowerPC 405 and PowerPC 440 processors, this function only enables non-critical exceptions.

---

```
void Xil_ExceptionInit()
```

Initialize exception handling for the processor. The exception vector table is set up with the stub handler for all exceptions.

---

```
void Xil_ExceptionRegisterHandler(u32 Id,  
    Xil_ExceptionHandler Handler, void *Data)
```

Make the connection between the ID of the exception source and the associated handler that runs when the exception is recognized. *Data* is used as the argument when the handler is called.

Parameters:

*Id* contains the identifier (ID) of the exception source. This should be `XIL_EXCEPTION_INT` or be in the range of 0 to `XIL_EXCEPTION_LAST`. Refer to the `xil_exception.h` file for further information.

*Handler* is the handler for that exception.

*Data* is a reference to data that will be passed to the handler when it is called.

---

```
void Xil_ExceptionRemoveHandler(u32 Id)
```

Remove the handler for a specific exception ID. The stub handler is then registered for this exception ID.

Parameters:

*Id* contains the ID of the exception source. It should be `XIL_EXCEPTION_INT` or in the range of 0 to `XIL_EXCEPTION_LAST`. Refer to the `xil_exception.h` file for further information.

## Common Macro

The common macro is:

```
#define XIL_EXCEPTION_ID_INT
```

This macro is defined for all processors and used to set the exception handler that corresponds to the interrupt controller handler. The value is processor-dependent. For example:

```
Xil_ExceptionRegisterHandler(XIL_EXCEPTION_ID_INT,  
    (XilExceptionHandler)IntcHandler, IntcData)
```



## MicroBlaze Processor-Specific Macros

Macro	Value
#define XIL_EXCEPTION_ID_FIRST	0
#define XIL_EXCEPTION_ID_FSL	0
#define XIL_EXCEPTION_ID_UNALIGNED_ACCESS	1
#define XIL_EXCEPTION_ID_ILLEGAL_OPCODE	2
#define XIL_EXCEPTION_ID_IOPB_EXCEPTION	3
#define XIL_EXCEPTION_ID_IPLB_EXCEPTION	3
#define XIL_EXCEPTION_ID_DOPB_EXCEPTION	4
#define XIL_EXCEPTION_ID_DPLB_EXCEPTION	4
#define XIL_EXCEPTION_ID_DIV_BY_ZERO	5
#define XIL_EXCEPTION_ID_FPU	6
#define XIL_EXCEPTION_ID_MMU	7
#define XIL_EXCEPTION_ID_LAST	XIL_EXCEPTION_ID_MMU

## PowerPC 405 Processor-Specific Functions and Macros

The following functions and macros are used with PowerPC 405 Processors.

---

```
void Xil_ExceptionDisableMask(u32 Mask)
```

Disable exceptions.

Parameters:

Mask is a bitmask for exceptions to be disabled.

---

```
void Xil_ExceptionEnableMask(u32 Mask)
```

Enable exceptions.

Parameters:

Mask is a bitmask for exceptions to be enabled.

**Table 10: Macros Used for Both Enabling and Disabling Exceptions**

Macro	Value
#define XIL_EXCEPTION_CRITICAL	0x00020000
#define XIL_EXCEPTION_NON_CRITICAL	0x00008000
#define XIL_EXCEPTION_ALL	0x00028000

Table 11: Macros Used for Registering Exceptions

Macro	Value
#define XIL_EXCEPTION_ID_FIRST	0
#define XIL_EXCEPTION_ID_JUMP_TO_ZERO	0
#define XIL_EXCEPTION_ID_CRITICAL_INT	1
#define XIL_EXCEPTION_ID_MACHINE_CHECK	2
#define XIL_EXCEPTION_ID_DATA_STORAGE_INT	3
#define XIL_EXCEPTION_ID_INSTRUCTION_STORAGE_INT	4
#define XIL_EXCEPTION_ID_NON_CRITICAL_INT	5
#define XIL_EXCEPTION_ID_ALIGNMENT_INT	6
#define XIL_EXCEPTION_ID_PROGRAM_INT	7
#define XIL_EXCEPTION_ID_FPU_UNAVAILABLE_INT	8
#define XIL_EXCEPTION_ID_SYSTEM_CALL	9
#define XIL_EXCEPTION_ID_APU_AVAILABLE	10
#define XIL_EXCEPTION_ID_PIT_INT	11
#define XIL_EXCEPTION_ID_FIT_INT	12
#define XIL_EXCEPTION_ID_WATCHDOG_TIMER_INT	13
#define XIL_EXCEPTION_ID_DATA_TLB_MISS_INT	14
#define XIL_EXCEPTION_ID_INSTRUCTION_TLB_MISS_INT	15
#define XIL_EXCEPTION_ID_DEBUG_INT	16
#define XIL_EXCEPTION_ID_LAST	16

### PowerPC 440 Processor-Specific Functions and Macros

The following functions and macros are used with PowerPC 440 Processors.

---

```
void Xil_ExceptionDisableMask(u32 Mask)
```

Disable exceptions.

Parameters:

Mask is a mask for exceptions to be disabled.

---

```
void Xil_ExceptionEnableMask(u32 Mask)
```

Enable exceptions.

Parameters:

Mask is a bitmask for exceptions to be disabled.

[Table 12, page 67](#) lists the macros used for enabling exceptions.

Table 12: Macros Used for Enabling Exceptions

Macro	Value
#define XIL_EXCEPTION_CRITICAL	0x00020000
#define XIL_EXCEPTION_NON_CRITICAL	0x00008000
#define XIL_EXCEPTION_MACHINE_CHECK	0x00001000
#define XIL_EXCEPTION_DEBUG	0x00000200
#define XIL_EXCEPTION_ALL	0x00029200
#define XIL_EXCEPTION_ID_FIRST	0
#define XIL_EXCEPTION_ID_CRITICAL_INT	0
#define XIL_EXCEPTION_ID_MACHINE_CHECK	1
#define XIL_EXCEPTION_ID_DATA_STORAGE_INT	2
#define XIL_EXCEPTION_ID_INSTRUCTION_STORAGE_INT	3
#define XIL_EXCEPTION_ID_NON_CRITICAL_INT	4
#define XIL_EXCEPTION_ID_ALIGNMENT_INT	5
#define XIL_EXCEPTION_ID_PROGRAM_INT	6
#define XIL_EXCEPTION_ID_FPU_UNAVAILABLE_INT	7
#define XIL_EXCEPTION_ID_SYSTEM_CALL	8
#define XIL_EXCEPTION_ID_APU_AVAILABLE	9
#define XIL_EXCEPTION_ID_DEC_INT	10
#define XIL_EXCEPTION_ID_FIT_INT	11
#define XIL_EXCEPTION_ID_WATCHDOG_TIMER_INT	12
#define XIL_EXCEPTION_ID_DATA_TLB_MISS_INT	13
#define XIL_EXCEPTION_ID_INSTRUCTION_TLB_MISS_INT	14
#define XIL_EXCEPTION_ID_DEBUG_INT	15
#define XIL_EXCEPTION_ID_LAST	15

## Cache (xil\_cache)

### Header File

```
#include "xil_cache.h"
```

### Common API

The functions listed in this sub-section can be executed on all processors.

---

```
void xil_DCacheDisable ()
```

Disable the data cache.

---

```
void xil_DCacheEnable ()
```

On MicroBlaze processors, enable the data cache.

On PowerPC 405 processors, enable the data cache with region mask 0x80000001.

On PowerPC 440 processors, enable the data cache with region mask 0xC0000001.

---

```
void Xil_DCacheFlush()
```

Flush the entire data cache. If any cacheline is dirty (has been modified), it is written to system memory. The entire data cache will be invalidated.

---

```
void Xil_DCacheFlushRange(u32 Addr, u32 Len)
```

Flush the data cache for the given address range. If any memory in the address range (identified as `Addr`) has been modified (and are dirty), the modified cache memory will be written back to system memory. The cacheline will also be invalidated.

Parameters:

`Addr` is the starting address of the range to be flushed.

`Len` is the length, in bytes, to be flushed.

---

```
void Xil_DCacheInvalidate()
```

Invalidate the entire data cache. If any cacheline is dirty (has been modified), the modified contents are lost.

---

```
void Xil_DCacheInvalidateRange(u32 Addr, u32 Len)
```

Invalidate the data cache for the given address range. If the bytes specified by the address (`Addr`) are cached by the data cache, the cacheline containing that byte is invalidated. If the cacheline is modified (dirty), the modified contents are lost.

Parameters:

`Addr` is address of range to be invalidated.

`Len` is the length in bytes to be invalidated.

---

```
void Xil_ICacheDisable()
```

Disable the instruction cache.

---

```
void Xil_ICacheEnable()
```

On MicroBlaze processors, enable the instruction cache.

On PowerPC 405 processors, enable the instruction cache with region mask `0x80000001`.

On PowerPC 440 processors, enable the instruction cache with region mask `0xC0000001`.

---

```
void Xil_ICacheInvalidate()
```

Invalidate the entire instruction cache.

---

```
void Xil_ICacheInvalidateRange(u32 Addr, u32 Len)
```

Invalidate the instruction cache for the given address range.

Parameters:

`Addr` is address of range to be invalidated.

`Len` is the length in bytes to be invalidated.

---

## PowerPC 405 Processor-Specific Functions and Macros

The following functions are specific to PowerPC 405 processors.

```
void Xil_DCACHEEnableRegion(u32 Regions)
```

```
void Xil_ICACHEEnableRegion(u32 Regions)
```

```
void Xil_DCACHEEnableRegion(u32 Regions)
```

Enable the data cache region.

Parameters:

Regions <sup>1</sup>	Cached Address Range
0x80000000	[0, 0x7FFFFFFF]
0x00000001	[0xF8000000, 0xFFFFFFFF]
0x80000001	[0, 0x7FFFFFFF],[0xF8000000, 0xFFFFFFFF]

- Regions to be marked as cacheable. Each bit in the regions variable stands for 128 MB of memory.

```
void Xil_ICACHEEnableRegion(u32 Regions)
```

Enable the instruction cache.

Parameters :

Regions <sup>1</sup>	Cached Address Range
0x80000000	[0, 0x7FFFFFFF]
0x00000001	[0xF8000000, 0xFFFFFFFF]
0x80000001	[0, 0x7FFFFFFF],[0xF8000000, 0xFFFFFFFF]

- Regions to be marked as cacheable. Each bit in the regions variable stands for 128 MB of memory.

## PowerPC 440 Processor-Specific Functions and Macros

The following functions are specific to PowerPC 440 processors.

```
void Xil_DCACHEEnableRegion(u32 Regions)
```

Enable the data cache.

Parameters:

Regions <sup>1</sup>	Cached Address Range
0x4000_0000	[0, 0x0FFF_FFFF]
0x8000_0000	
0xC000_0000	
0x0000_0001	[0xF000_0000, 0xFFFF_FFFF]
0x0000_0002	
0x0000_0003	
0x4000_0001	[0, 0x0FFF_FFFF],[0xF000_0000, 0xFFFF_FFFF]
0x4000_0002	
0x4000_0003	
0x8000_0001	
0x8000_0002	
0x8000_0003	
0xC000_0001	
0xC000_0002	
0xC000_0003	

- Regions of memory to be marked as cacheable. Each pair of adjacent bits in the regions variable stands for 256 MB of memory. Setting either bit in the pair will enable caching for the corresponding region.

---

```
void Xil_ICacheEnableRegion(u32 Regions)
```

Enable the instruction cache.

Parameters:

Regions <sup>1</sup>	Cached Address Range
0x4000_0000	[0, 0x0FFF_FFFF]
0x8000_0000	
0xC000_0000	
0x0000_0001	[0xF000_0000, 0xFFFF_FFFF]
0x0000_0002	
0x0000_0003	
0x4000_0001	[0, 0x0FFF_FFFF],[0xF000_0000, 0xFFFF_FFFF]
0x4000_0002	
0x4000_0003	
0x8000_0001	
0x8000_0002	
0x8000_0003	
0xC000_0001	
0xC000_0002	
0xC000_0003	

1. Regions of memory to be marked as cacheable. Each pair of adjacent bits in the regions variable stands for 256 MB of memory. Setting either bit in the pair will enable caching for the corresponding region.

## Assert (xil\_assert)

### Header File

```
#include "xil_assert.h"
```

### Typedef

```
typedef void(* Xil_AssertCallback)(char *Filename, int Line)
```

### Common API

The functions listed in this sub-section can be executed on all processors.

---

```
void Xil_Assert(char *File, int Line)
```

Implement `assert`. Currently, it calls a user-defined callback function if one has been set. Then, potentially enters an infinite loop depending on the value of the `Xil_AssertWait` variable.

Parameters:

`File` is the name of the filename of the source.

`Line` is the line number within `File`.

---

```
void Xil_AssertSetCallback(xil_AssertCallback Routine)
```

Set up a callback function to be invoked when an assert occurs. If there was already a callback installed, then it is replaced.

Parameters:

`Routine` is the callback to be invoked when an assert is taken.

---

```
#define Xil_AssertVoid(Expression)
```

This assert macro is to be used for functions that do not return anything (void). This can be used in conjunction with the `Xil_AssertWait` boolean to accommodate tests so that asserts that fail still allow execution to continue.

Parameters:

`Expression` is the expression to evaluate. If it evaluates to false, the assert occurs.

---

```
#define Xil_AssertNonvoid(Expression)
```

This assert macro is to be used for functions that return a value. This can be used in conjunction with the `Xil_AssertWait` boolean to accommodate tests so that asserts that fail still allow execution to continue.

Parameters:

`Expression` is the expression to evaluate. If it evaluates to false, the assert occurs.

Returns:

Returns 0 unless the `Xil_AssertWait` variable is true, in which case no return is made and an infinite loop is entered.

---

```
#define Xil_AssertVoidAlways( )
```

Always assert. This assert macro is to be used for functions that do not return anything (void). Use for instances where an assert should always occur.

Returns:

Returns void unless the `Xil_AssertWait` variable is true, in which case no return is made and an infinite loop is entered.

---

```
#define Xil_AssertNonvoidAlways( )
```

Always assert. This assert macro is to be used for functions that return a value. Use for instances where an assert should always occur.

Returns:

Returns void unless the `xil_AssertWait` variable is true, in which case no return is made and an infinite loop is entered.



## Extra Header File

The `xil_hal.h` header file is provided as a convenience. It includes all the header files related to the Hardware Abstraction Layer. The contents of this header file are as follows:

```
#ifndef XIL_HAL_H
#define XIL_HAL_H

#include "xil_assert.h"
#include "xil_exception.h"
#include "xil_cache.h"
#include "xil_io.h"
#include "xil_types.h"

#endif
```

## Test Memory (xil\_testmem)

### Description

A subset of the memory tests can be selected or all of the tests can be run in order. If there is an error detected by a subtest, the test stops and the failure code is returned. Further tests are not run even if all of the tests are selected.

### Subtest Descriptions

---

#### **XIL\_TESTMEM\_ALLMEMTESTS**

Runs all of the subtests.

---

#### **XIL\_TESTMEM\_INCREMENT**

Incrementing Value test.

This test starts at `XIL_TESTMEM_MEMTEST_INIT_VALUE` and uses the incrementing value as the test value for memory.

---

#### **XIL\_TESTMEM\_WALKONES**

Walking Ones test.

This test uses a walking "1" as the test value for memory.

```
location 1 = 0x00000001
location 2 = 0x00000002
...
```

---

#### **XIL\_TESTMEM\_WALKZEROS**

Walking Zeros test.

This test uses the inverse value of the walking ones test as the test value for memory.

```
location 1 = 0xFFFFFFFF
location 2 = 0xFFFFFFFFD
...
```

---

**XIL\_TESTMEM\_INVERSEADDR**

Inverse Address test.

This test uses the inverse of the address of the location under test as the test value for memory.

---

**XIL\_TESTMEM\_FIXEDPATTERN**

Fixed Pattern test.

This test uses the provided patterns as the test value for memory.

If zero is provided as the pattern, the test uses 0xDEADBEEF.

**Caution!** The tests are DESTRUCTIVE. Run them before any initialized memory spaces have been set up. The address provided to the memory tests is not checked for validity, except for the case where the value is NULL. It is possible to provide a code-space pointer for this test to start with and ultimately destroy executable code causing random failures.

**Note:** This test is used for spaces where the address range of the region is smaller than the data width. If the memory range is greater than 2 to the power of width, the patterns used in XIL\_TESTMEM\_WALKONES and XIL\_TESTMEM\_WALKZEROS will repeat on a boundary of a power of two, making it more difficult to detect addressing errors. The XIL\_TESTMEM\_INCREMENT and XIL\_TESTMEM\_INVERSEADDR tests suffer the same problem. If you need to test large blocks of memory, it is recommended that you break them up into smaller regions of memory to allow the test patterns used not to repeat over the region tested.

**Header File**

```
#include "xil_testmem.h"
```

**Common API**

---

```
int Xil_Testmem8(u8 *Addr, u32 Words, u8 Pattern, u8
    Subtest)
```

Perform a destructive 8-bit wide memory test.

Parameters:

Addr is a pointer to the region of memory to be tested.

Words is the length of the block.

Pattern is the constant used for the constant pattern test, if 0, 0xDEADBEEF is used.

Subtest is the test selected. See xil\_testmem.h for possible values.

Returns:

-1 is returned for a failure

0 is returned for a pass

**Note:** Used for spaces where the address range of the region is smaller than the data width. If the memory range is greater than 2 to the power of width, the patterns used in XIL\_TESTMEM\_WALKONES and XIL\_TESTMEM\_WALKZEROS repeat on a boundary of a power of two, which makes detecting addressing errors more difficult. This is true of XIL\_TESTMEM\_INCREMENT and XIL\_TESTMEM\_INVERSEADDR tests also. If you need to test large blocks of memory, it is recommended that you break them up into smaller regions of memory to allow the test patterns used not to repeat over the region tested.

---

```
int Xil_Testmem16(u16 *Addr, u32 Words, u16 Pattern, u8
    Subtest)
```

Perform a destructive 16-bit wide memory test.

Parameters:

`Addr` is a pointer to the region of memory to be tested.

`Words` is the length of the block.

`Pattern` is the constant used for the constant pattern test, if 0, 0xDEADBEEF is used.

`Subtest` is the test selected. See `xil_testmem.h` for possible values.

Returns:

-1 is returned for a failure.

0 is returned for a pass.

**Note:** Used for spaces where the address range of the region is smaller than the data width. If the memory range is greater than 2 to the power of width, the patterns used in `XIL_TESTMEM_WALKONES` and `XIL_TESTMEM_WALKZEROS` repeat on a boundary of a power of two, making detecting addressing errors more difficult.

This is true of `XIL_TESTMEM_INCREMENT` and `XIL_TESTMEM_INVERSEADDR` tests also. If you need to test large blocks of memory, it is recommended that you break them up into smaller regions of memory to allow the test patterns used not to repeat over the region tested.

---

```
int Xil_Testmem32 (u32 *Addr, u32 Words, u32 pattern, u8
    Subtest)
```

Perform a destructive 32-bit wide memory test.

Parameters:

`Addr` is a pointer to the region of memory to be tested.

`Words` is the length of the block.

`Pattern` is the constant used for the constant pattern test, if 0, 0xDEADBEEF is used.

`Subtest` is the test selected. See `xil_testmem.h` for possible values.

Returns:

0 is returned for a pass.

-1 is returned for a failure.

**Note:** This test is used for spaces where the address range of the region is smaller than the data width. If the memory range is greater than 2 to the power of width, the patterns used in `XIL_TESTMEM_WALKONES` and `XIL_TESTMEM_WALKZEROS` repeat on a boundary of a power of two, making detecting addressing errors more difficult. This is true of the `XIL_TESTMEM_INCREMENT` and `XIL_TESTMEM_INVERSEADDR` tests also. If you need to test large blocks of memory, it is recommended that you break them up into smaller regions of memory to allow the test patterns used not to repeat over the region tested.

## Test Register IO (`xil_testio`)

This file contains utility functions to teach endian-related memory I/O functions.

### Header File

```
#include "xil_testio.h"
```

## Common API

---

```
int Xil_TestIO8(u8 *Addr, int Len, u8 Value)
```

Perform a destructive 8-bit wide register IO test where the register is accessed using `Xil_Out8` and `Xil_In8`. the `Xil_TestIO8` function compares the read and write values.

Parameters:

`Addr` is a pointer to the region of memory to be tested.

`Len` is the length of the block.

`Value` is the constant used for writing the memory.

Returns:

0 is returned for a pass.

-1 is returned for a failure.

---

```
int Xil_TestIO16(u8 *Addr, int Len, u16 Value, int Kind,  
int Swap)
```

Perform a destructive 16-bit wide register IO test. Each location is tested by sequentially writing a 16-bit wide register, reading the register, and comparing value. This function tests three kinds of register IO functions, normal register IO, little-endian register IO, and big-endian register IO. When testing little/big-endian IO, the function performs the following sequence:

`Xil_Out16LE/Xil_Out16BE`, `Xil_In16`, Compare In-Out values, `Xil_Out16`, `Xil_In16LE/Xil_In16BE`, Compare In-Out values. Whether to swap the read-in value before comparing is controlled by the 5th argument.

Parameters:

`Addr` is a pointer to the region of memory to be tested.

`Len` is the length of the block.

`Value` is the constant used for writing the memory.

`Kind` is the test kind. Acceptable values are: `XIL_TESTIO_DEFAULT`, `XIL_TESTIO_LE`, `XIL_TESTIO_BE`.

`Swap` indicates whether to byte swap the read-in value.

Returns:

0 is returned for a pass.

-1 is returned for a failure.

---

```
int Xil_TestIO32(u8 *Addr, int Len, u32 Value, int Kind,  
int Swap)
```

Perform a destructive 32-bit wide register IO test. Each location is tested by sequentially writing a 32-bit wide register, reading the register, and comparing value. This function tests three kinds of register IO functions, normal register IO, little-endian register IO, and big-endian register IO. When testing little/big-endian IO, the function performs the following sequence: Xil\_Out32LE/Xil\_Out32BE, Xil\_In32, Compare In-Out values, Xil\_Out32, Xil\_In32LE/Xil\_In32BE, Compare In-Out values. Whether to swap the read-in value before comparing is controlled by the 5th argument.

Parameters:

Addr is a pointer to the region of memory to be tested.

Len is the length of the block.

Value is the constant used for writing the memory.

Kind is the test kind. Acceptable values are: XIL\_TESTIO\_DEFAULT, XIL\_TESTIO\_LE, XIL\_TESTIO\_BE.

Swap indicates whether to byte swap the read-in value.

Returns:

0 is returned for a pass.

-1 is returned for a failure.

## Test Cache (xil\_testcache)

This file contains utility functions to test the cache.

### Header File

```
#include "xil_testcache.h"
```

### Common API

---

```
int Xil_TestDCacheAll()
```

Tests the DCache related functions on all related API tests such as Xil\_DCacheFlush and Xil\_DCacheInvalidate. This test function writes a constant value to the data array, flushes the DCache, writes a new value, and then invalidates the DCache.

Returns:

0 is returned for a pass.

-1 is returned for a failure.

---

```
int Xil_TestDCacheRange()
```

Tests the DCache range-related functions on a range of related API tests such as Xil\_DCacheFlushRange and Xil\_DCacheInvalidate\_range. This test function writes a constant value to the data array, flushes the range, writes a new value, and then invalidates the corresponding range.

Returns:

0 is returned for a pass.

-1 is returned for a failure.

```
int Xil_TestICacheAll()
```

Perform `xil_icache_invalidate()`.

Returns:

0 is returned for a pass. The function will hang if it fails.

```
int Xil_TestICacheRange()
```

Perform `Xil_ICacheInvalidateRange()` on a few function pointers.

Returns:

0 is returned for a pass. The function will hang if it fails.

## Hardware Abstraction Layer Migration Tips

### Mapping Header Files to HAL Header Files

You can map old header files to the new HAL header files as listed in [Table 13](#).

*Table 13: HAL Header File Mapping*

Area	Old Header File	New Header File
Register IO	"xio.h"	"xil_io.h"
Exception	"xexception_l.h" "mb_interface.h"	"xil_exception.h"
Cache	"xcache.h" "mb_interface.h"	"xil_cache.h"
Interrupt	"xexception_l.h" "mb_interface.h"	"xil_exception.h"
Typedef u8 u16 u32	"xbasic_types.h"	"xil_types.h"
Typedef of Xuint32 Xfloat32 ...	"xbasic_types.h"	Deprecated. Do not use.
Assert	"xbasic_types.h"	"xil_assert.h"
Test Memory	"xutil.h"	"xil_testmem.h"
Test Register IO	None	"xil_testio.h"
Test Cache	None	"xil_testcache.h"

## Mapping Functions to HAL Functions

You can map old functions to the new HAL functions as follows.

**Table 14: I/O Function Mapping**

Old xio	New xil_io
#include "xio.h"	#include "xil_io.h"
Xlo_In8	Xil_In8
Xlo_Out8	Xil_Out8
Xlo_In16	Xil_In16
Xlo_Out16	Xil_Out16
Xlo_In32	Xil_In32
Xlo_Out32	Xil_Out32

**Table 15: Exception Function Mapping**

Old xexception	New Xil_exception
#include "xexception.l.h" #include "mb_interface.h"	#include "xil_exception.h"
XExc_Init	Xil_ExceptionInit
XExc_mEnableException microblaze_enable_exceptions	For all processors: Xil_ExceptionEnable(void) For PowerPC Only: Xil_ExceptionEnableMask(void)
XExc_registerHandler microblaze_register_exception_handler	Xil_ExceptionRegisterHandler
XExc_RemoveHandler	Xil_ExceptionRemoveHandler
XExc_mDisableExceptions microblaze_disable_exceptions	Xil_ExceptionDisable

**Table 16: Interrupt Function Mapping**

Old Interrupt	New Xil_interrupt
#include "xexception.l.h"	#include "xil_exception.h"
XExc_RegisterHandler(XEXC_ID_NON_CRITICAL, handler) microblaze_register_handler(handler)	Xil_ExceptionRegisterHandler(XIL_EXCEPTION_ID_INT, handler)

Table 17: Cache Function Mapping

Old xcache	New xil_cache
#include "Xcache_I.h" #include "mb_interface.h"	#include "xil_cache.h"
XCache_EnableDCache microblaze_enable_dcache	For all processors: Xil_DCacheEnable(void) For PowerPC only: Xil_DCacheEnableRegion(regions)
XCache_DisableDCache microblaze_disable_dcache	Xil_DCacheDisable
XCache_InvalidateDCacheRange microblaze_invalidate_dcache_range	Xil_DCacheInvalidateRange
microblaze_invalidate_dcache	Xil_DCacheInvalidate
XCache_FlushDCacheRange microblaze_flush_dcache_range	Xil_DCacheFlushRange
microblaze_flush_dcache	Xil_DCacheFlush
XCache_EnableICache microblaze_enable_icache	For all processors: Xil_ICacheEnable(void) For PowerPC only: Xil_ICacheEnableRegion(regions)
XCache_DisableICache microblaze_disable_icache	Xil_ICacheDisable
XCache_InvalidateICacheRange microblaze_invalidate_icache_Range	Xil_ICacheInvalidateRange
microblaze_invalidate_icache	Xil_ICacheInvalidate

Table 18: Assert Function Mapping

Old ASSERT	New xil_assert
#include "xbasic_types.h"	#include "xil_assert.h"
XAssert	Xil_Assert
XASSERT_VOID	Xil_AssertVoid
XASSERT_NONVOID	Xil_AssertNonvoid
XASSERT_VOID_ALWAYS	Xil_AssertVoidAlways
XASSERT_NONVOID_ALWAYS	Xil_AssertNonvoidAlways
XAssertSetCallback	Xil_AssertSetCallback

Table 19: Memory Test Function Mapping

Old XUtil_Memtest	New xil_util_testmem
#include "xutil.h"	#include "xil_util_testmem.h"
XUtil_MemoryTest32	Xil_Testmem32
XUtil_MemoryTest16	Xil_Testmem16
XUtil_MemoryTest8	Xil_Testmem8



## Program Profiling

The Standalone OS supports program profiling in conjunction with the GNU compiler tools and the Xilinx Microprocessor Debugger (XMD). Profiling a program running on a hardware (board) provides insight into program execution and identifies where execution time is spent. The interaction of the program with memory and other peripherals can be more accurately captured.

Program running on hardware target is profiled using *software intrusive* method. In this method, the profiling software code is instrumented in the user program. The profiling software code is a part of the `libxil.a` library and is generated when software intrusive profiling is enabled in Standalone. For more details on about profiling, refer to the “Profile Overview” section of the *SDK Help*.

When the `-pg` profile option is specified to the compiler (either `mb-gcc` or `powerpc-eabi-gcc`), the profiling functions are linked with the application to profile automatically. The generated executable file contains code to generate profile information.

Upon program execution, this instrumented profiling function stores information on the hardware. XMD collects the profile information and generates the output file, which can be read by the GNU `gprof` tool. The program functionality remains unchanged but it slows down the execution.

**Note:** The profiling functions do not have any explicit application API. The library is linked due to profile calls (`_mcount`) introduced by GCC for profiling.

### Profiling Requirements

- Software intrusive profiling requires memory for storing profile information. You can use any memory in the system for profiling.
- A timer is required for sampling instruction address. The `xps_timer` is the supported profile timer. For PowerPC processor systems, the Programmable Interrupt Timer (PIT) can be used as profile timer also.

### Profiling Functions

---

#### `_profile_init`

Called before the application `main( )` function. Initializes the profile timer routine and registers timer handler accordingly, based on the timer used, connects to the processor, and starts the timer. The Tcl routine of Standalone library determines the timer type and the connection to processor, then generates the `#defines` in the `profile_config.h` file.

Refer to the “Microprocessor Library Definition (MLD)” chapter in the *Embedded System Tools Reference Manual (UG111)*, which is available in the installation directory. A link to this document is also provided in [“MicroBlaze Processor API,” page 1](#).

---

#### `_mcount`

Called by the `_mcount` function, which is inserted at every function start by `gcc`. Records the *caller* and *callee* information (Instruction address), which is used to generate call graph information.

---

#### `_profile_intr_handler`

The interrupt handler for the profiling timer. The timer is set to sample the executing application for PC values at fixed intervals and increment the Bin count. This function is used to generate the histogram information.

## Configuring the Standalone OS

You can configure the Standalone OS using the Board Support Package Settings dialog box in SDK.

Table 20 lists the configurable parameters for the Standalone OS.

Table 20: Configuration Parameters

Parameter	Type	Default Value	Description
enable_sw_intrusive_profiling	Bool	false	Enable software intrusive profiling functionality. Select <b>true</b> to enable.
profile_timer	Peripheral Instance	none	Specify the timer to use for profiling. Select an <b>xps_timer</b> or <b>axi_timer</b> from the list of displayed instances. For a PowerPC system, select <b>none</b> to use the built-in PIT timer. For Cortex A9, the ARM Cortex-A9 Private timer is used.
stdin	Peripheral Instance	none	Specify the <b>STDIN</b> peripheral from the drop down list
stdout	Peripheral Instance	none	Specify the <b>STDOUT</b> peripheral from the drop down list.
predecode_fpu_exception	Bool	false	This parameter is valid only for MicroBlaze processor when FPU exceptions are enabled in the hardware. Setting this to <b>true</b> will include extra code that decodes and stores the faulting FP instruction operands in global variables.

## MicroBlaze MMU Example

The `tlb_add` function adds a single TLB entry. The parameters are:

tlbindex	The index of the TLB entry to be updated.
tlbhi	The value of the TLBHI field.
tlblo	The value of the TLBLO field.

```
static inline void tlb_add(int tlbindex, unsigned int tlbhi, unsigned int
tlblo)
{
    __asm__ __volatile__ ("mts rtlbx,  %2 \n\t"
                          "mts rtlbhi, %0 \n\t"
                          "mts rtlblo, %1 \n\t"
                          ":: "r" (tlbhi),
                          "r" (tlblo),
                          "r" (tlbindex));

    tlbentry[tlbindex].tlbhi = tlbhi;
    tlbentry[tlbindex].tlblo = tlblo;
}
```

Given a base and high address, the `tlb_add_entries` function figures the minimum number page mappings/TLB entries required to cover the area. This function uses recursion to figure the entire range of mappings.

Parameters:

base	The base address of the region of memory
high	The high address of the region of memory
tlbaccess	The type of access required for this region of memory. It can be a logical or -ing of the following flags: 0 indicates read-only access TLB_ACCESS_EXECUTABLE means the region is executable TLB_ACCESS_WRITABLE means the region is writable

Returns: 1 on success and 0 on failure

```

static int tlb_add_entries (unsigned int base, unsigned int high, unsigned
int tlbaccess)
{
    int sizeindex, tlbsizemask;
    unsigned int tlbhi, tlblo;
    unsigned int area_base, area_high, area_size;
    static int tlbindex = 0;

    // Align base and high to 1KB boundaries
    base = base & 0xfffffc00;
    high = (high >= 0xfffffc00) ? 0xffffffff : ((high + 0x400) & 0xfffffc00)
- 1;

    // Start trying to allocate pages from 16 MB granularity down to 1 KB
    area_size = 0x1000000;           // 16 MB
    tlbsizemask = 0x380;             // TLBHI[SIZE] = 7 (16 MB)

    for (sizeindex = 7; sizeindex >= 0; sizeindex--) {
        area_base = base & sizemask[sizeindex];
        area_high = area_base + (area_size - 1);

        // if (area_base <= (0xffffffff - (area_size - 1))) {

        if ((area_base >= base) && (area_high <= high)) {

            if (tlbindex < TLBSIZE) {
                tlbhi = (base & sizemask[sizeindex]) | tlbsizemask | 0x40;
// TLBHI: TAG, SIZE, V
                tlblo = (base & sizemask[sizeindex]) | tlbaccess | 0x8;
// TLBLO: RPN, EX, WR, W
                tlb_add (tlbindex, tlbhi, tlblo);

                tlbindex++;
            } else {
                // We only handle the 64 entry UTLB management for now
                return 0;
            }

            // Recursively add entries for lower area
            if (area_base > base)
                if (!tlb_add_entries (base, area_base - 1, tlbaccess))
                    return 0;
        }
    }
}

```

```
        // Recursively add entries for higher area
        if (area_high < high)
            if (!tlb_add_entries(area_high + 1, high, tlbaccess))
                return 0;

            break;
    }
    // else, we try the next lower page size
    area_size  = area_size >> 2;
    tlbsizemask = tlbsizemask - 0x80;
}
return 1;
}
```

For a complete example, refer to:

`$XILINX_EDK/sw/lib/bsp/xilkernel_v5_00_a/src/src/arch/microblaze/mpu.c`.

## Overview

Xilkernel is a small, robust, and modular kernel. It is highly integrated with the Platform Studio framework and is a free software library that you receive with the Xilinx Embedded Development Kit (EDK). Xilkernel:

- Allows a high degree of customization, letting you tailor the kernel to an optimal level both in terms of size and functionality.
- Supports the core features required in a lightweight embedded kernel, with a POSIX API.
- Works on MicroBlaze™, PowerPC® 405, and PowerPC 440 processors.

Xilkernel IPC services can be used to implement higher level services (such as networking, video, and audio) and subsequently run applications using these services.

## Why Use a Kernel?

The following are a few of the deciding factors that can influence your choice of using a kernel as the software platform for your next application project:

- Typical embedded control applications comprise various *tasks* that need to be performed in a particular sequence or schedule. As the number of control tasks involved grows, it becomes difficult to organize the sub-tasks manually, and to time-share the required work. The responsiveness and the capability of such an application decreases dramatically when the complexity is increased.
- Breaking down tasks as individual applications and implementing them on an operating system (OS) is much more intuitive.
- A kernel enables the you to write code at an abstract level, instead of at a small, micro-controller-level standalone code.
- Many common and legacy applications rely on OS services such as file systems, time management, and so forth. Xilkernel is a thin library that provides these essential services. Porting or using common and open source libraries (such as graphics or network protocols) might require some form of these OS services also.

## Key Features

Xilkernel includes the following key features:

- High scalability into a given system through the inclusion or exclusion of functionality as required.
- Complete kernel configuration and deployment within minutes from inside of SDK.
- Robustness of the kernel: system calls protected by parameter validity checks and proper return of POSIX error codes.
- A POSIX API targeting embedded kernels, with core kernel features such as:
  - Threads with round-robin or strict priority scheduling.
  - Synchronization services: semaphores and mutex locks.
  - IPC services: message queues and shared memory.
  - Dynamic buffer pool memory allocation.
  - Software timers.
  - User-level interrupt handling.
- Static thread creation that startup with the kernel.

- System call interface to the kernel.
- Exception handling for the MicroBlaze processor.
- Memory protection using MicroBlaze Memory Management (Protection) Unit (MMU) features when available.

## Additional Resources

- Xilkernel-based example designs:  
[http://www.xilinx.com/ise/embedded/edk\\_examples.htm](http://www.xilinx.com/ise/embedded/edk_examples.htm)

## Xilkernel Organization

The kernel is highly modular in design. You can select and customize the kernel modules that are needed for the application at hand. Customizing the kernel is discussed in detail in “[Kernel Customization](#),” page 43<sup>(1)</sup>. [Figure 1](#) shows the various modules of Xilkernel:




Figure 1: Xilkernel Modules

## Building Xilkernel Applications

Xilkernel is organized in the form of a library of kernel functions. This leads to a simple model of kernel linkage. To build Xilkernel, you must include Xilkernel in your software platform, configure it appropriately, and run Libgen to generate the Xilkernel library. Your application sources can be edited and developed separately. After you have developed your application, you must link with the Xilkernel library, thus pulling in all the kernel functionality to build the final kernel image. The Xilkernel library is generated as `libxilkernel.a`. [Figure 2](#), page 3 shows this development flow.


Internally, Xilkernel also supports the much more powerful, traditional OS-like method of linkage and separate executables. Conventional operating systems have the kernel image as a separate file and each application that executes on the kernel as a separate file. However, Xilinx recommends that you use the more simple and more elegant library linkage mode. This mode provides maximum ease of use. It is also the preferred mode for debugging, downloading, and bootloading. The separate executable mode is required only by those who have advanced requirements in the form of separate executables. The separate executable mode and its caveats are documented in “[Deprecated Features](#),” page 51.

The following are the steps for the kernel linkage mode of application development:

1. Some of these features might not be fully supported in a given release of Xilkernel.

1. Application source C files should include the file `xmk.h` as the first file among others. For example, defining the `includexmk.h` flag makes available certain definitions and declarations from the GNU include files that are required by Xilkernel and applications.
2. Your application software project links with the library `libxil.a`. This library contains the actual kernel functions generated. Your application links with this and forms the final kernel and application image.
3. Xilkernel is responsible for all first level interrupt and exception handling on both the MicroBlaze and PowerPC processors. Therefore, you should not directly attempt to use any of the methods of handling interrupts documented for standalone programs. Instead refer to the section on interrupt handling for how to handle user level interrupts and exceptions.
4. You can control the memory map of the kernel by using the linker script feature of the final software application project that links with the kernel. Automatic linker script generation helps you here.
5. Your application must provide a `main( )` which is the starting point of execution for your kernel image. Inside your `main( )`, you can do any initialization and setup that you need to do. The kernel remains unstarted and dormant. At the point where your application setup is complete and you want the kernel to start, you must invoke `xilkernel_main( )` that starts off the kernel, enables interrupts, and transfers control to your application processes, as configured. Some system-level features may need to be enabled before invoking `xilkernel_main( )`. These are typically machine-state features such as cache enablement, hardware exception enablement which must be “always ON” even when context switching from application to application. Make sure that you setup such system state before invoking `xilkernel_main( )`. Also, you must not arbitrarily modify such system-state in your application threads. If a context switch occurs when the system state is modified, it could lead to subsequent threads executing without that state being enabled; consequently, you must lock out context switches and interrupts before you modify such a state.

**Note:** Your linker script must be aware of the requirements for the kernel. For example, on PowerPC 405 systems, there is a `.vectors` section that contains all first level exception handling code. Your final linker script must make sure that this section receives proper memory assignment.



X10128

Figure 2: Xilkernel Development Flow

## Xilkernel Process Model

The units of execution within Xilkernel are called *process contexts*. Scheduling is done at the process context level. There is no concept of thread groups combining to form, what is conventionally called a process. Instead, all the threads are peers and compete equally for resources. The POSIX threads API is the primary user-visible interface to these process contexts. There are a few other useful additional interfaces provided, that are not a part of POSIX. The interfaces allow creating, destroying, and manipulating created application threads. The actual interfaces are described in detail in “Xilkernel API,” page 6. Threads are manipulated with thread identifiers. The underlying process context is identified with a process identifier *pid\_t*.

## Xilkernel Scheduling Model


Xilkernel supports either priority-driven, preemptive scheduling with time slicing (`SCHED_PRIO`) or simple round-robin scheduling (`SCHED_RR`). This is a global scheduling policy and cannot be changed on a per-thread basis. This must be configured statically at kernel generation time.

In `SCHED_RR`, there is a single ready queue and each process context executes for a configured time slice before yielding execution to the next process context in the queue.

In `SCHED_PRIO` there are as many ready queues as there are priority levels. Priority 0 is the highest priority in the system and higher values mean lower priority.

As shown in the following figure, the process that is at the head of the highest priority ready queue is always scheduled to execute next. Within the same priority level, scheduling is round-robin and time-sliced. If a ready queue level is empty, it is skipped and the next ready queue level examined for schedulable processes. Blocked processes are off their ready queues and in their appropriate wait queues. The number of priority levels can be configured for `SCHED_PRIO`.

For both the scheduling models, the length of the ready queue can also be configured. If there are wait queues inside the kernel (in semaphores, message queues), they are configured as priority queues if scheduling mode is `SCHED_PRIO`. Otherwise, they are configured as simple first-in-first-out (FIFO) queues.



X10132


Figure 3: Priority-Driven Scheduling



Each process context is in any of the following six states:

- `PROC_NEW` - A newly created process.
- `PROC_READY` - A process ready to execute.
- `PROC_RUN` - A process that is running.
- `PROC_WAIT` - A process that is blocked on a resource.
- `PROC_DELAY` - A process that is waiting for a timeout.
- `PROC_TIMED_WAIT` - A process that is blocked on a resource and has an associated timeout.

When a process terminates, it enters a dead state called `PROC_DEAD`. The process context state diagram is shown in the following figure.



X10227

Figure 4: Process Context States

## POSIX Interface

Xilkernel provides a POSIX interface to the kernel. Not all the concepts and interfaces defined by POSIX are available. A subset covering the most useful interfaces and concepts are implemented. Xilkernel programs can run almost equivalently on your desktop OS, like Linux or SunOS. This makes for easy application development, portability and legacy software support. The programming model appeals to those who have worked on equivalent POSIX interfaces on traditional operating systems. For those interfaces that have been provided, POSIX is rigorously adhered to in almost all cases. For cases that do differ, the differences are clearly specified. Refer to “[Xilkernel API](#)”, for the actual interfaces and their descriptions.

## Xilkernel Functions

Click an item below view function summaries and descriptions for:

- [Thread Management](#)
- [Semaphores](#)
- [Message Queues](#)
- [Shared Memory](#)
- [Mutex Locks](#)
- [Dynamic Buffer Memory Management](#)
- [Software Timers](#)
- [Memory Protection Overview](#)

## Xilkernel API

### Thread Management

Xilkernel supports the basic POSIX threads API. Thread creation and manipulation is done in standard POSIX notation. Threads are identified by a unique thread identifier. The thread identifier is of type `pthread_t`. This thread identifier uniquely identifies a thread for an operation. Threads created in the system have a kernel wrapper to which they return control to when they terminate. So, a specific exit function is not required at the end of the thread's code.

Thread stack is allocated automatically on behalf of the thread from a pool of Block Starting Symbol (BSS) memory that is statically allocated based upon the maximum number of system threads. You can also assign a custom piece of memory as the stack for each thread to create dynamically.

The entire thread module is optional and can be configured in or out as a part of the software specification. See “[Configuring Thread Management](#),” [page 45](#) for more details on customizing this module.

## Thread Management Function Summary

The following list is a linked summary of the thread management functions in Xilkernel. Click on a function to view a detailed description.

```
int pthread_create(pthread_t thread, pthread_attr_t* attr, void*(*start_func)(void*),void*
param)
void pthread_exit(void *value_ptr)
int pthread_join(pthread_t thread, void **value_ptr)
int pthread_detach(pthread_t target)
int pthread_equal(pthread_t t1, pthread_t t2)
int pthread_getschedparam(pthread_t thread, int *policy, struct sched_param *param)
int pthread_setschedparam(pthread_t thread, int policy, const struct sched_param *param)
int pthread_attr_init(pthread_attr_t* attr)
int pthread_attr_destroy (pthread_attr_t* attr)
int pthread_attr_setdetachstate(pthread_attr_t* attr, int dstate)
int pthread_attr_getdetachstate(pthread_attr_t* attr, int *dstate)
int pthread_attr_setschedparam(pthread_attr_t* attr, struct sched_param *schedpar)
int pthread_attr_getschedparam(pthread_attr_t* attr, struct sched_param* schedpar)
int pthread_attr_setstack(const pthread_attr_t *attr, void *stackaddr, size_t stacksize)
int pthread_attr_getstack(const pthread_attr_t *attr, void **stackaddr, size_t *stacksize)
pid_t get_currentPID(void)
int kill(pid_tpid)
int process_status(pid_t pid, p_stat *ps)
int xmk_add_static_thread(void* (*start_routine)(void *), int sched_priority)
int yield(void)
```

## Thread Management Function Descriptions

The following descriptions are the thread management interface identifiers.

---

```
int pthread_create(pthread_t thread, pthread_attr_t* attr,
    void* (*start_func)(void*), void* param)
```

Parameters	<p><i>thread</i> is the location at which to store the created thread's identifier.</p> <p><i>attr</i> is the pointer to thread creation attributes structure.</p> <p><i>start_func</i> is the start address of the function from which the thread needs to execute.</p> <p><i>param</i> is the pointer argument to the thread function.</p>
Returns	<p>0 and thread identifier of the created thread in <i>*thread</i>, on success.</p> <p>-1 if <i>thread</i> refers to an invalid location.</p> <p>EINVAL if <i>attr</i> refers to invalid attributes.</p> <p>EAGAIN if resources unavailable to create the thread.</p>
Description	<p><code>pthread_create( )</code> creates a new thread, with attributes specified by <i>attr</i>, within a process. If <i>attr</i> is NULL, the default attributes are used. If the attributes specified by <i>attr</i> are modified later, the thread's attributes are not affected. Upon successful completion, <code>pthread_create( )</code> stores the ID of the created thread in the location referenced by <i>thread</i>. The thread is created executing <i>start_routine</i> with <i>arg</i> as its sole argument. If the <i>start_routine</i> returns, the effect is as if there was an implicit call to <code>pthread_exit( )</code> using the return value of <i>start_routine</i> as the exit status. This is explained in the <code>pthread_exit</code> description.</p> <p>You can control various attributes of a thread during its creation. See the <code>pthread_attr</code> routines for a description of the kinds of thread creation attributes that you can control.</p>
Includes	<code>xmk.h</code> , <code>pthread.h</code>

---

```
void pthread_exit(void *value_ptr)
```

Parameters	<i>value_ptr</i> is a pointer to the return value of the thread.
Returns	None.
Description	<p>The <code>pthread_exit( )</code> function terminates the calling thread and makes the value <i>value_ptr</i> available to any successful join with the terminating thread. Thread termination releases process context resources including, but not limited to, memory and attributes. An implicit call to <code>pthread_exit( )</code> is made when a thread returns from the creating start routine. The return value of the function serves as the thread's exit status. Therefore no explicit <code>pthread_exit( )</code> is required at the end of a thread.</p>
Includes	<code>xmk.h</code> , <code>pthread.h</code>

---

```
int pthread_join(pthread_t thread, void **value_ptr)
```

Parameters     *value\_ptr* is a pointer to the return value of the thread.

Returns        0 on success.

ESRCH if the target thread is not in a joinable state or is an invalid thread.

EINVAL if the target thread already has someone waiting to join with it.

Description    The `pthread_join( )` function suspends execution of the calling thread until the `pthread_t` (target thread) terminates, unless the target thread has already terminated. Upon return from a successful `pthread_join( )` call with a non-NULL *value\_ptr* argument, the value passed to the `pthread_exit( )` function by the terminating thread is made available in the location referenced by *value\_ptr*. When a `pthread_join( )` returns successfully, the target thread has been terminated. The results of multiple simultaneous calls to `pthread_join( )` specifying the same target thread are that only one thread succeeds and the others fail with `EINVAL`.

**Note:** No deadlock detection is provided.

Includes        `xmk.h`, `pthread.h`

---

```
pthread_t pthread_self(void)
```

Parameters     None.

Returns        On success, returns thread identifier of current thread.

Error behavior not defined.

Description    The `pthread_self( )` function returns the thread ID of the calling thread.

Includes        `xmk.h`, `pthread.h`

---

```
int pthread_detach(pthread_t target)
```

Parameters     *target* is the target thread to detach.

Returns        0 on success.

ESRCH if target thread cannot be found.

Description    The `pthread_detach( )` function indicates to the implementation that storage for the *thread* can be reclaimed when that thread terminates. If thread has not terminated, `pthread_detach( )` does not cause it to terminate. The effect of multiple `pthread_detach( )` calls on the same target thread is unspecified.

Includes        `xmk.h`, `pthread.h`

---

```
int pthread_equal(pthread_t t1, pthread_t t2)
```

Parameters     *t1* and *t2* are the two thread identifiers to compare.

Returns        1 if *t1* and *t2* refer to threads that are equal.

0 otherwise.

Description    The `pthread_equal( )` function returns a non-zero value if *t1* and *t2* are equal; otherwise, zero is returned. If either *t1* or *t2* are not valid thread IDs, zero is returned.

Includes        `xmk.h`, `pthread.h`

---

```
int pthread_getschedparam(pthread_t thread, int *policy,
    struct sched_param *param)
```

Parameters	<p><i>thread</i> is the identifier of the thread on which to perform the operation.</p> <p><i>policy</i> is a pointer to the location where the global scheduling policy is stored.</p> <p><i>param</i> is a pointer to the scheduling parameters structure.</p>
Returns	<p>0 on success.</p> <p>ESRCH if the value specified by thread does not refer to an existing thread.</p> <p>EINVAL if param or policy refer to invalid memory.</p>
Description	<p>The <code>pthread_getschedparam( )</code> function gets the scheduling policy and parameters of an individual thread. For <code>SCHED_RR</code> there are no scheduling parameters; consequently, this routine is not defined for <code>SCHED_RR</code>.</p> <p>For <code>SCHED_PRIO</code>, the only required member of the <code>sched_param</code> structure is the priority <i>sched_priority</i>. The returned priority value is the value specified by the most recent <code>pthread_getschedparam( )</code> or <code>pthread_create( )</code> call affecting the target thread.</p> <p>It does not reflect any temporary adjustments to its priority as a result of any priority inheritance or ceiling functions.</p> <p>This routine is defined only if scheduling type is <code>SCHED_PRIO</code>.</p>
Returns	<code>xmk.h</code> , <code>pthread.h</code>

```
int pthread_setschedparam(pthread_t thread, int policy,
    const struct sched_param *param)
```

Parameters	<p><i>thread</i> is the identifier of the thread on which to perform the operation.</p> <p><i>policy</i> is ignored.</p> <p><i>param</i> is a pointer to the scheduling parameters structure.</p>
Returns	<p>0 on success.</p> <p>ESRCH if <i>thread</i> does not refer to a valid thread.</p> <p>EINVAL if the scheduling parameters are invalid.</p>
Description	<p>The <code>pthread_setschedparam( )</code> function sets the scheduling policy and parameters of individual threads to be retrieved. For <code>SCHED_RR</code> there are no scheduling parameters; consequently this routine is not defined for <code>SCHED_RR</code>.</p> <p>For <code>SCHED_PRIO</code>, the only required member of the <code>sched_param</code> structure is the priority <i>sched_priority</i>. The priority value must be a valid value as configured in the scheduling parameters of the kernel. The policy parameter is ignored.</p> <p><b>Note:</b> This routine is defined only if scheduling type is <code>SCHED_PRIO</code>.</p>
Includes	<code>xmk.h</code> , <code>pthread.h</code>

```
int pthread_attr_init(pthread_attr_t* attr)
```

Parameters *attr* is a pointer to the attribute structure to be initialized.

Returns 0 on success.  
1 on failure.  
EINVAL on invalid *attr* parameter.

Description The `pthread_attr_init( )` function initializes a thread attributes object *attr* with the default value for all of the individual attributes used by a given implementation. The function contents are defined in the `sys/types.h` header.

**Note:** This function does not make a call to the kernel.

Includes `xmk.h`, `pthread.h`

---

```
int pthread_attr_destroy (pthread_attr_t* attr)
```

Parameters *attr* is a pointer to the thread attributes that must be destroyed.

Returns 0 on success.  
EINVAL on errors.

Description The `pthread_attr_destroy( )` function destroys a thread attributes object and sets *attr* to an implementation-defined invalid value.  
Re-initialize a destroyed *attr* attributes object with `pthread_attr_init( )`; the results of otherwise referencing the object after it is destroyed are undefined.

**Note:** This function does not make a call to the kernel.

Includes `xmk.h`, `pthread.h`

---

```
int pthread_attr_setdetachstate(pthread_attr_t* attr, int dstate)
```

Parameters *attr* is the attribute structure on which the operation is to be performed.  
*dstate* is the detachstate required.

Returns 0 on success.  
EINVAL on invalid parameters.

Description The detachstate attribute controls whether the thread is created in a detached state. If the thread is created detached, then when the thread exits, the thread's resources are detached without requiring a `pthread_join( )` or a call `pthread_detach( )`. The application can set detachstate to either `PTHREAD_CREATE_DETACHED` or `PTHREAD_CREATE_JOINABLE`.

**Note:** This does not make a call into the kernel.

Includes `xmk.h`, `pthread.h`

```
int pthread_attr_getdetachstate(pthread_attr_t* attr, int
*dstate)
```

Parameters	<i>attr</i> is the attribute structure on which the operation is to be performed. <i>dstate</i> is the location in which to store the detachstate.
Returns	0 on success. EINVAL on invalid parameters.
Description	The implementation stores either PTHREAD_CREATE_DETACHED or PTHREAD_CREATE_JOINABLE in <i>dstate</i> , if the value of detachstate was valid in <i>attr</i> . <b>Note:</b> This does not make a call into the kernel.
Includes	xmk.h, pthread.h

```
int pthread_attr_setschedparam(pthread_attr_t* attr,
struct sched_param *schedpar)
```

Parameters	<i>attr</i> is the attribute structure on which the operation is to be performed. <i>schedpar</i> is the location of the structure that contains the scheduling parameters.
Returns	0 on success. EINVAL on invalid parameters. ENOTSUP for invalid scheduling parameters.
Description	The pthread_attr_setschedparam( ) function sets the scheduling parameter attributes in the <i>attr</i> argument. The contents of the <i>sched_param</i> structure are defined in the sched.h header. <b>Note:</b> This does not make a call into the kernel.
Includes	xmk.h, pthread.h

```
int pthread_attr_getschedparam(pthread_attr_t* attr,
struct sched_param* schedpar)
```

Parameters	<i>attr</i> is the attribute structure on which the operation is to be performed. <i>schedpar</i> is the location at which to store the <i>sched_param</i> structure.
Returns	0 on success. EINVAL on invalid parameters.
Description	The pthread_attr_getschedparam( ) gets the scheduling parameter attributes in the <i>attr</i> argument. The contents of the <i>param</i> structure are defined in the sched.h header. <b>Note:</b> This does not make a call to the kernel.
Includes	xmk.h, pthread.h



```
int pthread_attr_setstack(const pthread_attr_t *attr, void
    *stackaddr, size_t stacksize)
```

Parameters	<p><i>attr</i> is the attributes structure on which to perform the operation.</p> <p><i>stackaddr</i> is base address of the stack memory.</p> <p><i>stacksize</i> is the size of the memory block in bytes.</p>
Returns	<p>0 on success.</p> <p>EINVAL if the <i>attr</i> param is invalid or if <i>stackaddr</i> is not aligned appropriately.</p>
Description	<p>The <code>pthread_attr_setstack( )</code> function shall set the thread creation stack attributes <i>stackaddr</i> and <i>stacksize</i> in the <i>attr</i> object.</p> <p>The stack attributes specify the area of storage to be used for the created thread's stack. The base (lowest addressable byte) of the storage is <i>stackaddr</i>, and the size of the storage is <i>stacksize</i> bytes.</p> <p>The <i>stackaddr</i> must be aligned appropriately according to the processor EABI, to be used as a stack; for example, <code>pthread_attr_setstack( )</code> might fail with EINVAL if (<i>stackaddr</i> and 0x3) is not 0.</p> <p>For PowerPC 405 processors, the alignment required is 8 bytes.</p> <p><b>Note:</b> For the MicroBlaze processor, the alignment required is 4 bytes.</p>
Includes	xmk.h, pthread.h

---

```
int pthread_attr_getstack(const pthread_attr_t *attr, void
    **stackaddr, size_t *stacksize)
```

Parameters	<p><i>attr</i> is the attributes structure on which to perform the operation.</p> <p><i>stackaddr</i> is the location at which to store the base address of the stack memory.</p> <p><i>stacksize</i> is the location at which to store the size of the memory block in bytes.</p>
Returns	<p>0 on success.</p> <p>EINVAL on invalid <i>attr</i>.</p>
Description	<p>The <code>pthread_attr_getstack( )</code> function retrieves the thread creation attributes related to stack of the specified attributes structure and stores it in <i>stackaddr</i> and <i>stacksize</i>.</p>
Includes	xmk.h, pthread.h

---

```
pid_t get_currentPID(void)
```

Parameters	None.
Returns	The process identifier associated with the current thread or elf process.
Description	Gets the underlying process identifier of the process context that is executing currently. The process identifier is needed to perform certain operations like <code>kill( )</code> on both processes and threads.
Includes	xmk.h, sys/process.h

```
int kill(pid_t pid)
```

Parameters	<i>pid</i> is the PID of the process.
Returns	0 on success. -1 on failure.
Description	Removes the process context specified by <i>pid</i> from the system. If <i>pid</i> refers to the current executing process context, then it is equivalent to the current process context terminating. A kill can be invoked on processes that are suspended on wait queues or on a timeout. No indication is given to other processes that are dependant on this process context.  <b>Note:</b> This function is defined only if CONFIG_KILL is true. This can be configured in with the enhanced features category of the kernel.
Includes	xmk.h, sys/process.h

```
int process_status(pid_t pid, p_stat *ps)
```

Parameters	<i>pid</i> is the PID of process. <i>ps</i> is the buffer where the process status is returned.
Returns	Process status in <i>ps</i> on success. NULL in <i>ps</i> on failure.
Description	Get the status of the process or thread, whose pid is <i>pid</i> . The status is returned in structure <i>p_stat</i> which has the following fields: <ul style="list-style-type: none"> <li>• <i>pid</i> is the process ID.</li> <li>• <i>state</i> is the current scheduling state of the process.</li> </ul> The contents of <i>p_stat</i> are defined in the <i>sys/ktypes.h</i> header.
Includes	xmk.h, sys/process.h

```
int xmk_add_static_thread(void* (*start_routine)(void *),  
int sched_priority)
```

Parameters	<i>start_routine</i> is the thread start routine. <i>sched_priority</i> is the priority of the thread when the kernel is configured for priority scheduling.
Returns	0 on success and -1 on failure.
Description	This function provides the ability to add a thread to the list of startup or static threads that run on kernel start, via C code. This function must be used prior to <i>xilkernel_main()</i> being invoked.
Includes	xmk.h, sys/init.h

```
int yield(void)
```

Parameters      None.

Returns          None.

Description      Yields the processor to the next process context that is ready to execute. The current process is put back in the appropriate ready queue.

**Note:** This function is optional and included only if `CONFIG_YIELD` is defined. This can be configured in with the enhanced features category of the kernel.

Includes          `xmk.h`, `sys/process.h`

## Semaphores

Xilkernel supports kernel-allocated POSIX semaphores that can be used for synchronization. POSIX semaphores are counting semaphores that also count below zero (a negative value indicates the number of processes blocked on the semaphore). Xilkernel also supports a few interfaces for working with named semaphores. The number of semaphores allocated in the kernel and the length of semaphore wait queues can be configured during system initialization. Refer to “[Configuring Semaphores](#),” page 46 for more details. The semaphore module is optional and can be configured in or out during system initialization. The message queue module, described later on in this document, uses semaphores. This module must be included if you are to use message queues.

### Semaphore Function Summary

The following list provides a linked summary of the semaphore functions in Xilkernel. You can click on a function to go to the description.

[int sem\\_init\(sem\\_t \\*sem, int pshared, unsigned value\)](#)

[int sem\\_destroy\(sem\\_t\\* sem\)](#)

[int sem\\_getvalue\(sem\\_t\\* sem, int\\* value\)](#)

[int sem\\_wait\(sem\\_t\\* sem\)](#)

[int sem\\_trywait\(sem\\_t\\* sem\)](#)

[int sem\\_timedwait\(sem\\_t\\* sem, unsigned\\_ms\)](#)

[sem\\_t\\* sem\\_open\(const char\\* name, int oflag,...\)](#)

[int sem\\_close\(sem\\_t\\* sem\)](#)

[int sem\\_post\(sem\\_t\\* sem\)](#)

[int sem\\_unlink\(const char\\* name\)](#)

## Semaphore Function Descriptions

The following are descriptions of the Xilkernel semaphore functions:

---

```
int sem_init(sem_t *sem, int pshared, unsigned value)
```

Parameters	<p><i>sem</i> is the location at which to store the created semaphore's identifier.</p> <p><i>pshared</i> indicates sharing status of the semaphore, between processes.</p> <p><i>value</i> is the initial count of the semaphore.</p> <p><b>Note:</b> <i>pshared</i> is unused currently.</p>
Returns	<p>0 on success.</p> <p>-1 on failure and sets <code>errno</code> appropriately. The <code>errno</code> is set to <code>ENOSPC</code> if no more semaphore resources are available in the system.</p>
Description	<p>The <code>sem_init( )</code> function initializes the unnamed semaphore referred to by <i>sem</i>. The value of the initialized semaphore is <i>value</i>. Following a successful call to <code>sem_init( )</code>, the semaphore can be used in subsequent calls to <code>sem_wait( )</code>, <code>sem_trywait( )</code>, <code>sem_post( )</code>, and <code>sem_destroy( )</code>. This semaphore remains usable until the semaphore is destroyed. Only <i>sem</i> itself can be used for performing synchronization. The result of referring to copies of <i>sem</i> in calls to <code>sem_wait( )</code>, <code>sem_trywait( )</code>, <code>sem_post( )</code>, and <code>sem_destroy( )</code> is undefined. Attempting to initialize an already initialized semaphore results in undefined behavior.</p>
Includes	<code>xmk.h</code> , <code>semaphore.h</code>

---

```
int sem_destroy(sem_t* sem)
```

Parameters	<i>sem</i> is the semaphore to be destroyed.
Returns	<p>0 on success.</p> <p>-1 on failure and sets <code>errno</code> appropriately. The <code>errno</code> can be set to:</p> <ul style="list-style-type: none"> <li>• <code>EINVAL</code> if the semaphore identifier does not refer to a valid semaphore.</li> <li>• <code>EBUSY</code> if the semaphore is currently locked, and processes are blocked on it.</li> </ul>
Description	<p>The <code>sem_destroy( )</code> function destroys the unnamed semaphore indicated by <i>sem</i>. Only a semaphore that was created using <code>sem_init( )</code> can be destroyed using <code>sem_destroy( )</code>; the effect of calling <code>sem_destroy( )</code> with a named semaphore is undefined. The effect of subsequent use of the semaphore <i>sem</i> is undefined until <i>sem</i> is re-initialized by another call to <code>sem_init( )</code>.</p>
Includes	<code>xmk.h</code> , <code>semaphore.h</code>

---

```
int sem_getvalue(sem_t* sem, int* value)
```

Parameters	<p><i>sem</i> is the semaphore identifier.</p> <p><i>value</i> is the location where the semaphore value is stored.</p>
Returns	<p>0 on success and <i>value</i> appropriately filled in.</p> <p>-1 on failure and sets <i>errno</i> appropriately. The <i>errno</i> can be set to <code>EINVAL</code> if the semaphore identifier refers to an invalid semaphore.</p>
Description	<p>The <code>sem_getvalue( )</code> function updates the location referenced by the <i>sval</i> argument to have the value of the semaphore referenced by <i>sem</i> without affecting the state of the semaphore. The updated value represents an actual semaphore value that occurred at some unspecified time during the call, but it need not be the actual value of the semaphore when it is returned to the calling process.</p> <p>If <i>sem</i> is locked, then the object to which <i>sval</i> points is set to a negative number whose absolute value represents the number of processes waiting for the semaphore at some unspecified time during the call.</p>
Includes	<code>xmk.h</code> , <code>semaphore.h</code>

---

```
int sem_wait(sem_t* sem)
```

Parameters	<i>sem</i> is the semaphore identifier.
Returns	<p>0 on success and the semaphore in a locked state.</p> <p>-1 on failure and <i>errno</i> is set appropriately. The <i>errno</i> can be set to:</p> <ul style="list-style-type: none"> <li>• <code>EINVAL</code> if the semaphore identifier is invalid.</li> <li>• <code>EIDRM</code> if the semaphore was forcibly removed.</li> </ul>
Description	<p>The <code>sem_wait( )</code> function locks the semaphore referenced by <i>sem</i> by performing a semaphore lock operation on that semaphore. If the semaphore value is currently zero, then the calling thread does not return from the call to <code>sem_wait( )</code> until it either locks the semaphore or the semaphore is forcibly destroyed.</p> <p>Upon successful return, the state of the semaphore is locked and remains locked until the <code>sem_post( )</code> function is executed and returns successfully.</p> <p><b>Note:</b> When a process is unblocked within the <code>sem_wait</code> call, where it blocked due to unavailability of the semaphore, the semaphore might have been destroyed forcibly. In such a case, -1 is returned. Semaphores might be forcibly destroyed due to destroying message queues that use semaphores internally. No deadlock detection is provided.</p>
Includes	<code>xmk.h</code> , <code>semaphore.h</code>

---

```
int sem_trywait(sem_t* sem)
```

Parameters	<i>sem</i> is the semaphore identifier.
Returns	<p>0 on success.</p> <p>-1 on failure and <i>errno</i> is set appropriately. The <i>errno</i> can be set to:</p> <ul style="list-style-type: none"> <li>• <code>EINVAL</code> if the semaphore identifier is invalid.</li> <li>• <code>EAGAIN</code> if the semaphore could not be locked immediately.</li> </ul>
Description	<p>The <code>sem_trywait( )</code> function locks the semaphore referenced by <i>sem</i> only if the semaphore is currently not locked; that is, if the semaphore value is currently positive. Otherwise, it does not lock the semaphore and returns -1.</p>
Includes	<code>xmk.h</code> , <code>semaphore.h</code>

---

```
int sem_timedwait(sem_t* sem, unsigned ms)
```

Parameters     *sem* is the semaphore identifier.

Returns        0 on success and the semaphore in a locked state.  
                -1 on failure and *errno* is set appropriately. The *errno* can be set to:

- **EINVAL** - If the semaphore identifier does not refer to a valid semaphore.
- **ETIMEDOUT** - The semaphore could not be locked before the specified timeout expired.
- **EIDRM** - If the semaphore was forcibly removed from the system.

Description    The `sem_timedwait( )` function locks the semaphore referenced by *sem* by performing a semaphore lock operation on that semaphore. If the semaphore value is currently zero, then the calling thread does not return from the call to `sem_timedwait( )` until one of the following conditions occurs:

- It locks the semaphore.
- The semaphore is forcibly destroyed.
- The timeout specified has elapsed.

Upon successful return, the state of the semaphore is locked and remains locked until the `sem_post( )` function is executed and returns successfully.

**Note:** When a process is unblocked within the `sem_wait` call, where it blocked due to unavailability of the semaphore, the semaphore might have been destroyed forcibly. In such a case, -1 is returned. Semaphores may be forcibly destroyed due to destroying message queues which internally use semaphores. No deadlock detection is provided.

**Note:** This routine depends on software timers support being present in the kernel and is defined only if `CONFIG_TIME` is true.

**Note:** This routine is slightly different from the POSIX equivalent. The POSIX version specifies the timeout as absolute wall-clock time. Because there is no concept of absolute time in Xilkernel, we use relative time specified in milliseconds.

Includes        `xmk.h`, `semaphore.h`

```
sem_t* sem_open(const char* name, int oflag, ...)
```

Parameters     *name* points to a string naming a semaphore object.

*oflag* is the flag that controls the semaphore creation.

Returns        A pointer to the created/existing semaphore identifier.

SEM\_FAILED on failures and when *errno* is set appropriately. The *errno* can be set to:

- ENOSPC - If the system is out of resources to create a new semaphore (or mapping).
- EEXIST - if O\_EXCL has been requested and the named semaphore already exists.
- EINVAL - if the parameters are invalid.

Description

The `sem_open( )` function establishes a connection between a named semaphore and a process. Following a call to `sem_open( )` with semaphore *name*, the process can reference the semaphore associated with *name* using the address returned from the call. This semaphore can be used in subsequent calls to `sem_wait( )`, `sem_trywait( )`, `sem_post( )`, and `sem_close( )`. The semaphore remains usable by this process until the semaphore is closed by a successful call to `sem_close( )`. The *oflag* argument controls whether the semaphore is created or merely accessed by the call to `sem_open( )`. The bits that can be set in *oflag* are:

◆ O\_CREAT

Used to create a semaphore if it does not already exist. If O\_CREAT is set and the semaphore already exists, then O\_CREAT has no effect, except as noted under O\_EXCL. Otherwise, `sem_open( )` creates a named semaphore. O\_CREAT requires a third and a fourth argument: *mode*, which is of type `mode_t`, and *value*, which is of type `unsigned`.

◆ O\_EXCL

If O\_EXCL and O\_CREAT are set, `sem_open( )` fails if the semaphore name exists. The check for the existence of the semaphore and the creation of the semaphore if it does not exist are atomic with respect to other processes executing `sem_open( )` with O\_EXCL and O\_CREAT set. If O\_EXCL is set and O\_CREAT is not set, the effect is undefined.

**Note:** The *mode* argument is unused currently. This interface is optional and is defined only if CONFIG\_NAMED\_SEMA is set to TRUE.

**Note:** If flags other than O\_CREAT and O\_EXCL are specified in the *oflag* parameter, an error is signalled.

The semaphore is created with an initial value of *value*.

After the *name* semaphore has been created by `sem_open( )` with the O\_CREAT flag, other processes can connect to the semaphore by calling `sem_open( )` with the same value of *name*.

If a process makes multiple successful calls to `sem_open( )` with the same value for *name*, the same semaphore address is returned for each such successful call, assuming that there have been no calls to `sem_unlink( )` for this semaphore.

Includes        `xmk.h`, `semaphore.h`

```
int sem_close(sem_t* sem)
```

Parameters     *sem* is the semaphore identifier.

Returns        0 on success.

-1 on failure and sets *errno* appropriately. The *errno* can be set to:

- EINVAL - If the semaphore identifier is invalid.
- ENOTSUP - If the semaphore is currently locked and/or processes are blocked on the semaphore.

Description	<p>The <code>sem_close( )</code> function indicates that the calling process is finished using the named semaphore <code>sem</code>. The <code>sem_close( )</code> function deallocates (that is, make available for reuse by a subsequent <code>sem_open( )</code> by this process) any system resources allocated by the system for use by this process for this semaphore. The effect of subsequent use of the semaphore indicated by <code>sem</code> by this process is undefined. The name mapping for this named semaphore is also destroyed. The call fails if the semaphore is currently locked.</p> <p><b>Note:</b> This interface is optional and is defined only if <code>CONFIG_NAMED_SEMA</code> is true.</p>
Includes	<code>xmk.h</code> , <code>semaphore.h</code>

```
int sem_post(sem_t* sem)
```

Parameters	<code>sem</code> is the semaphore identifier.
Returns	<p>0 on success.</p> <p>-1 on failure and sets <code>errno</code> appropriately. The <code>errno</code> can be set to <code>EINVAL</code> if the semaphore identifier is invalid.</p>
Description	<p>The <code>sem_post( )</code> function performs an unlock operation on the semaphore referenced by the <code>sem</code> identifier.</p> <p>If the semaphore value resulting from this operation is positive, then no threads were blocked waiting for the semaphore to become unlocked and the semaphore value is incremented.</p> <p>If the value of the semaphore resulting from this operation is zero or negative, then one of the threads blocked waiting for the semaphore is allowed to return successfully from its call to <code>sem_wait( )</code>. This is either the first thread on the queue, if scheduling mode is <code>SCHED_RR</code> or, it is the highest priority thread in the queue, if scheduling mode is <code>SCHED_PRIO</code>.</p> <p><b>Note:</b> If an unlink operation was requested on the semaphore, the post operation performs an unlink when no more processes are waiting on the semaphore.</p>
Includes	<code>xmk.h</code> , <code>semaphore.h</code>



```
int sem_unlink(const char* name)
```

Parameters     *name* is the name that refers to the semaphore.

Returns        0 on success.

-1 on failure and *errno* is set appropriately. *errno* can be set to `ENOENT` - If an entry for name cannot be located.

Description    The `sem_unlink( )` function removes the semaphore named by the string name. If the semaphore named by *name* has processes blocked on it, then `sem_unlink( )` has no immediate effect on the state of the semaphore. The destruction of the semaphore is postponed until all blocked and locking processes relinquish the semaphore. Calls to `sem_open( )` to recreate or reconnect to the semaphore refer to a new semaphore after `sem_unlink( )` is called. The `sem_unlink( )` call does not block until all references relinquish the semaphore; it returns immediately.

**Note:** If an unlink operation had been requested on the semaphore, the unlink is performed on a post operation that sees that no more processes waiting on the semaphore. This interface is optional and is defined only if `CONFIG_NAMED_SEMA` is true.

Includes        `xmk.h`, `semaphore.h`

## Message Queues

Xilkernel supports kernel allocated X/Open System Interface (XSI) message queues. XSI is a set of optional interfaces under POSIX. Message queues can be used as an IPC mechanism. The message queues can take in arbitrary sized messages. However, buffer memory allocation must be configured appropriately for the memory blocks required for the messages, as a part of system buffer memory allocation initialization. The number of message queue structures allocated in the kernel and the length of the message queues can be also be configured during system initialization. The message queue module is optional and can be configured in/out. Refer to “[Configuring Message Queues](#),” page 46 for more details. This module depends on the semaphore module and the dynamic buffer memory allocation module being present in the system. There is also a larger, but more powerful message queue functionality that can be configured if required. When the enhanced message queue interface is chosen, then *malloc* and *free* are used to allocate and free space for the messages. Therefore, arbitrary sized messages can be passed around without having to make sure that buffer memory allocation APIs can handle requests for arbitrary size.

**Note:** When using the enhanced message queue feature, you must choose your global heap size carefully, such that requests for heap memory from the message queue interfaces are satisfied without errors. You must also be aware of thread-safety issues when using `malloc( )`, `free( )` in your own code. You must disable interrupts and context switches before invoking the dynamic memory allocation routines. You must follow the same rules when using any other library routines that may internally use dynamic memory allocation.

## Message Queue Function Summary

The following list provides a linked summary of the message queues in Xilkernel. You can click on a function to go to the description.

[int msgget\(key\\_t key, int msgflg\)](#)

[int msgctl\(int msqid, int cmd, struct msqid\\_ds\\* buf\)](#)

[int msgsnd\(int msqid, const void \\*msgp, size\\_t msgsz, int msgflg\)](#)

[ssize\\_t msgrcv\(int msqid, void \\*msgp, size\\_t nbytes, long msgtyp, int msgflg\)](#)

## Message Queue Function Descriptions

The Xilkernel message queue function descriptions are as follows:

---

```
int msgget(key_t key, int msgflg)
```

**Parameters**     *key* is a unique identifier for referring to the message queue.  
                   *msgflg* specifies the message queue creation options.

**Returns**        A unique non-negative integer message queue identifier.  
                   -1 on failure and sets *errno* appropriately; *errno* can be set to:

- ◆ EEXIST - If a message queue identifier exists for the argument key but ((*msgflg* and IPC\_CREAT) and *msgflg* & IPC\_EXCL) is non-zero.
- ◆ ENOENT - A message queue identifier does not exist for the argument key and (*msgflg* & IPC\_CREAT) is 0.
- ◆ ENOSPC - If the message queue resources are exhausted.

**Description**    The `msgget ( )` function returns the message queue identifier associated with the argument key. A message queue identifier, associated message queue, and data structure (see `sys/kmsg.h`), are created for the argument key if the argument key does not already have a message queue identifier associated with it, and (*msgflg* and IPC\_CREAT) is non-zero.

Upon creation, the data structure associated with the new message queue identifier is initialized as follows:

- ◆ *msg\_qnum*, *msg\_lspid*, *msg\_lrpid* are set equal to 0.
- ◆ *msg\_qbytes* is set equal to the system limit (MSGQ\_MAX\_BYTES).

The `msgget ( )` function fails if a message queue identifier exists for the argument key but ((*msgflg* and IPC\_CREAT) and (*msgflg* & IPC\_EXCL)) is non-zero.

IPC\_PRIVATE is not supported. Also, messages in the message queue are not required to be of the form shown below. There is no support for message type based message receives and sends in this implementation.

The following is an example code snippet:

```
struct mymsg {
    long mtype; /* Message type. */
    char mtext[some_size]; /* Message text. */
}
```

**Includes**        `xmk.h`, `sys/msg.h`, `sys/ipc.h`

```
int msgctl(int msqid, int cmd, struct msqid_ds* buf)
```

**Parameters**

*msqid* is the message queue identifier.

*cmd* is the command.

*buf* is the data buffer

**Returns**

0 on success. Status is returned in *buf* for `IPC_STAT`.

-1 on failure and sets `errno` appropriately. The `errno` can be set to `EINVAL` if any of the following conditions occur:

- *msqid* parameter refers to an invalid message queue.
- *cmd* is invalid.
- *buf* contains invalid parameters.

**Description**

The `msgctl( )` function provides message control operations as specified by *cmd*. The values for *cmd*, and the message control operations they specify, are:

- `IPC_STAT` - Places the current value of each member of the `msqid_ds` data structure associated with *msqid* into the structure pointed to by *buf*. The contents of this structure are defined in `sys/msg.h`.
- `IPC_SET` - Unsupported.
- `IPC_RMID` - Removes the message queue identifier specified by *msqid* from the system and destroys the message queue and associated `msqid_ds` data structure. The remove operation forcibly destroys the semaphores used internally and unblocks processes that are blocked on the semaphore. It also deallocates memory allocated for the messages in the queue.

**Includes**

`xmk.h`, `sys/msg.h`, `sys/ipc.h`

```
int msgsnd(int msqid, const void *msgp, size_t msgsz, int
           msgflg)
```

Parameters	<p><i>msqid</i> is the message queue identifier.</p> <p><i>msgp</i> is a pointer to the message buffer.</p> <p><i>msgsz</i> is the size of the message.</p> <p><i>msgflg</i> is used to specify message send options.</p>
Returns	<p>0 on success.</p> <p>-1 on failure and sets <i>errno</i> appropriately. The <i>errno</i> can be set to:</p> <ul style="list-style-type: none"> <li>• EINVAL - The value of <i>msqid</i> is not a valid message queue identifier.</li> <li>• ENOSPC - The system could not allocate space for the message.</li> <li>• EIDRM - The message queue was removed from the system during the send operation.</li> </ul>
Description	<p>The <code>msgsnd( )</code> function sends a message to the queue associated with the message queue identifier specified by <i>msqid</i>.</p> <p>The argument <i>msgflg</i> specifies the action to be taken if the message queue is full:</p> <p>If (<i>msgflg</i> and <code>IPC_NOWAIT</code>) is non-zero, the message is not sent and the calling thread returns immediately.</p> <p>If (<i>msgflg</i> and <code>IPC_NOWAIT</code>) is 0, the calling thread suspends execution until one of the following occurs:</p> <ul style="list-style-type: none"> <li>• The condition responsible for the suspension no longer exists, in which case the message is sent.</li> <li>• The message queue identifier <i>msqid</i> is removed from the system; when this occurs a -1 is returned.</li> </ul> <p>The send fails if it is unable to allocate memory to store the message inside the kernel. On a successful send operation, the <i>msg_lspid</i> and <i>msg_qnum</i> members of the message queues are appropriately set.</p>
Includes	<p><code>xmk.h</code>, <code>sys/msg.h</code>, <code>sys/ipc.h</code></p>

```
ssize_t msgrcv(int msqid, void *msgp, size_t nbytes, long
               msgtyp, int msgflg)
```

Parameters	<p><i>msqid</i> is the message queue identifier.</p> <p><i>msgp</i> is the buffer where the received message is to be copied.</p> <p><i>nbytes</i> specifies the size of the message that the buffer can hold.</p> <p><i>msgtyp</i> is currently unsupported.</p> <p><i>msgflg</i> is used to control the message receive operation.</p>
Returns	<p>On success, stores received message in user buffer and returns number of bytes of data received.</p> <p>-1 on failure and sets <i>errno</i> appropriately. The <i>errno</i> can be set to:</p> <ul style="list-style-type: none"> <li>• EINVAL - If <i>msqid</i> is not a valid message queue identifier.</li> <li>• EIDRM - If the message queue was removed from the system.</li> <li>• ENOMSG - <i>msgsz</i> is smaller than the size of the message in the queue.</li> </ul>
Description	<p>The <code>msgrcv( )</code> function reads a message from the queue associated with the message queue identifier specified by <i>msqid</i> and places it in the user-defined buffer pointed to by <i>msgp</i>.</p> <p>The argument <i>msgsz</i> specifies the size in bytes of the message. The received message is truncated to <i>msgsz</i> bytes if it is larger than <i>msgsz</i> and (<i>msgflg</i> and MSG_NOERROR) is non-zero. The truncated part of the message is lost and no indication of the truncation is given to the calling process. If MSG_NOERROR is not specified and the received message is larger than <i>nbytes</i>, then a -1 is returned signalling error.</p> <p>The argument <i>msgflg</i> specifies the action to be taken if a message is not on the queue. These are as follows:</p> <ul style="list-style-type: none"> <li>• If (<i>msgflg</i> and IPC_NOWAIT) is non-zero, the calling thread returns immediately with a return value of -1.</li> <li>• If (<i>msgflg</i> and IPC_NOWAIT) is 0, the calling thread suspends execution until one of the following occurs:             <ul style="list-style-type: none"> <li>♦ A message is placed on the queue</li> <li>♦ The message queue identifier <i>msqid</i> is removed from the system; when this occurs -1 is returned</li> </ul> </li> </ul> <p>Upon successful completion, the following actions are taken with respect to the data structure associated with <i>msqid</i>:</p> <ul style="list-style-type: none"> <li>• <i>msg_qnum</i> is decremented by 1.</li> <li>• <i>msg_lrpId</i> is set equal to the process ID of the calling process.</li> </ul>
Includes	<p><code>xmk.h</code>, <code>sys/msg.h</code>, <code>sys/ipc.h</code></p>

## Shared Memory

Xilkernel supports kernel-allocated XSI shared memory. XSI is the X/Open System Interface which is a set of optional interfaces under POSIX. Shared memory is a common, low-latency IPC mechanism. Shared memory blocks required during run-time must be identified and specified during the system configuration. From this specification, buffer memory is allocated to each shared memory region. Shared memory is currently not allocated dynamically at run-time. This module is optional and can be configured in or out during system specification. Refer to [“Configuring Shared Memory,” page 47](#) for more details.

### Shared Memory Function Summary

The following list provides a linked summary of the shared memory functions in Xilkernel. You can click on a function to go to the description.

```
int shmget\(key\_t key, size\_t size, int shmflg\)  
int shmctl\(int shmid, int cmd, struct shmid\_ds \*buf\)  
void\* shmat\(int shmid, const void \*shmaddr, int flag\)  
int shm\_dt\(void \*shmaddr\)
```

### Shared Memory Function Descriptions

The Xilkernel shared memory interface is described below.

**Caution!** The memory buffers allocated by the shared memory API might not be aligned at word boundaries. Therefore, structures should not be arbitrarily mapped to shared memory segments, without checking if alignment requirements are met.

<b>int shmget</b> (key_t key, size_t size, int shmflg)	
Parameters	<p><i>key</i> is used to uniquely identify the shared memory region.</p> <p><i>size</i> is the requested size of the shared memory segment.</p> <p><i>shmflg</i> specifies segment creation options.</p>
Returns	<p>Unique non-negative shared memory identifier on success.</p> <p>-1 on failure and sets <i>errno</i> appropriately: <i>errno</i> can be set to:</p> <ul style="list-style-type: none"> <li>◆ EEXIST - A shared memory identifier exists for the argument <i>key</i> but (<i>shmflg</i> and IPC_CREAT) and (<i>shmflg</i> and IPC_EXCL) is non-zero.</li> <li>◆ ENOTSUP - Unsupported <i>shmflg</i>.</li> <li>◆ ENOENT - A shared memory identifier does not exist for the argument <i>key</i> and (<i>shmflg</i> and IPC_CREAT) is 0.</li> </ul>
Description	<p>The <code>shmget( )</code> function returns the shared memory identifier associated with <i>key</i>. A shared memory identifier, associated data structure, and shared memory segment of at least <i>size</i> bytes (see <code>sys/shm.h</code>) are created for <i>key</i> if one of the following is true:</p> <ul style="list-style-type: none"> <li>◆ <i>key</i> is equal to IPC_PRIVATE.</li> <li>◆ <i>key</i> does not already have a shared memory identifier associated with it and (<i>shmflg</i> and IPC_CREAT) is non-zero.</li> </ul> <p>Upon creation, the data structure associated with the new shared memory identifier shall be initialized. The value of <i>shm_segsz</i> is set equal to the value of <i>size</i>. The values of <i>shm_lpid</i>, <i>shm_nattch</i>, <i>shm_cpid</i> are all initialized appropriately. When the shared memory segment is created, it is initialized with all zero values. At least one of the shared memory segments available in the system must match <i>exactly</i> the requested size for the call to succeed. Key IPC_PRIVATE is not supported.</p>
Includes	<code>xmk.h</code> , <code>sys/shm.h</code> , <code>sys/ipc.h</code>

---

<b>int shmctl</b> (int shmid, int cmd, struct shmid_ds *buf)	
Parameters	<p><i>shmid</i> is the shared memory segment identifier.</p> <p><i>cmd</i> is the command to the control function.</p> <p><i>buf</i> is the buffer where the status is returned.</p>
Returns	<p>0 on success. Status is returned in buffer for IPC_STAT.</p> <p>-1 on failure and sets <i>errno</i> appropriately: <i>errno</i> can be set to EINVAL on the following conditions:</p> <ul style="list-style-type: none"> <li>• if <i>shmid</i> refers to an invalid shared memory segment.</li> <li>• if <i>cmd</i> or other params are invalid.</li> </ul>
Description	<p>The <code>shmctl( )</code> function provides a variety of shared memory control operations as specified by <i>cmd</i>. The following values for <i>cmd</i> are available:</p> <ul style="list-style-type: none"> <li>• IPC_STAT: places the current value of each member of the <code>shmid_ds</code> data structure associated with <i>shmid</i> into the structure pointed to by <i>buf</i>. The contents of the structure are defined in <code>sys/shm.h</code>.</li> <li>• IPC_SET is not supported.</li> <li>• IPC_RMID: removes the shared memory identifier specified by <i>shmid</i> from the system and destroys the shared memory segment and <code>shmid_ds</code> data structure associated with it. No notification is sent to processes still attached to the segment.</li> </ul>
Includes	<code>xmk.h</code> , <code>sys/shm.h</code> , <code>sys/ipc.h</code>

```
void* shmat(int shmid, const void *shmaddr, int flag)
```

Parameters	<p><i>shmid</i> is the shared memory segment identifier.</p> <p><i>shmaddr</i> is used to specify the location, to attach shared memory segment. This is currently unused.</p> <p><i>flag</i> is used to specify shared memory (SHM) attach options.</p>
Returns	<p>The start address of the shared memory segment on success.</p> <p>NULL on failure and sets <i>errno</i> appropriately. <i>errno</i> can be set to EINVAL if <i>shmid</i> refers to an invalid shared memory segment</p>
Description	<p><i>shmat</i>( ) increments the value of <i>shm_nattch</i> in the data structure associated with the shared memory ID of the attached shared memory segment and returns the start address of the segment. <i>shm_lpid</i> is also appropriately set.</p> <p><b>Note:</b> <i>shmaddr</i> and <i>flag</i> arguments are not used.</p>
Includes	xmk.h, sys/shm.h, sys/ipc.h

```
int shm_dt(void *shmaddr)
```

Parameters	<i>shmaddr</i> is the shared memory segment address that is to be detached.
Returns	<p>0 on success.</p> <p>-1 on failure and sets <i>errno</i> appropriately. The <i>errno</i> can be set to EINVAL if <i>shmaddr</i> is not within any of the available shared memory segments.</p>
Description	The <i>shm_dt</i> ( ) function detaches the shared memory segment located at the address specified by <i>shmaddr</i> from the address space of the calling process. The value of <i>shm_nattch</i> is also decremented. The memory segment is not removed from the system and can be attached to again.
Includes	xmk.h, sys/shm.h, sys/ipc.h

## Mutex Locks

Xilkernel provides support for kernel allocated POSIX thread mutex locks. This synchronization mechanism can be used alongside of the *pthread\_* API. The number of mutex locks and the length of the mutex lock wait queue can be configured during system specification. PTHREAD\_MUTEX\_DEFAULT and PTHREAD\_MUTEX\_RECURSIVE type mutex locks are supported. This module is also optional and can be configured in or out during system specification. Refer to “Configuring Shared Memory,” page 47 for more details.

### Mutex Lock Function Summary

The following list provides a linked summary of the Mutex locks in Xilkernel. You can click on a function to go to the description.

[int pthread\\_mutex\\_init\(pthread\\_mutex\\_t\\* mutex, const pthread\\_mutexattr\\_t\\* attr\)](#)  
[int pthread\\_mutex\\_destroy\(pthread\\_mutex\\_t\\* mutex\)](#)  
[int pthread\\_mutex\\_lock\(pthread\\_mutex\\_t\\* mutex\)](#)  
[int pthread\\_mutex\\_trylock\(pthread\\_mutex\\_t\\* mutex\)](#)  
[int pthread\\_mutex\\_unlock\(pthread\\_mutex\\_t\\* mutex\)](#)  
[int pthread\\_mutexattr\\_init\(pthread\\_mutexattr\\_t\\* attr\)](#)  
[int pthread\\_mutexattr\\_destroy\(pthread\\_mutexattr\\_t\\* attr\)](#)  
[int pthread\\_mutexattr\\_settype\(pthread\\_mutexattr\\_t\\* attr, int type\)](#)  
[int pthread\\_mutexattr\\_gettype\(pthread\\_mutexattr\\_t\\* attr, int \\*type\)](#)



## Mutex Lock Function Descriptions

The Mutex lock function descriptions are as follows:

---

```
int pthread_mutex_init(pthread_mutex_t* mutex, const
    pthread_mutexattr_t* attr)
```

**Parameters**            *mutex* is the location where the newly created mutex lock's identifier is to be stored.  
                          *attr* is the mutex creation attributes structure.

**Returns**                0 on success and mutex identifier in \**mutex*.  
                          EAGAIN if system is out of resources.

**Description**           The `pthread_mutex_init( )` function initializes the mutex referenced by *mutex* with attributes specified by *attr*. If *attr* is NULL, the default mutex attributes are used; the effect is the same as passing the address of a default mutex attributes object.

Refer to the `pthread_mutexattr_` routines, which are documented starting on [page 32](#) to determine what kind of mutex creation attributes can be changed. Upon successful initialization, the state of the mutex becomes initialized and unlocked. Only the mutex itself can be used for performing synchronization. The result of referring to copies of mutex in calls to `pthread_mutex_lock( )`, `pthread_mutex_trylock( )`, `pthread_mutex_unlock( )`, and `pthread_mutex_destroy( )` is undefined.

Attempting to initialize an already initialized mutex results in undefined behavior. In cases where default mutex attributes are appropriate, the macro `PTHREAD_MUTEX_INITIALIZER` can be used to initialize mutexes that are statically allocated. The effect is equivalent to dynamic initialization by a call to `pthread_mutex_init( )` with parameter *attr* specified as NULL, with the exception that no error checks are performed.

For example:

```
static pthread_mutex_t foo_mutex =
    PTHREAD_MUTEX_INITIALIZER;
```

**Includes**                `xmk.h`, `pthread.h`

**Note:** The mutex locks allocated by Xilkernel follow the semantics of `PTHREAD_MUTEX_DEFAULT` mutex locks by default. The following actions will result in undefined behavior:

- Attempting to recursively lock the mutex.
- Attempting to unlock the mutex if it was not locked by the calling thread.
- Attempting to unlock the mutex if it is not locked.

```
int pthread_mutex_destroy(pthread_mutex_t* mutex)
```

Parameters	<i>mutex</i> is the mutex identifier.
Returns	0 on success. EINVAL if <i>mutex</i> refers to an invalid identifier.
Description	The <code>pthread_mutex_destroy( )</code> function destroys the mutex object referenced by <i>mutex</i> ; the mutex object becomes, in effect, uninitialized. A destroyed mutex object can be reinitialized using <code>pthread_mutex_init( )</code> ; the results of otherwise referencing the object after it has been destroyed are undefined. <b>Note:</b> Mutex lock/unlock state disregarded during destroy. No consideration is given for waiting processes.
Includes	<code>xmk.h</code> , <code>pthread.h</code>

```
int pthread_mutex_lock(pthread_mutex_t* mutex)
```

Parameters	<i>mutex</i> is the mutex identifier.
Returns	0 on success and mutex in a locked state. EINVAL on invalid <i>mutex</i> reference. -1 on unhandled errors.
Description	The mutex object referenced by <i>mutex</i> is locked by the thread calling <code>pthread_mutex_lock( )</code> . If the mutex is already locked, the calling thread blocks until the mutex becomes available. If the mutex type is <code>PTHREAD_MUTEX_RECURSIVE</code> , then the mutex maintains the concept of a lock count. When a thread successfully acquires a mutex for the first time, the lock count is set to one. Every time a thread relocks this mutex, the lock count is incremented by one. Each time the thread unlocks the mutex, the lock count is decremented by one. If the mutex type is <code>PTHREAD_MUTEX_DEFAULT</code> , attempting to recursively lock the mutex results in undefined behavior. If successful, this operation returns with the mutex object referenced by <i>mutex</i> in the locked state.
Includes	<code>xmk.h</code> , <code>pthread.h</code>

```
int pthread_mutex_trylock(pthread_mutex_t* mutex)
```

Parameters	<i>mutex</i> is the mutex identifier.
Returns	0 on success. <i>mutex</i> in a locked state. EINVAL on invalid <i>mutex</i> reference, EBUSY if <i>mutex</i> is already locked. -1 on unhandled errors.
Description	<p>The mutex object referenced by <i>mutex</i> is locked by the thread calling <code>pthread_mutex_trylock( )</code>. If the mutex is already locked, the calling thread returns immediately with EBUSY.</p> <p>If the mutex type is PTHREAD_MUTEX_RECURSIVE, then the mutex maintains the concept of a lock count.</p> <p>When a thread successfully acquires a mutex for the first time, the lock count is set to one.</p> <p>Every time a thread relocks this mutex, the lock count is incremented by one. Each time the thread unlocks the mutex, the lock count is decremented by one.</p> <p>If the mutex type is PTHREAD_MUTEX_DEFAULT, attempting to recursively lock the mutex results in undefined behavior. If successful, this operation returns with the mutex object referenced by <i>mutex</i> in the locked state.</p>
Includes	xmk.h, pthread.h

```
int pthread_mutex_unlock(pthread_mutex_t* mutex)
```

Parameters	<i>mutex</i> is the mutex identifier.
Returns	0 on success, EINVAL on invalid mutex reference. -1 on undefined errors.
Description	<p>The <code>pthread_mutex_unlock( )</code> function releases the mutex object referenced by <i>mutex</i>. If there are threads blocked on the mutex object referenced by <i>mutex</i> when <code>pthread_mutex_unlock( )</code> is called, resulting in the mutex becoming available, the scheduling policy determines which thread will acquire the mutex. If it is SCHED_RR, then the thread that is at the head of the mutex wait queue is unblocked and allowed to lock the mutex.</p> <p>If the mutex type is PTHREAD_MUTEX_RECURSIVE, the mutex maintains the concept of a lock count. When the lock count reaches zero, the mutex becomes available for other threads to acquire. If a thread attempts to unlock a mutex that it has not locked or a mutex which is unlocked, an error is returned.</p> <p>If the mutex type is PTHREAD_MUTEX_DEFAULT the following actions result in undefined behavior:</p> <ul style="list-style-type: none"> <li>• Attempting to unlock the mutex if it was not locked by the calling thread.</li> <li>• Attempting to unlock the mutex if it is not locked.</li> </ul> <p>If successful, this operation returns with the mutex object referenced by <i>mutex</i> in the unlocked state.</p>
Includes	xmk.h, pthread.h

```
int pthread_mutexattr_init(pthread_mutexattr_t* attr)
```

Parameters	<i>attr</i> is the location of the attributes structure.
Returns	0 on success. EINVAL if <i>attr</i> refers to an invalid location.
Description	The <code>pthread_mutexattr_init( )</code> function initializes a mutex attributes object <i>attr</i> with the default value for all of the attributes defined by the implementation. Refer to <code>sys/types.h</code> for the contents of the <code>pthread_mutexattr</code> structure. <b>Note:</b> This routine does not involve a call into the kernel.
Includes	<code>xmk.h</code> , <code>pthread.h</code>

---

```
int pthread_mutexattr_destroy(pthread_mutexattr_t* attr)
```

Parameters	<i>attr</i> is the location of the attributes structure.
Returns	0 on success. EINVAL if <i>attr</i> refers to an invalid location.
Description	The <code>pthread_mutexattr_destroy( )</code> function destroys a mutex attributes object; the object becomes, in effect, uninitialized. <b>Note:</b> This routine does not involve a call into the kernel.
Includes	<code>xmk.h</code> , <code>pthread.h</code>

---

```
int pthread_mutexattr_settype(pthread_mutexattr_t* attr,  
int type)
```

Parameters	<i>attr</i> is the location of the attributes structure. <i>type</i> is the type to which to set the mutex.
Returns	0 on success. EINVAL if <i>attr</i> refers to an invalid location or if <i>type</i> is an unsupported type.
Description	The <code>pthread_mutexattr_settype( )</code> function sets the type of a mutex in a mutex attributes structure to the specified type. Only <code>PTHREAD_MUTEX_DEFAULT</code> and <code>PTHREAD_MUTEX_RECURSIVE</code> are supported. <b>Note:</b> This routine does not involve a call into the kernel.
Includes	<code>xmk.h</code> , <code>pthread.h</code>

```
int pthread_mutexattr_gettype(pthread_mutexattr_t* attr,
    int *type)
```

Parameters	<i>attr</i> is the location of the attributes structure. <i>type</i> is a pointer to the location at which to store the mutex.
Returns	0 on success. EINVAL if <i>attr</i> refers to an invalid location.
Description	The <code>pthread_mutexattr_gettype( )</code> function gets the type of a mutex in a mutex attributes structure and stores it in the location pointed to by <i>type</i> .
Includes	<code>xmk.h</code> , <code>pthread.h</code>

## Dynamic Buffer Memory Management

The kernel provides a buffer memory allocation scheme, which can be used by applications that need dynamic memory allocation. These interfaces are alternatives to the standard C memory allocation routines - `malloc( )`, `free( )` which are much slower and bigger, though more powerful. The allocation routines hand off pieces of memory from a pool of memory that the user passes to the buffer memory manager.

The buffer memory manager manages the pool of memory. You can dynamically create new pools of memory. You can also statically specify the different memory blocks sizes and number of such memory blocks required for your applications. Refer to “[Configuring Buffer Memory Allocation](#),” page 47 for more details. This method of buffer management is relatively simple, small and a fast way of allocating memory. The following are the buffer memory allocation interfaces. This module is optional and can be included during system initialization.

### Dynamic Buffer Memory Management Function Summary

The following list provides a linked summary of the dynamic buffer memory management functions in Xilkernel. You can click on a function to go to the description.

```
int bufcreate\(membuf\_t \*mbuf, void \*memptr, int nblks, size\_t blksiz\)
int bufdestroy\(membuf\_t mbuf\)
void\* bufmalloc\(membuf\_t mbuf, size\_t siz\)
void buf.free\(membuf\_t mbuf, void\* mem\)
```

**Caution!** The buffer memory allocation API internally uses the memory pool handed down the by the user to store a free-list in-place within the memory pool. As a result, only memory sizes greater than or equal to 4 bytes long are supported by the buffer memory allocation APIs. Also, because there is a free-list being built in-place within the memory pool, requests in which memory block sizes are not multiples of 4 bytes cause unalignment at run time. If your software platform can handle unalignment natively or through exceptions then this does not present an issue. The memory buffers allocated and returned by the buffer memory allocation API might also not be aligned at word boundaries. Therefore, your application should not arbitrarily map structures to memory allocated in this way without first checking if alignment and padding requirements are met.

## Dynamic Buffer Memory Management Function Descriptions

The dynamic buffer memory management function descriptions are as follows:

---

```
int bufcreate(membuf_t *mbuf, void *memptr, int nblks,
               size_t blksiz)
```

Parameters	<i>mbuf</i> is location at which to store the identifier of the memory pool created. <i>memptr</i> is the pool of memory to use. <i>nblks</i> is the number of memory blocks that this pool should support. <i>blksiz</i> is the size of each memory block in bytes.
Returns	0 on success and stores the identifier of the created memory pool in the location pointed to by <i>mbuf</i> . -1 on errors.
Description	Creates a memory pool out of the memory block specified in <i>memptr</i> . <i>nblks</i> number of chunks of memory are defined within the pool, each of size <i>blksiz</i> . Therefore, <i>memptr</i> must point to at least ( <i>nblks</i> * <i>blksiz</i> ) bytes of memory. <i>blksiz</i> must be greater than or equal to 4.
Includes	xmk.h, sys/bufmalloc.h

---

```
int bufdestroy(membuf_t mbuf)
```

Parameters	<i>mbuf</i> is the identifier of the memory pool to destroy.
Returns	0 on success. -1 on errors.
Description	This routine destroys the memory pool identified by <i>mbuf</i> .
Includes	xmk.h, sys/bufmalloc.h

---

```
void* bufmalloc(membuf_t mbuf, size_t siz)
```

Parameters	<i>mbuf</i> is the identifier of the memory pool from which to allocate memory. <i>size</i> is the size of memory block requested.
Returns	The start address of the memory block on success. NULL on failure and sets <i>errno</i> appropriately: <i>errno</i> is set to: <ul style="list-style-type: none"> <li>• EINVAL if <i>mbuf</i> refers to an invalid memory buffer.</li> <li>• EAGAIN if the request cannot be satisfied.</li> </ul>
Description	Allocate a chunk of memory from the memory pool specified by <i>mbuf</i> . If <i>mbuf</i> is MEMBUF_ANY, then all available memory pools are searched for the request and the first pool that has a free block of size <i>siz</i> , is used and allocated from.
Includes	xmk.h, sys/bufmalloc.h

---

```
void buffree(membuf_t mbuf, void* mem)
```

Parameters	<i>mbuf</i> is the identifier of the memory pool. <i>mem</i> is the address of the memory block.
Returns	None.
Description	Frees the memory allocated by a corresponding call to <i>bufmalloc</i> . If <i>mbuf</i> is MEMBUF_ANY, returns the memory to the pool that satisfied this request. If not, returns the memory to specified pool. Behavior is undefined if arbitrary values are specified for <i>mem</i> .
Includes	xmk.h, sys/bufmalloc.h

## Software Timers

Xilkernel provides software timer functionality, for time relating processing. This module is optional and can be configured in or out. Refer to [“Configuring Software Timers,” page 48](#) for more information on customizing this module.

The following list provides a linked summary of the interfaces are available with the software timers module. You can click on a function to go to the description.

[unsigned int xget\\_clock\\_ticks\( \)](#)

---

```
unsigned int xget_clock_ticks( )
```

Parameters	None.
Returns	Number of kernel ticks elapsed since the kernel was started.
Description	A single tick is counted, every time the kernel timer delivers an interrupt. This is stored in a 32-bit integer and eventually overflows. The call to <i>xget_clock_ticks</i> ( ) returns this tick information, without conveying the overflows that have occurred.
Includes	xmk.h, sys/timer.h

---

```
time_t time(time_t *timer)
```

Parameters	<i>timer</i> points to the memory location in which to store the requested time information.
Returns	Number of seconds elapsed since the kernel was started.
Description	The routine time elapsed since kernel start in units of seconds. This is also subject to overflow.
Includes	xmk.h, sys/timer.h

unsigned **sleep**(unsigned int *ms*)

Parameters            *ms* is the number of milliseconds to sleep.


Returns                Number of seconds between sleeps.  
0 on complete success.

Description           This routine causes the invoking process to enter a sleep state for the specified number of milliseconds.

Includes                *xmk.h*, *sys/timer.h*

## Interrupt Handling

Xilkernel abstracts away primary interrupt handling requirements from the user application. Even though the kernel is functional without any interrupts, the system only makes sense when it is driven by at least one timer interrupt for scheduling. The kernel handles the main timer interrupt, using it as the kernel tick to perform scheduling. The timer interrupt is initialized and tied to the vectoring code during system initialization. This kernel pulse provides software timer facilities and time-related routines also. Additionally, Xilkernel can handle multiple interrupts when connected through an interrupt controller, and works with the *xps\_intc* or *axi\_intc* interrupt controller core. The following figure shows a basic interrupt service in Xilkernel.



X10229

Figure 5: Basic Interrupt Service in Xilkernel

The interrupt handling scenario is illustrated in this diagram. Upon an interrupt:

- The context of the currently executing process is saved into the context save area.
- Interrupts are disabled from this point in time onwards, until they are enabled at the end of interrupt handling.
- This alleviates the stack burden of the process, as the execution within interrupt, does not use the user application stack.
- This interrupt context can be thought of as a special kernel thread that executes interrupt handlers in order. This thread starts to use its own separate execution stack space.
- The separate kernel execution stack is at-least 1 KB in size to enable it to handle deep levels of nesting within interrupt handlers. This kernel stack is also automatically configured to use the pthread stack size chosen by the user, if it is larger than 1 KB. If you foresee a large stack usage within your interrupt handlers, you will need to specify a large value for *pthread\_stack\_size*.

This ends the first level of interrupt handling by the kernel. At this point, the kernel transfers control to the second level interrupt handler. This is the main interrupt handler routine of the



interrupt controller. From this point, the handler for the interrupt controller invokes the user-specified interrupt handlers for the various interrupting peripherals.

In MicroBlaze processor kernels, if the system timer is connected through the interrupt controller, then the kernel invisibly handles the main timer interrupt (kernel tick), by registering itself as the handler for that interrupt.

Interrupt handlers can perform any kind of required interrupt handling action, including making system calls. However, the handlers must never invoke blocking system calls, or the entire kernel is blocked and the system comes to a suspended state. Use handlers wisely to do minimum processing upon interrupts.

**Caution!** User level interrupt handlers must not make blocking system calls. System calls made, if any, should be non-blocking.

After the user-level interrupt handlers are serviced, the first-level interrupt handler in the kernel gets control again. It determines if the preceding interrupt handling caused a rescheduling requirement in the kernel.

If there is such a requirement, it invokes the kernel scheduler and performs the appropriate rescheduling. After the scheduler has determined the next process to execute, the context of the new process is restored and interrupts are enabled again.

**Note:** Currently, Xilkernel only supports an interrupt controller tied to the external interrupt pin of the PowerPC 405 processor. It does not support interrupt controllers tied to the critical input pin of the processor.

When Xilkernel is used with multiple-interrupts in the system, the Xilkernel user-level interrupt handling API becomes available. The following subsection lists user-level interrupt handling APIs.

## User-Level Interrupt Handling APIs

### User-Level Interrupt Handling APIs Function Summary

The following list provides a linked summary of the user-level interrupt handling APIs in Xilkernel. You can click on a function to go to the description.

[unsigned int register\\_int\\_handler\(int\\_id\\_t id, void \\*handler\)\(void\\*\), void \\*callback](#)  
[void unregister\\_int\\_handler\(int\\_id\\_t id\)](#)  
[void enable\\_interrupt\(int\\_id\\_t id\)](#)  
[void disable\\_interrupt\(int\\_id\\_t id\)](#)  
[void acknowledge\\_interrupt\(int\\_id\\_t id\)](#)

### User-Level Interrupt Handling APIs Function Descriptions

The interrupt handlings API descriptions are as follows:

---

```
unsigned int register_int_handler(int_id_t id, void
    *handler)(void*), void *callback)
```

Parameters	<i>id</i> is the zero-based numeric id of the interrupt. <i>handler</i> is the user-level handler. <i>callback</i> is a callback value that can be delivered to the user-level handler.
Returns	XST_SUCCESS on success. error codes defined in <code>xstatus.h</code> .
Description	The <code>register_int_handler( )</code> function registers the specified user level interrupt handler as the handler for a specified interrupt. The user level routine is invoked asynchronously upon being serviced by an interrupt controller in the system. The routine returns an error on MicroBlaze processor systems if <i>id</i> is the identifier for the system timer interrupt. PowerPC processor systems have a dedicated hardware timer interrupt that exists separately from the other interrupts in the system. Therefore, this check is not performed for a PowerPC processor system.
Includes	<code>xmk.h</code> , <code>sys/intr.h</code>

---

```
void unregister_int_handler(int_id_t id)
```

Parameters	<i>id</i> is the zero-based numeric id of the interrupt.
Returns	None.
Description	The <code>unregister_int_handler( )</code> function unregisters the registered user-level interrupt handler as the handler for the specified interrupt. The routine does nothing and fails silently on MicroBlaze processor systems if <i>id</i> is the identifier for the system timer interrupt.
Includes	<code>xmk.h</code> , <code>sys/intr.h</code>

---

```
void enable_interrupt(int_id_t id)
```

Parameters	<i>id</i> is the zero-based numeric id of the interrupt.
Returns	None.
Description	The <code>enable_interrupt( )</code> function enables the specified interrupt in the interrupt controller. The routine does nothing and fails silently on MicroBlaze processor systems, if <i>id</i> is the identifier for the system timer interrupt.
Includes	<code>xmk.h</code> , <code>sys/intr.h</code>

---

```
void disable_interrupt(int_id_t id)
```

Parameters	<i>id</i> is the zero-based numeric id of the interrupt.
Returns	None.
Description	The <code>disable_interrupt( )</code> function disables the specified interrupt in the interrupt controller. The routine does nothing and fails silently on MicroBlaze processor systems if <i>id</i> is the identifier for the system timer interrupt.
Includes	<code>xmk.h</code> , <code>sys/intr.h</code>

---

```
void acknowledge_interrupt(int_id_t id)
```

Parameters	<i>id</i> is the zero-based numeric identifier of the interrupt.
Returns	None.
Description	The <code>acknowledge_interrupt( )</code> function acknowledges handling the specified interrupt to the interrupt controller. The routine does nothing and fails silently on MicroBlaze processor systems if <i>id</i> is the identifier for the system timer interrupt.
Includes	<code>xmk.h</code> , <code>sys/intr.h</code>

---

## Exception Handling

Xilkernel handles exceptions for the MicroBlaze processor, treating them as faulting conditions by the executing processes/threads. Xilkernel kills the faulting process and reports using a message to the console (if verbose mode is on) as to the nature of the exception. You cannot register your own handlers for these exceptions and Xilkernel handles them all natively.

Xilkernel does *not* handle exceptions for the PowerPC processor. The exception handling API and model that is available for the Standalone platform is available for Xilkernel. You might want to register handlers or set breakpoints (during debug) for exceptions that are of interest to you.

## Memory Protection

Memory protection is an extremely useful feature that can increase the robustness, reliability, and fault tolerance of your Xilkernel-based application. Memory protection requires support from the hardware. Xilkernel is designed to make use of the MicroBlaze Memory Management (Protection) Unit (MMU) features when available. This allows you to build fail-safe applications that each run within the valid sandbox of the system, as determined by the executable file and available I/O devices.

**Note:** Full virtual memory management is not supported by Xilkernel. Even when a full MMU is available on a MicroBlaze processor, only transparent memory translations are used, and there is no concept of demand paging.

**Note:** Xilkernel does not support the Memory Protection feature on PowerPC processors.

## Memory Protection Overview

When the MicroBlaze parameter `C_USE_MMU` is set to `>=2`, the kernel configures in memory protection during startup automatically.

**Note:** To disable the memory protection in the kernel, add the compiler flag `-D XILKERNEL_MB_MPU_DISABLE`, to your library and application build.

The kernel identifies three types of protection violations:

1. **Code violation** — occurs when a thread tries to execute from memory that is not defined to contain program instructions.  
**Note:** Because Xilkernel is a single executable, all threads have access to all program instructions and the kernel cannot trap violations where a thread starts executing the kernel code directly.
2. **Data access violation** — Occurs when a thread tries to read or write data to or from memory that is not defined to be a part of the program data space. Similarly, read-only data segments can be protected by write access by all threads.  
**Note:** Because Xilkernel is a single executable, all threads have equal access to all data as well as the kernel data structures. The kernel cannot trap violations where a thread accesses data that it is not designated to handle.
3. **I / O violation** — occurs when a thread tries to read or write from memory-mapped peripheral I / O space that is not present in the system.

Xilkernel attempts to determine these three conceptual protection areas in your program and system during system build and kernel boot time automatically. The kernel attempts to identify code and data labels that demarcate code and data sections in your executable ELF file. These labels are typically provided by linker scripts.

For example, MicroBlaze linker scripts use the labels `_ftext` and `_etext` to indicate the beginning and the end of the `.text` section respectively.

The following table summarizes the logical sections that must be present in the linker script, the requirements on the alignment of each section, and the demarcating labels.

**Table 1: Linker Script Logical Sections**

Section	Start Label	End Label	Description
<code>.text</code>	<code>_ftext</code>	<code>_etext</code>	Executable instruction sections
<code>.data</code>	<code>_fdata</code>	<code>_edata</code>	Read-write data sections including small data sections
<code>.rodata</code>	<code>_frodata</code>	<code>_erodata</code>	Read only data sections including small data sections
<code>.stack</code>	<code>_stack_end</code>	<code>_stack</code>	Kernel stack with 1 KB guard page above and below
stack guard page (top)	<code>_fstack_guard_top</code>	<code>_estack_guard_top</code>	Top kernel stack guard page (1 KB)
stack guard page (bottom)	<code>_fstack_guard_bottom</code>	<code>_estack_guard_bottom</code>	Bottom kernel stack guard page (1 KB)

Each section must be aligned at 1 KB boundary and clearly demarcated by the specified labels. Otherwise, Xilkernel will ignore the missing logical sections with no error or warning message.

**Caution!** This behavior could manifest itself in your software not working as expected, because MPU translation entries will be missing for important ELF sections and the processor will treat valid requests as invalid.

**Note:** Each section typically has a specific type of data that is expected to be present. If the logic of the data inserted into the sections by your linker script is inappropriate, then the protection offered by the kernel could be incorrect or the level of protection could be diluted.

I/O ranges are automatically enumerated by the library generation tools and provided as a data structure to the kernel. These peripheral I/O ranges will not include read/write memory areas because the access controls for memory are determined automatically from the ELF file. During kernel boot, the enumerated I/O ranges are marked as readable and writable by the threads. Accesses outside of the defined I/O ranges causes a protection fault.

## User-specified Protection

In addition to the automatic inference and protection region setup done by the kernel, you can provide your own protection regions by providing the data structures as shown in the following example. If this feature is not required, these data structures can be removed from the application code.

```
#include <mpu.h>

int user_io_nranges = 2;
xilkernel_io_range_t user_io_range[1] = {{0x25004000, 0x25004fff,
MPU_PROT_READWRITE},
{0x44000000, 0x44001fff, MPU_PROT_NONE}};
```

The `xilkernel_io_ranges_t` type is defined as follows:

```
typedef struct xilkernel_io_range_s {
    unsigned int baseaddr;
    unsigned int highaddr;
    unsigned int flags;
} xilkernel_io_range_t;
```

The following table lists the valid field flags that identify the user-specified access protection options:

**Table 2: Access Protection Field Flags**

Field Flag	Description
MPU_PROT_EXEC	Executable program instructions (no read or write permissions)
MPU_PROT_READWRITE	Readable and writable data sections (no execute permissions)
MPU_PROT_READ	Read-only data sections (no write/execute permissions)
MPU_PROT_NONE	(Currently no page can be protected from all three accesses at the same time. This field flag is equivalent to MPU_PROT_READ)

## Fixed Unified Translation Look-aside Buffer (TLB) Support on the MicroBlaze Processor

The MicroBlaze processor has a fixed 64-entry Unified Translation Look-aside Buffer (TLB). Xilkernel can support up to this maximum number of TLBs only. If the maximum TLBs to enable protection for a given region are exceeded, Xilkernel will report an error during Microprocessor Unit (MPU) initialization and proceed to boot the kernel without memory protection. There is no support for dynamically swapping TLB management to provide an arbitrary number of protection regions.

## Other Interfaces

Internally, Xilkernel, depends on the Standalone platform; consequently, the interfaces that the Standalone presents are inherited by Xilkernel. Refer to the “Standalone” document for information on available interfaces. For example, to add your own custom handlers for the various exceptions that PowerPC 405 processor supports, you would use the exception handling interface provided by the Standalone for the PowerPC 405 processor.

## Hardware Requirements

Xilkernel has been designed to work with the EDK hardware and software flow. It is completely integrated with the software platform configuration and automatic library generation mechanism. As a result, a software platform based on Xilkernel can be configured and built in a matter of minutes. However, some services in the kernel require support from the hardware. Scheduling and all the dependent features require a periodic kernel tick and typically some kind of timer is used. Xilkernel has been designed to work with either the Xilinx `fit_timer` IP core or the `xps_timer/axi_timer` IP core. By specifying the instance name of the timer device in the software platform configuration, Xilkernel is able to initialize and use the timer cores and timer related services automatically. Refer to “[Configuring System Timer](#),” page 48 for more information on how to specify the timer device. On PowerPC 405 and PowerPC 440 processors, Xilkernel uses the internal programmable timer of the processor and consequently does not need external timer cores for kernel functionality; you must, however, specify values for the system timer frequency and system timer interval.

Xilkernel has also been designed to work in scenarios involving multiple-interrupting peripherals. The `xps_intc/axi_intc` IP core handles the hardware interrupts and feeds a single IRQ line from the controller to the processor. By specifying the name of the interrupt controller peripheral in the software platform configuration, you would be getting kernel awareness of multiple interrupts. Xilkernel would automatically initialize the hardware cores, interrupt system, and the second level of software handlers as a part of its startup. You do not have to do this manually. Xilkernel handles non-cascaded interrupt controllers; cascaded interrupt controllers are not supported.

## System Initialization

The entry point for the kernel is the `xilkernel_main( )` routine defined in `main.c`. Any user initialization that must be performed can be done before the call to `xilkernel_main( )`. This includes any system-wide features that might need to be enabled before invoking `xilkernel_main( )`. These are typically machine-state features such as cache enablement or hardware exception enablement that must be “always ON” even when context switching between applications. Make sure to set up such system states before invoking `xilkernel_main( )`. Conceptually, the `xilkernel_main( )` routine does two things: it initializes the kernel via `xilkernel_init( )` and then starts the kernel with `xilkernel_start( )`. The first action performed within `xilkernel_init( )` is kernel-specific hardware initialization. This includes registering the interrupt handlers and configuring the system timer, as well as memory protection initialization. Interrupts/exceptions are not enabled after completing `hw_init( )`. The `sys_init( )` routine is entered next.

The `sys_init( )` routine performs initialization of each module, such as processes and threads, initializing in the following order:

1. Internal process context structures
2. Ready queues
3. pthread module
4. Semaphore module
5. Message queue module
6. Shared memory module
7. Memory allocation module
8. Software timers module
9. Idle task creation
10. Static pthread creation

After these steps, `xilkernel_start( )` is invoked where interrupts and exceptions are enabled. The kernel loops infinitely in the *idle task*, enabling the scheduler to start scheduling processes.

## Thread Safety and Re-Entrancy

Xilkernel, by definition, creates a multi-threaded environment. Many library and driver routines might not be written in a thread-safe or re-entrant manner. Examples include the C library routines such as `printf( )`, `sprintf( )`, `malloc( )`, `free( )`. When using any library or driver API that is not a part of Xilkernel, you must make sure to review thread-safety and re-entrancy features of the routine. One common way to prevent incorrect behavior with unsafe routines is to protect entry into the routine with locks or semaphores.

## Restrictions

- Floating point applications cannot be used with Xilkernel on the PowerPC 440 and PowerPC 405 processors. This limitation is because Xilkernel does not context switch the floating point registers and floating point control/status registers on these processors. A future release will aim to add this support to Xilkernel.

Floating point applications *can* be used safely with MicroBlaze processors because the MicroBlaze processor does not have a different register set for floating point values.

- The MicroBlaze processor compiler supports a `-mxl-stack-check` switch, which can be used to catch stack overflows. However, this switch is meant to work only with single-threaded applications, so it cannot be used in Xilkernel.

## Kernel Customization

Xilkernel is highly customizable. As described in previous sections, you can change the modules and individual parameters to suit your application. The SDK **Board Support Package Settings** dialog box provides an easy configuration method for Xilkernel parameters. Refer to the “Embedded System and Tools Architecture Overview” chapter in the *Embedded Systems Tools Reference Manual (UG111)* for more details (a link to the document is available in [“Additional Resources,” page 2](#)). To customize a module in the kernel, a parameter with the name of the category set to `TRUE` must be defined in the Microprocessor Software Specification (MSS) file. An example for customizing the pthread is shown as follows:

```
parameter config_pthread_support = true
```

If you do not define a configurable `config_` parameter for the module, that module is not implemented. You do not have to manually key in these parameters and values. When you input information in the **Board Support Package Settings** dialog box, SDK generates the corresponding Microprocessor Software Specification (MSS) file entries automatically.

The following is an MSS file snippet for configuring OS Xilkernel for a PowerPC processor system. The values in the snippet are sample values that target a hypothetical board:

```
BEGIN OS
PARAMETER OS_NAME = xilkernel
PARAMETER OS_VER = 5.01.a
PARAMETER STDIN = RS232
PARAMETER STDOUT = RS232
PARAMETER proc_instance = ppc405_0
PARAMETER config_debug_support = true
PARAMETER verbose = true
PARAMETER systmr_spec = true
PARAMETER systmr_freq = 100000000
PARAMETER systmr_interval = 80
PARAMETER sysintc_spec = system_intc
PARAMETER config_sched = true
PARAMETER sched_type = SCHED_PRIO
PARAMETER n_prio = 6
PARAMETER max_readyq = 10
PARAMETER config_pthread_support = true
PARAMETER max_pthreads = 10
PARAMETER config_sema = true
PARAMETER max_sema = 4
PARAMETER max_sema_waitq = 10
PARAMETER config_msgq = true
PARAMETER num_msgqs = 1
PARAMETER msgq_capacity = 10
PARAMETER config_bufmalloc = true
PARAMETER config_pthread_mutex = true
PARAMETER config_time = true
PARAMETER max_tmrs = 10
PARAMETER enhanced_features = true
PARAMETER config_kill = true
PARAMETER mem_table = ((4,30),(8,20))
PARAMETER static_pthread_table = ((shell_main,1))
END
```

The configuration parameters in the MSS specification impact the memory and code size of the Xilkernel image. Kernel-allocated structures whose count can be configured through the MSS must be reviewed to ensure that your memory and code size is appropriate to your design.

For example, the maximum number of process context structures allocated in the kernel is determined by the sum of two parameters; `max_procs` and `max_pthreads`. If a process context structures occupies `x` bytes of `bss` memory, then the total `bss` memory requirement for process contexts is  $(\text{max\_pthreads} * x)$  bytes. Consequently, such parameters must be tuned carefully, and you need to examine the final kernel image with the GNU size utility to ensure that your memory requirements are met. To get an idea the contribution each kernel-allocated structure makes to memory requirements, review the corresponding header file. The specification in the MSS is translated by Libgen and Xilkernel Tcl files into C-language configuration directives in two header files: `os_config.h` and `config_init.h`. Review these two files, which are generated in the main processor include directory, to understand how the specification gets translated.



## Configuring STDIN and STDOUT

The standard input and output peripherals can be configured for Xilkernel. Xilkernel can work without a standard input and output also. These peripherals are the targets of input-output APIs like `print`, `outbyte`, and `inbyte`. The following table provides the attribute descriptions, data types, and defaults.

**Table 3: STDIN/STDOUT Configuration Parameters**

Attribute	Description	Type	Defaults
<code>stdin</code>	Instance name of stdin peripheral.	string	none
<code>stdout</code>	Instance name of stdout peripheral.	string	none

## Configuring Scheduling

You can configure the kernel scheduling policy by configuring the parameters shown in the following table.

**Table 4: Scheduling Parameters**

Attribute	Description	Type	Defaults
<code>config_sched</code>	Configure scheduler module.	boolean	true
<code>sched_type</code>	Type of Scheduler to be used. Allowed values: 2 - SCHED_RR 3 - SCHED_PRIO	enum	SCHED_RR
<code>n_prio</code>	Number of priority levels if scheduling is SCHED_PRIO.	numeric	32
<code>max_readyq</code>	Length of each ready queue. This is the maximum number of processes that can be active in a ready queue at any instant in time.	numeric	10

## Configuring Thread Management

Threads are the primary mechanism for creating process contexts. The configurable parameters of the thread module are listed in the following table.

**Table 5: Thread Module Parameters**

Attribute	Description	Type	Defaults
<code>config_pthread_support</code>	Need pthread module.	boolean	true
<code>max_pthreads</code>	Maximum number of threads that can be allocated at any point in time.	numeric	10
<code>pthread_stack_size</code>	Stack size for dynamically created threads (in bytes).	numeric	1000

Table 5: Thread Module Parameters (Cont'd)

Attribute	Description	Type	Defaults
<code>static_pthread_table</code>	Statically configure the threads that startup when the kernel is started. This is defined to be an array with each element containing the parameters <code>pthread_start_addr</code> and <code>pthread_prio</code> . <b>Note:</b> If you are specifying function names for <code>pthread_start_addr</code> , they must be functions in your source code that are compiled with the C dialect. They <i>cannot</i> be functions compiled with the C++ dialect.	array of 2-tuples	none
<code>pthread_start_addr</code>	Thread start address.	Function name (string)	none
<code>pthread_prio</code>	Thread priority.	numeric	none

## Configuring Semaphores

You can configure the semaphores module, the maximum number of semaphores, and semaphore queue length. The following table shows the parameters used for configuration.

Table 6: Semaphore Module Parameters

Attribute	Description	Type	Defaults
<code>config_sema</code>	Need Semaphore module.	boolean	false
<code>max_sem</code>	Maximum number of Semaphores.	numeric	10
<code>max_sem_waitq</code>	Semaphore Wait Queue Length.	numeric	10
<code>config_named_sema</code>	Configure named semaphore support in the kernel.	boolean	false

## Configuring Message Queues

Optionally, you can configure the message queue module, number of message queues, and the size of each message queue. The message queue module depends on both the semaphore module and the buffer memory allocation module. The following table shows the parameter definitions used for configuration. Memory for messages must be explicitly specified in the `malloc` customization or created at run-time.

Table 7: Message Queue Module Parameters

Attribute	Description	Type	Defaults
<code>config_msgq</code>	Need Message Queue module.	boolean	false
<code>num_msgqs</code>	Number of message queues in the system.	numeric	10
<code>msgq_capacity</code>	Maximum number of messages in the queue.	numeric	10
<code>use_malloc</code>	Provide for more powerful message queues which use <code>malloc</code> and <code>free</code> to allocate memory for messages.	boolean	false

## Configuring Shared Memory

Optionally, you can configure the shared memory module and the size of each shared memory segment. All the shared memory segments that are needed must be specified in these parameters. The following table shows the parameters used for configuration.

**Table 8: Shared Memory Module Parameters**

Attribute	Description	Type	Defaults
<code>config_shm</code>	Need shared memory module.	boolean	false
<code>shm_table</code>	Shared memory table. Defined as an array with each element having <code>shm_size</code> parameter.	array of 1-tuples	none
<code>shm_size</code>	Shared memory size.	numeric	none
<code>num_shm</code>	Number of shared memories expressed as the <code>shm_table</code> array size.	numeric	none

## Configuring Pthread Mutex Locks

Optionally, you can choose to include the pthread mutex module, number of mutex locks, and the size of the wait queue for the mutex locks. The following table shows the parameters used for configuration.

**Table 9: Pthread Mutex Module Parameters**

Attribute	Description	Type	Defaults
<code>config_pthread_mutex</code>	Need pthread mutex module.	boolean	false
<code>max_pthread_mutex</code>	Maximum number of pthread mutex locks available in the system.	numeric	10
<code>max_pthread_mutex_waitq</code>	Length of each the mutex lock wait queue.	numeric	10

## Configuring Buffer Memory Allocation

Optionally, you can configure the dynamic buffer memory management module, size of memory blocks, and number of memory blocks. The following table shows the parameters used for configuration.

**Table 10: Memory Management Module Parameters**

Attribute	Description	Type	Defaults
<code>config_bufmalloc</code>	Need buffer memory management.	boolean	false
<code>max_bufs</code>	Maximum number of buffer pools that can be managed at any time by the kernel.	numeric	10
<code>mem_table</code>	Memory block table. This is defined as an array with each element having <code>mem_bsize</code> , <code>mem_nblks</code> parameters.	array of 2-tuples	none
<code>mem_bsize</code>	Memory block size in bytes.	numeric	none
<code>mem_nblks</code>	Number of memory blocks of a size.	numeric	none

## Configuring Software Timers

Optionally, you can configure the software timers module and the maximum number of timers supported. The following table shows the parameters used for configuration.

**Table 11: Software Timers Module Parameters**

Attribute	Description	Type	Defaults
<code>config_time</code>	Need software timers and time management module.	boolean	false
<code>max_tmrs</code>	Maximum number of software timers in the kernel.	numeric	10

## Configuring Enhanced Interfaces

Optionally, you can configure some enhanced features/interfaces using the following parameters shown in the following table.

**Table 12: Enhanced Features**

Attribute	Description	Type	Defaults
<code>config_kill</code>	Include the ability to kill a process with the <code>kill( )</code> function.	boolean	false
<code>config_yield</code>	Include the <code>yield( )</code> interface.	boolean	false

## Configuring System Timer

You can configure the timer device in the system for MicroBlaze processor kernels. Additionally, you can configure the timer interval for PowerPC and PIT timer based MicroBlaze processor systems. The following table shows the available parameters .

**Table 13: Attributes for Copying Kernel Source Files**

Attribute	Description	Type	Defaults
<code>systmr_dev<sup>1</sup></code>	Instance name of the system timer peripheral.	string	none
<code>systmr_freq</code>	Specify the clock frequency of the system timer device: <ul style="list-style-type: none"> <li>For the <code>xps_timer</code>, it is the OPB clock frequency.</li> <li>For the <code>axi_timer</code>, it is the frequency of the AXI bus to which the <code>axi_timer</code> is connected.</li> <li>For the <code>fit_timer</code>, it is the clock given to the <code>fit_timer</code>.</li> <li>For PowerPC 405 processor, it is the frequency of the PowerPC 405.</li> </ul>	numeric	100000000
<code>systmr_interval</code>	Time interval per system timer interrupt. This is automatically determined (and cannot be changed) for the <code>fit_timer</code> .	numeric (milliseconds)	10

1. MicroBlaze only.

## Configuring Interrupt Handling

You can configure the interrupt controller device in the system kernels. Adding this parameter automatically configures multiple interrupt support and the user-level interrupt handling API in the kernel. This also causes the kernel to automatically initialize the interrupt controller. The following table shows the implemented parameters.

**Table 14: Attributes for Copying Kernel Source Files**

Attribute	Description	Type	Defaults
<code>sysintc_spec</code>	Specify the instance name of the interrupt controller device connected to the external interrupt port.	string	null

## Configuring Debug Messages

You can configure that the kernel outputs debug/diagnostic messages through its execution flow. Enabling the parameter in the following table makes the `DBG_PRINT` macro available, and subsequently its output to the standard output device:

**Table 15: Attribute for Debug Messages**

Attribute	Description	Type	Defaults
<code>debug_mode</code>	Turn on kernel debug messages.	boolean	false

## Coping Kernel Source Files

You can copy the configured kernel source files to your repository for further editing and use them for building the kernel. The following table shows the implemented parameters:

**Table 16: Attributes for Copying Kernel Source Files**

Attribute	Description	Type	Defaults
<code>copyoutfiles</code>	Need to copy source files.	boolean	false
<code>copytodir</code>	User repository directory. The path is relative to <i>project_directory</i> / <i>system_name</i> / <i>libsrc</i> / <i>xilkernel_v5_00_a</i> / <i>src_dir</i> .	path string	<code>"../copyoflib"</code>

## Debugging Xilkernel

The entire kernel image is a single file that can serve as the target for debugging with the EDK GNU Debugger (GDB) mechanism. User applications and the library must be compiled with a `-g`. Refer to the *Embedded System Tools Reference Manual (UG111)* for documentation on how to debug applications with GDB. A link to this document is available in the [“Additional Resources,” page 2](#).

**Note:** This method of debugging involves great visibility into the kernel and is intrusive. Also, this debugging scheme is *not* kernel-user application aware.

## Memory Footprint

The size of Xilkernel depends on the user configuration. It is small in size and can fit in different configurations. The following table shows the memory size output from GNU size utility for the kernel. Xilkernel has been tested with the GNU Compiler Collection (GCC) optimization flag of -O2; the numbers in the table are from the same optimization level.

**Table 17: User Configuration and Xilkernel Size**

Configuration	MicroBlaze (in kb)	PowerPC (in kb)
Basic kernel functionality with multi-threading only.	7	16
Full kernel functionality with round-robin scheduling (no multiple interrupt support and no enhanced features).	16	26
Full kernel functionality with priority scheduling (no multiple interrupt support and no enhanced features).	16.5	26.5
Full kernel functionality with all modules (threads, support for both ELF processes, priority scheduling, IPC, synchronization constructs, buffer malloc, multiple and user level interrupt handling, drivers for interrupt controller and timer, enhanced features).	22	32

## Xilkernel File Organization

Xilkernel sources are organized as shown in the table below:

**Table 18: Organization of Xilkernel Sources**

root/				Contains the /data and the /src folders.
	data/			Contains Microprocessor Library Definition (MLD) and Tcl files that determine XilKernel configuration.
	src/			Contains all the source.
		include/		Contains header files organized similar to /src.
		src/		Non-header source files.
			arch/	Architecture-specific sources.
			sys/	System-level sources.
			ipc/	Sources that implement the IPC functionality.

## Modifying Xilkernel

You can further customize Xilkernel by changing the actual code base. To work with a custom copy of Xilkernel, you must first copy the Xilkernel source folder `xilkernel_v5_01_a` from the EDK installation and place it in a software repository; for example, `<.../mylibraries/bsp/xilkernel_v5_01_a>`. If the repository path is added to the tools, Libgen picks up the source folder of Xilkernel for compilation.

Refer to “[Xilkernel File Organization](#),” page 50 for more information on the organization of the Xilkernel sources. Xilkernel sources have been written in an elementary and intuitive style and include comment blocks above each significant function. Each source file also carries a comment block indicating its role.

## Deprecated Features

### ELF Process Management (Deprecated)

A deprecated feature of Xilkernel is the support for creating execution contexts out of separate Executable Linked Files (ELFs).

You might do this if you need to create processes out of executable files that lay on a file system (such as XiFATFS or XiMFS). Typically, a loader is required, which Xilkernel does not provide. Assuming that your application does involve a loader, then given an entry point in memory to the executable, Xilkernel can then create a process. The kernel does not allocate a separate stack for such processes; the stack is set up as a part of the CRT of the separate executable.

**Note:** Such separate executable ELF files, which are designed to run on top of Xilkernel, must be compiled with the compiler flag `-xl-mode-xilkernel` for MicroBlaze processors. For PowerPC processors, you must use a custom linker script, that does not include the `.boot` and the `.vectors` sections in the final ELF image. The reason that these modifications are required is that, by default, any program compiled with the EDK GNU tool flow, could potentially contain sections that overwrite the critical interrupt, exception, and reset vectors section in memory. Xilkernel requires that its own ELF image initialize these sections and that they stay intact. Using these special compile flags and linker scripts, removes these sections from the output image for applications.

The separate executable mode has the following caveats:

- Global pointer optimization is not supported.  
**Note:** This is supported in the default kernel linkage mode. It is not supported only in this separate executable mode.
- Xilkernel does not feature a loader when creating new processes and threads. It creates process and thread contexts to start of from memory images assumed to be initialized. Therefore, if any ELF file depends on initialized data sections, then the next time the same memory image is used to create a process, the initialized sections are invalid, unless some external mechanism is used to reload the ELF image before creating the process.

**Note:** This feature is deprecated. Xilinx encourages use of the standard, single executable file application model.

Refer to the [“Configuring ELF Process Management \(Deprecated\),” page 52](#) for more details. An ELF process is created and handled using the following interfaces.

---

```
int elf_process_create(void* start_addr, int prio)
```

Parameters	<p><code>start_addr</code> is the start address of the process.</p> <p><code>prio</code> is the starting priority of the process in the system.</p>
Returns	<ul style="list-style-type: none"> <li>• The PID of the new process on success.</li> <li>• -1 on failure.</li> </ul>
Description	Creates a new process. Allocates a new PID and Process Control Block (PCB) for the process. The process is placed in the appropriate ready queue.
Includes	<code>xmk.h</code> , <code>sys/process.h</code>

```
int elf_process_exit(void)
```

Parameters          None.

Returns             None.

Description         Removes the process from the system.

**Caution!** Do not use this function to terminate a thread.

Includes             xmk.h, sys/process.h

## Configuring ELF Process Management (Deprecated)

You can select the maximum number of processes in the system and the different functions needed to handle processes. The processes and threads that are present in the system on system startup can be configured statically. The following table provides a list of available parameters:

Table 19: Process Management Parameters

Attribute	Description	Type	Defaults
config_elf_process	Need ELF process management. <b>Note:</b> Using config_elf_process requires enhanced_features=true in the kernel configuration.	boolean	true
max_procs	Maximum number of processes in the system.	numeric	10
static_elf_process_table	Configure startup processes that are separate executable files. This is defined to be an array with each element containing the parameters process_start and process_prio.	Array of 2-tuples	none
process_start_addr	Process start address.	Address	none
process_prio	Process priority.	Numeric	none



## Overview

The XilFATFS filesystem access library provides read/write access to files stored on a Xilinx® System ACE compact flash or IBM microdrive device. This library requires the underlying hardware platform to contain the following:

- XPS/AXI System ACE Interface Controller - LogiCore module
- System ACE controller and CompactFlash connector
- CompactFlash card or IBM Microdrive formatted with a FAT12, FAT16, or FAT32 file system

**Caution!** FAT16 is required for the System ACE to directly configure the FPGA but the XilFATFS library can work with the System ACE hardware to support FAT12 and FAT32 also.

You can copy files to the flash device from your PC by plugging the flash or microdrive into a suitable USB adapter or similar device.

If the compact flash or microdrive has multiple partitions, each formatted as a FAT12, FAT16, or FAT32 filesystem, XilFATFS allows the partitions to be accessed with partition names. The first partition is always called A:, the second partition is always called B:, and so on. As noted earlier, the first partition must be FAT16 for the System ACE to directly configure the FPGA.

The following sections provide a summary of the XilFATFS functions and the function descriptions.

## XilFATFS Function Summary

This section provides a list of functions provided by the XilFATFS. The following is a linked list where you can click on the function name to go to the description.

```
void \*sysace\_fopen\(const char \*file, const char \*mode\)  
int sysace\_fread \(void \*buffer, int\_size, int count, void \*file\)  
int sysace\_fwrite\(void \*buffer, int size, int count, void \*file\)  
int sysace\_fclose\(void \*file\)  
int sysace\_mkdir\(const char \*path\)  
int sysace\_chdir\(const char \*path\)  
int sysace\_remove\_dir\(const char \*path\)  
int sysace\_remove\_file\(const char \*path\)
```

## XilFATFS Function Descriptions

**void \*sysace\_fopen**(const char \*file, const char \*mode)

Parameters      *file* is the name of the file on the flash device.  
                     *mode* is "r" or "w".

Returns              A non-zero file handle on success.  
                           0 for failure.

Description        The file name must follow the Microsoft 8.3 naming convention of an eight character file name followed by a '.' and a three character extension. For example: test.txt.  
                           This function returns a file handle that has to be used for subsequent calls to read, write, or close the file.  
                           If mode is "r" and the named file does not exist on the device, a 0 is returned.

Includes            sysace\_stdio.h

---

**int sysace\_fread** (void \*buffer, int size, int count, void \*file)

Parameters        *buffer* is a pre allocated buffer that is passed in to this procedure, and is used to return the characters read from the device.  
                           *size* is restricted to 1.  
                           *count* is the number of characters to be read.  
                           *file* is the file handle returned by sysace\_fopen.

Returns              Non-zero number of characters actually read for success.  
                           0 for failure.

Description        The preallocated buffer is filled with the characters that are read from the device. The return value indicates the actual number of characters read, while *count* specifies the maximum number of characters to read. The buffer size must be at least *count*. *stream* should be a valid file handle returned by a call to *sysace\_fopen*.

Includes            sysace\_stdio.h

---

**int sysace\_fwrite**(void \*buffer, int size, int count, void \*file)

Parameters        *buffer* is a pre allocated buffer that is passed in to this procedure, and contains the characters to be written to the device.  
                           *size* is restricted to 1.  
                           *count* is the number of characters to be written.  
                           *file* is the file handle returned by sysace\_fopen.

Returns              Non-zero number of characters actually written for success.  
                           0 or -1 for failure.

Description        The pre-allocated buffer is filled (by the caller) with the characters that are to be written to the device. The return value indicates the actual number of characters written, while *count* specifies the maximum number of characters to write. The buffer size must be at least *count*. *stream* should be a valid file handle returned by a call to *sysace\_fopen*. This function might simply return after updating the buffer cache (see CONFIG\_BUFCACHE\_SIZE). To ensure that the data is written to the device, perform a *sysace\_fclose* call.

Includes            sysace\_stdio.h

```
int sysace_fclose(void *file)
```

Parameters      *file*: File handle returned by `sysace_fopen`.

Returns          0 on success.  
-1 on failure.

Description      Closes an open file. This function also synchronizes the buffer cache to memory. If any files were written to using `sysace_fwrite`, then it is necessary to synchronize the data to the disk by performing `sysace_fclose`. If this is not performed, then the disk could possibly become corrupted.

Includes          `sysace_stdio.h`

---

```
int sysace_mkdir(const char *path)
```

Parameters      *path* is the path name of new directory.

Returns          0 on success.  
-1 on failure.

Description      Create a new directory specified by *path*. The directory name can be either absolute or relative, and must follow the 8.3 file naming convention.

Examples: `a:\\dirname`, `a:\\dirname.dir`,  
`a:\\dir1\\dirnew`, `dirname`, `dirname.dir`

If a relative path is specified, and the current working directory is not already set, the current working directory defaults to the root directory.

Includes          `sysace_stdio.h`

---

```
int sysace_chdir(const char *path)
```

Parameters      *path* is the path name of new directory

Returns          0 on success  
-1 on failure

Description      Create a new directory specified by *path*. The directory name can be either absolute or relative, and must follow the 8.3 file naming convention.

Examples: `a:\\dirname`, `a:\\dirname.dir`,  
`a:\\dir1\\dirnew`, `dirname`, `dirname.dir`

If a relative path is specified, and the current working directory is not already set, the current working directory defaults to the root directory.

Includes          `sysace_stdio.h`

```
int sysace_remove_dir(const char *path)
```

Parameters      *path* is the full path to the directory that must be deleted.

Returns          0 on success  
Negative integer on failure.

Description      Remove the file or directory specified by the path. Available only when the CONFIG\_WRITE parameter to XilFATFS is set.

Includes          sysace\_stdio.h

```
int sysace_remove_file(const char *path)
```

Parameters      *path* is the full path to the file that must be deleted.

Returns          0 on success.  
Negative integer on failure.

Description      Remove the file or directory specified by the path. These functions are available only when the CONFIG\_WRITE parameter to XilFATFS is set.

Includes          sysace\_stdio.h

## Libgen Customization

XilFATFS file system can be integrated with a system using the following snippet in the Microprocessor Software Specification (MSS) file:

```
BEGIN LIBRARY
  parameter LIBRARY_NAME = xilfatfs
  parameter LIBRARY_VER = 1.00.a
  parameter CONFIG_WRITE = true
  parameter CONFIG_DIR_SUPPORT = false
  parameter CONFIG_FAT12 = false
  parameter CONFIG_MAXFILES = 5
  parameter CONFIG_BUFCACHE_SIZE = 10240
  parameter PROC_INSTANCE = powerpc_0
END LIBRARY
```

Parameter description:

- When CONFIG\_WRITE is set to true, write capabilities are added to the library.
- When CONFIG\_DIR\_SUPPORT is set to true, the mkdir and chdir functions are added to the library. For mkdir() function to work, CONFIG\_WRITE needs to be enabled.
- When CONFIG\_FAT12 is set to true, the library is configured to work with FAT12 file systems. Otherwise, the library works with both FAT16 and FAT32 file systems.
- CONFIG\_MAXFILES limits the maximum number of files that can be open. This influences the amount of memory allocated statically by XilFATFS.
- CONFIG\_BUFCACHE\_SIZE: defines the amount of memory (in bytes) used by the library for buffering reads and write calls to the System ACE. This improves the performance of both sysace\_fread and sysace\_fwrite by buffering the data in memory and avoiding unnecessary calls to read the CF device. The buffers are synced up to the device only on a sysace\_fclose call; consequently, it is essential to perform a sysace\_fclose if any file was modified.
- The parameter PROC\_INST is not necessary for uniprocessor systems. In a multiprocessor system, set PROC\_INST to the processor name for which the library must be compiled. The System ACE peripheral must be reachable from this processor.

## Overview

The LibXil MFS provides the capability to manage program memory in the form of file handles. You can create directories and have files within each directory. The file system can be accessed from the high-level C language through function calls specific to the file system.

## MFS Functions

This section provides a linked summary and descriptions of MFS functions.

### MFS Function Summary

The following list is a linked summary of the supported MFS functions. Descriptions of the functions are provided after the summary table. You can click on a function in the summary list to go to the description.

```
void mfs_init_fs(int numbytes, _char_ *address, _int init_type)
void mfs_init_genimage(int numbytes, char *address, int init_type)
int mfs_change_dir(char_ *newdir)
int mfs_create_dir(char *newdir)
int mfs_delete_dir(char *dirname) 3
int mfs_get_current_dir_name(char *dirname)
int mfs_delete_file(char *filename) 3
int mfs_rename_file(char *from_file, char *to_file)
int mfs_exists_file(char *filename)
int mfs_get_usage(int *num_blocks_used, int *num_blocks_free)
int mfs_dir_open(char *dirname)
int mfs_dir_close(int fd)
int mfs_dir_read(int fd, char_ **filename, int *filesize, int *filetype)
int mfs_file_open(char *filename, int mode)
int mfs_file_read(int fd, char *buf, int buflen)
int mfs_file_write(int fd, char *buf, int buflen)
int mfs_file_close(int fd)
long mfs_file_lseek(int fd, long offset, int whence)
```

## MFS Function Descriptions

---

```
void mfs_init_fs(int numbytes, char *address, int
    init_type)
```

**Parameters**     *numbytes* is the number of bytes of memory available for the file system.  
                   *address* is the starting(base) address of the file system memory.  
                   *init\_type* is MFSINIT\_NEW, MFSINIT\_IMAGE, or MFSINIT\_ROM\_IMAGE.

**Description**     Initialize the memory file system. This function must be called before any file system operation. Use `mfs_init_genimage` instead of this function if the filesystem is being initialized with an image generated by `mfsgen`. The status/mode parameter determines certain filesystem properties:

- MFSINIT\_NEW creates a new, empty file system for read/write.
- MFSINIT\_IMAGE initializes a filesystem whose data has been previously loaded into memory at the base address.
- MFSINIT\_ROM\_IMAGE initializes a Read-Only filesystem whose data has been previously loaded into memory at the base address.

**Includes**         `xilmfs.h`

---

```
void mfs_init_genimage(int numbytes, char *address, int
    init_type)
```

**Parameters**     *numbytes* is the number of bytes of memory in the image generated by the `mfsgen` tool. This is equal to the size of the memory available for the file system, plus 4.  
                   *address* is the starting(base) address of the image.  
                   *init\_type* is either MFSINIT\_IMAGE or MFSINIT\_ROM\_IMAGE

**Description**     Initialize the memory file system with an image generated by `mfsgen`. This function must be called before any file system operation. The status/mode parameter determines certain filesystem properties:

- MFSINIT\_IMAGE initializes a filesystem whose data has been previously loaded into memory at the base address.
- MFSINIT\_ROM\_IMAGE initializes a Read-Only filesystem whose data has been previously loaded into memory at the base address.

**Includes**         `xilmfs.h`

---

```
int mfs_change_dir(char *newdir)
```

**Parameters**     *newdir* is the chdir destination.

**Returns**         1 on success.  
                   0 on failure.

**Description**     If *newdir* exists, make it the current directory of MFS. Current directory is not modified in case of failure.

**Includes**         `xilmfs.h`

---

```
int mfs_create_dir(char *newdir)
```

Parameters	<i>newdir</i> is the directory name to be created.
Returns	Index of new directory in the file system on success. 0 on failure.
Description	Create a new empty directory called <i>newdir</i> inside the current directory.
Includes	<code>xilmfs.h</code>

---

```
int mfs_delete_dir(char *dirname)
```

Parameters	<i>dirname</i> is the directory to be deleted.
Returns	Index of new directory in the file system on success. 0 on failure.
Description	Delete the directory <i>dirname</i> , if it exists and is empty.
Includes	<code>xilmfs.h</code>

---

```
int mfs_get_current_dir_name(char *dirname)
```

Parameters	<i>dirname</i> is the current directory name.
Returns	1 on success. 0 on failure.
Description	Return the name of the current directory in a preallocated buffer, <i>dirname</i> , of at least 16 chars. It does not return the absolute path name of the current directory, but just the name of the current directory.
Includes	<code>xilmfs.h</code>

---

```
int mfs_delete_file(char *filename)
```

Parameters	<i>filename</i> is the file to be deleted.
Returns	1 on success. 0 on failure.
Description	Delete <i>filename</i> from the directory.
Includes	<code>xilmfs.h</code>

**Caution!** This function does not completely free up the directory space used by the file. Repeated calls to create and delete files can cause the filesystem to run out of space.

```
int mfs_rename_file(char *from_file, char *to_file)
```

Parameters	<i>from_file</i> is the original filename. <i>to_file</i> is the new file name.
Returns	1 on success. 0 on failure.
Description	Rename <i>from_file</i> to <i>to_file</i> . Rename works for directories as well as files. Function fails if <i>to_file</i> already exists.
Includes	xilmfs.h

---

```
int mfs_exists_file(char *filename)
```

Parameters	<i>filename</i> is the file or directory to be checked for existence.
Returns	0 if <i>filename</i> does not exist. 1 if <i>filename</i> is a file. 2 if <i>filename</i> is a directory.
Description	Check if the file/directory is present in current directory.
Includes	xilmfs.h

---

```
int mfs_get_usage(int *num_blocks_used, int  
                  *num_blocks_free)
```

Parameters	<i>num_blocks_used</i> is the number of blocks used. <i>num_blocks_free</i> is the number of free blocks.
Returns	1 on success. 0 on failure.
Description	Get the number of used blocks and the number of free blocks in the file system through pointers.
Includes	xilmfs.h

---

```
int mfs_dir_open(char *dirname)
```

Parameters	<i>dirname</i> is the directory to be opened for reading.
Returns	The index of <i>dirname</i> in the array of open files on success. -1 on failure.
Description	Open directory <i>dirname</i> for reading. Reading a directory is done using <code>mfs_dir_read( )</code> .
Includes	xilmfs.h



```
int mfs_dir_close(int fd)
```

Parameters	<i>fd</i> is file descriptor return by open.
Returns	1 on success. 0 on failure.
Description	Close the dir pointed by <i>fd</i> . The file system regains the fd and uses it for new files.
Includes	xilmfs.h

---

```
int mfs_dir_read(int fd, char **filename,  
int *filesize, int *filetype)
```

Parameters	<p><i>fd</i> is the file descriptor return by open; passed to this function by caller.</p> <p><i>filename</i> is the pointer to file name at the current position in the directory in MFS; this value is filled in by this function.</p> <p><i>filesize</i> is the pointer to a value filled in by this function: Size in bytes of filename, if it is a regular file; Number of directory entries if filename is a directory.</p> <p><i>filetype</i> is the pointer to a value filled in by this function: MFS_BLOCK_TYPE_FILE if <i>filename</i> is a regular file. MFS_BLOCK_TYPE_DIR if <i>filename</i> is a directory.</p>
Returns	1 on success. 0 on failure.
Description	Read the current directory entry and advance the internal pointer to the next directory entry. <i>filename</i> , <i>filetype</i> , and <i>filesize</i> are pointers to values stored in the current directory entry.
Includes	xilmfs.h

---

```
int mfs_file_open(char *filename, int mode)
```

Parameters	<p><i>filename</i> is the file to be opened.</p> <p><i>mode</i> is Read/Write or Create.</p>
Returns	The index of filename in the array of open files on success. -1 on failure.
Description	<p>Open file filename with given mode. The function should be used for files and not directories:</p> <ul style="list-style-type: none"> <li>• <code>MODE_READ</code>, no error checking is done (if file or directory).</li> <li>• <code>MODE_CREATE</code> creates a file and not a directory.</li> <li>• <code>MODE_WRITE</code> fails if the specified file is a DIR.</li> </ul>
Includes	xilmfs.h

```
int mfs_file_read(int fd, char *buf, int buflen)
```

Parameters	<i>fd</i> is the file descriptor return by open. <i>buf</i> is the destination buffer for the read. <i>buflen</i> is the length of the buffer.
Returns	Number of bytes read on success. 0 on failure.
Description	Read <i>buflen</i> number bytes and place it in <i>buf</i> . <i>fd</i> should be a valid index in “open files” array, pointing to a file, not a directory. <i>buf</i> should be a pre-allocated buffer of size <i>buflen</i> or more. If fewer than <i>buflen</i> chars are available then only that many chars are read.
Includes	<code>xilmfs.h</code>

```
int mfs_file_write(int fd, char *buf, int buflen)
```

Parameters	<i>fd</i> is the file descriptor return by open. <i>buf</i> is the source buffer from where data is read. <i>buflen</i> is the length of the buffer.
Returns	1 on success. 0 on failure.
Description	Write <i>buflen</i> number of bytes from <i>buf</i> to the file. <i>fd</i> should be a valid index in open_files array. <i>buf</i> should be a pre-allocated buffer of size <i>buflen</i> or more.  <b>Caution!</b> Writing to locations other than the end of the file is not supported. Using <code>mfs_file_lseek( )</code> go to some other location in the file then calling <code>mfs_file_write( )</code> is not supported
Includes	<code>xilmfs.h</code>

```
int mfs_file_close(int fd)
```

Parameters	<i>fd</i> is the file descriptor return by open.
Returns	1 on success. 0 on failure.
Description	Close the file pointed by <i>fd</i> . The file system regains the <i>fd</i> and uses it for new files.
Includes	<code>xilmfs.h</code>

```
long mfs_file_lseek(int fd, long offset, int whence)
```

Parameters	<p><i>fd</i> is the file descriptor return by open.</p> <p><i>offset</i> is the number of bytes to seek.</p> <p><i>whence</i> is the file system dependent mode:</p> <ul style="list-style-type: none"> <li>• <code>MFS_SEEK_END</code>, then <i>offset</i> can be either 0 or negative, otherwise <i>offset</i> is non-negative.</li> <li>• <code>MFS_SEEK_CURR</code>, then <i>offset</i> is calculated from the current location.</li> <li>• <code>MFS_SEEK_SET</code>, then <i>offset</i> is calculated from the start of the file.</li> </ul>
Returns	<p>Returns <i>offset</i> from the beginning of the file to the current location on success.</p> <p>-1 on failure: the current location is not modified.</p>
Description	<p>Seek to a given <i>offset</i> within the file at location <i>fd</i> in <code>open_files</code> array.</p> <p><b>Caution!</b> It is an error to seek before beginning of file or after the end of file.</p> <p><b>Caution!</b> Writing to locations other than the end of the file is not supported. Using the <code>mfs_file_lseek( )</code> function or going to some other location in the file then calling <code>mfs_file_write( )</code> is not supported.</p>
Includes	<code>xilmfs.h</code>

## Utility Functions

The following subsections provide a summary and the descriptions of the utility functions that can be used along with the MFS. These functions are defined in `mfs_filesys_util.c` and are declared in `xilmfs.h`.

### Utility Function Summary

The following list is a linked summary of the supported MFS Utility functions. Descriptions of the functions are provided after the summary table. You can click on a function in the summary list to go to the description.

```
int mfs_ls(void)
int mfs_ls_r(int recurse)
int mfs_cat(char* filename)
int mfs_copy_stdin_to_file(char *filename)
int mfs_file_copy(char *from_file, char *to_file)
```

## Utility Function Descriptions

---

```
int mfs_ls(void)
```

Parameters	None.
Returns	1 on success. 0 on failure.
Description	List contents of current directory on <code>STDOUT</code> .
Includes	<code>xilmfs.h</code>

---

```
int mfs_ls_r(int recurse)
```

Parameters	<i>recurse</i> controls the amount of recursion: <ul style="list-style-type: none"> <li>• 0 lists the contents of the current directory and stop.</li> <li>• &gt; 0 lists the contents of the current directory and any subdirectories up to a depth of <i>recurse</i>.</li> <li>• = -1 completes recursive directory listing with no limit on recursion depth.</li> </ul>
Returns	1 on success. 0 on failure.
Description	List contents of current directory on <code>STDOUT</code> .
Includes	<code>xilmfs.h</code>

---

```
int mfs_cat(char* filename)
```

Parameters	<i>filename</i> is the file to be displayed.
Returns	1 on success. 0 on failure.
Description	Print the file to <code>STDOUT</code> .
Includes	<code>xilmfs.h</code>

---

```
int mfs_copy_stdin_to_file(char *filename)
```

Parameters	<i>filename</i> is the destination file.
Returns	1 on success. 0 on failure.
Description	Copy from <code>STDIN</code> to named file. An end-of-file (EOF) character should be sent from <code>STDIN</code> to allow the function to return 1.
Includes	<code>xilmfs.h</code>

```
int mfs_file_copy(char *from_file, char *to_file)
```

Parameters	<i>from_file</i> is the source file. <i>to_file</i> is the destination file.
Returns	1 on success. 0 on failure.
Description	Copy <i>from_file</i> to <i>to_file</i> . Copy fails if <i>to_file</i> already exists or either from or to location cannot be opened.
Includes	<code>xilmfs.h</code>

## Additional Utilities

The `mfsngen` program is provided along with the MFS library. You can use `mfsngen` to create an MFS memory image on a host system that can be subsequently downloaded to the embedded system memory. The `mfsngen` links to LibXil MFS and is compiled to run on the host machine rather than the target MicroBlaze™ or PowerPC® processor system. Conceptually, this is similar to the familiar `zip` or `tar` programs.

An entire directory hierarchy on the host system can be copied to a local MFS file image using `mfsngen`. This file image can then be downloaded on to the memory of the embedded system for creating a pre-loaded file system.

Test programs are included to illustrate this process. For more information, see the `readme.txt` file in the `utils` sub-directory.

Usage: **mfsngen** **-{c t | x}** **vsb** *num\_blocks* **f** *mfs\_filename*

Specify exactly one of `c`, `t`, or `x` modes

`c`: creates an mfs file system image using the list of files specified on the command line (directories specified in this list are traversed recursively).

`t`: lists the files in the mfs file system image

`x`: extracts the mfs file system from image to host file system

`v`: is verbose mode

`s`: switches endianness

`b`: lists the number of blocks (*num\_blocks*) which should be more than 2

- If the `b` option is specified, the *num\_blocks* value should be specified
- If the `b` option is omitted, the default value of *num\_blocks* is 5000
- The `b` option is meaningful only when used in conjunction with the `c` option

`f`: specify the host file name (*mfs\_filename*) where the mfs file system image is stored

- If the `f` option is specified, the mfs filename should be specified
- If the `f` option is omitted, the default file name is `filesystem.mfs`

## Libgen Customization

A memory file system can be integrated with a system using the following snippet in the Microprocessor Software Specification (MSS) file.

```
BEGIN LIBRARY
  parameter LIBRARY_NAME = xilmfs
  parameter LIBRARY_VER = 1.00.a
  parameter numbytes= 50000
  parameter base_address = 0xffe00000
  parameter init_type = MFSINIT_NEW
  parameter need_utils = false
END
```

The memory file system must be instantiated with the name **xilmfs**. The following table lists the attributes used by Libgen.

**Table 1: Attributes for Including Memory File System**

Attributes	Description
numbytes	Number of bytes allocated for file system.
base_address	Starting address for file system memory.
init_type	Options are: <ul style="list-style-type: none"> <li>MFSINIT_NEW (default) creates a new, empty file system.</li> <li>MFSINIT_ROM_IMAGE creates a file system based on a pre-loaded memory image loaded in memory of size <i>numbytes</i> at starting address <i>base_address</i>. This memory is considered read-only and modification of the file system is not allowed.</li> <li>MFS_INIT_IMAGE is similar to the previous option except that the file system can be modified, and the memory is readable and writable.</li> </ul>
need_utils	true or false (default = false) If true, this causes <code>stdio.h</code> to be included from <code>mfs_config.h</code> . The functions described in “Utility Functions,” page 7 require that you have defined <code>stdin</code> or <code>stdout</code> . Setting the <code>need_utils</code> to true causes <code>stdio.h</code> to be included. <b>Caution!</b> The underlying software and hardware platforms must support <code>stdin</code> and <code>stdout</code> peripherals for these utility functions to compile and link correctly.

## Overview

The lwIP is an open source TCP/IP protocol suite available under the BSD license. The lwIP is a standalone stack; there are no operating systems dependencies, although it can be used along with operating systems. The lwIP provides two APIs for use by applications:

- RAW API: Provides access to the core lwIP stack.
- Socket API: Provides a BSD sockets style interface to the stack.

The `lwip140_v1_03_a` is an EDK library that is built on the open source lwIP library version 1.4.0. The `lwip140_v1_03_a` library provides adapters for the Ethernetlite (`xps_ethernetlite`, `axi_ethernetlite`), the TEMAC (`xps_ll_temac`, `axi_ethernet`), and the Gigabit Ethernet controller and MAC (GigE) cores. The library can run on MicroBlaze™, PowerPC® 405, PowerPC 440, and ARM Cortex-A9 processors. The Ethernetlite and TEMAC cores apply for MicroBlaze and PowerPC systems. The Gigabit Ethernet controller and MAC (GigE) core is applicable only for ARM Cortex-A9 system (Zynq™ devices).

## Features

The lwIP provides support for the following protocols:

- Internet Protocol (IP)
- Internet Control Message Protocol (ICMP)
- User Datagram Protocol (UDP)
- TCP (Transmission Control Protocol (TCP)
- Address Resolution Protocol (ARP)
- Dynamic Host Configuration Protocol (DHCP)
- Internet Group Message Protocol (IGMP)

## Additional Resources

- lwIP wiki: <http://lwip.scribblewiki.com>
- Xilinx® lwIP designs and application examples:  
[http://www.xilinx.com/support/documentation/application\\_notes/xapp1026.pdf](http://www.xilinx.com/support/documentation/application_notes/xapp1026.pdf)
- lwIP examples using RAW and Socket APIs: <http://savannah.nongnu.org/projects/lwip/>
- FreeRTOS Port for Zynq is available for download from the FreeRTOS website:  
[http://www.freertos.org/Interactive\\_Frames/Open\\_Frames.html](http://www.freertos.org/Interactive_Frames/Open_Frames.html) <http://interactive.freertos.org/forums>

## Using lwIP

The following sections detail the hardware and software steps for using lwIP for networking in an EDK system. The key steps are:

1. Creating a hardware system containing the processor, ethernet core, and a timer. The timer and ethernet interrupts must be connected to the processor using an interrupt controller.
2. Configuring `lwip140_v1_03_a` to be a part of the software platform. For operating with lwIP socket API, the Xilkernel library or FreeRTOS BSP is a prerequisite. See the Note below.

**Note:** The Xilkernel library is available only for MicroBlaze and PowerPC systems. For Cortex-A9 based systems (Zynq), there is no support for Xilkernel. Instead, use FreeRTOS. A FreeRTOS BSP is available for Zynq systems and must be included for using lwIP socket API.

## Setting up the Hardware System


This section describes the hardware configurations supported by lwIP. The key components of the hardware system include:

- Processor: Either a PowerPC (405 or 440), a MicroBlaze, or a Cortex-A9 processor. The Cortex-A9 processor applies to Zynq systems.
- MAC: LwIP supports `xps_ethernetlite`, `axi_ethernetlite`, `xps_ll_temac`, `axi_ethernet`, and Gigabit Ethernet controller and MAC (GigE) cores.
- Timer: to maintain TCP timers, lwIP raw API based applications require that certain functions are called at periodic intervals by the application. An application can do this by registering an interrupt handler with a timer.
- DMA: For `xps-ll-temac` or `axi_ethernet` based systems, the `xps-ll-temac` or the `axi_ethernet` cores can be configured with a soft DMA engine or a fifo interface. For GigE-based Zynq systems, there is a built-in DMA and so no extra configuration is needed. Same applies to `xps_ethernetlite` and `axi_ethernetlite` based systems, which have their built-in buffer management provisions.

The following figure shows a system architecture in which the system is using an `xps_ethernetlite` core.

The system has a processor connected to a Multi-Port Memory Controller (MPMC) with the other required peripherals (timer and ethernetlite) on the PLB v4.6 bus. Interrupts from both the timer and the ethernetlite are required, so interrupts are connected to the interrupt controller.

Figure 1 illustrates a system architecture using the `xps_ethernetlite` core.



X11003

Figure 1: System Architecture using `xps_ethernetlite` Core



When using TEMAC, the system architecture changes depending on whether DMA is required. If DMA is required, a fourth port (of type SDMA), which provides direct connection between the TEMAC (`xps_ll_temac`) and the memory controller (MPMC), is added to the memory controller. Figure 2 shows this system architecture.




Figure 2: System Architecture using `xps_ll_temac` Core (with DMA)

**Note:** There are four interrupts that are necessary in this case: a timer interrupt, a TEMAC interrupt, and the SDMA RX and TX interrupts. The SDMA interrupts are from the Multi-Port Memory Controller (MPMC) SDMA Personality Interface Module (PIM). Refer to the *Multi-Port Memory Controller (MPMC) Data Sheet (DS643)* for more information.

If the TEMAC is used without DMA, a FIFO (`xps_ll_fifo`) is used to interface to the TEMAC. The system architecture in this case is shown in Figure 3.




Figure 3: System Architecture using TEMAC with `xps_ll_fifo` (without DMA)

Figure 4 shows a sample system architecture with a Spartan®-6 device utilizing the axi\_ethernet core with DMA.




Figure 4: System Architecture using axi\_ethernet core with DMA

## Setting up the Software System

To use lwIP in a software application, you must first compile the lwIP library as part of software application.

To move the hardware design to SDK, you must first export it from XPS.

1. Select **Project > Export Hardware Design to SDK**.
2. On the Export to SDK dialog box that opens, click **Export & Launch SDK**.

XPS exports the design to SDK. SDK opens and prompts you to create a workspace.

After SDK opens with hw\_platform already present in the Project Explorer, compile the lwIP library:

1. Select **File > New > Xilinx Board Support Package**.

The New Board Support Package window opens.

2. Give the project a name and select a location for it. Select XilKernel, Standalone, or FreeRTOS, and click **Finish**.

**Note:** For Zynq there is no option for XilKernel. FreeRTOS must be used for Zynq. The FreeRTOS BSP for Zynq is available for download from:

[http://www.freertos.org/Interactive\\_Frames/Open\\_Frames.html?http://interactive.freertos.org/forums](http://www.freertos.org/Interactive_Frames/Open_Frames.html?http://interactive.freertos.org/forums)

Follow the steps provided in the pdf document provided with the port to use the FreeRTOS BSP.

The Board Support Package Settings window opens.

3. Select the lwip140 library with version 1.03.a.  
On the left side of the SDK window, lwip140 appears in the list of libraries to be compiled.
4. Select lwip140 in the Project Explorer tab. The configuration options for lwIP are listed. Configure the lwIP and click **OK**.

The board support package automatically builds with lwIP included in it.

## Configuring lwIP Options

The lwIP provides configurable parameters. The values for these parameters can be changed in SDK. There are two major categories of configurable options:

- Xilinx Adapter to lwIP options: These control the settings used by Xilinx adapters for the ethernet cores.
- Base lwIP options: These options are part of lwIP library itself, and include parameters for TCP, UDP, IP and other protocols supported by lwIP.

The following sections describe the available lwIP configurable options.

## Customizing lwIP API Mode

The `lwip140_v1_03_a` supports both raw API and socket API:

- The raw API is customized for high performance and lower memory overhead. The limitation of raw API is that it is callback-based, and consequently does not provide portability to other TCP stacks.
- The socket API provides a BSD socket-style interface and is very portable; however, this mode is not as efficient as raw API mode in performance and memory requirements.

The `lwip140_v1_03_a` also provides the ability to set the priority on TCP/IP and other lwIP application threads. [Table 1](#) provides lwIP library API modes.

**Table 1: API Mode Options and Descriptions**

Attribute/Options	Description	Type	Default
<b>api_mode</b> {RAW_API   SOCKET_API}	The lwIP library mode of operation.	enum	RAW_API
<b>socket_mode_thread_prio</b> <i>integer</i>	<p>Priority of lwIP TCP/IP thread and all lwIP application threads.</p> <p>This setting applies only when Xilkernel is used in priority mode.</p> <p>It is recommended that all threads using lwIP run at the same priority level.</p> <p>For GigE based Zynq systems using FreeRTOS, appropriate priority should be set. The default priority of 1 will not give the expected behavior.</p> <p>For FreeRTOS (Zynq systems), all internal lwIP tasks (except the main TCP/IP task) are created with the priority level set for this attribute. The TCP/IP task is given a higher priority than other tasks for improved performance. The typical TCP/IP task priority is 1 more than the priority set for this attribute for FreeRTOS.</p>	integer	1

## Configuring Xilinx Adapter Options

The Xilinx adapters for EMAC/GigE cores are configurable.

## Ethernetlite Adapter Options

Table 2 provides the configuration parameters for the `xps_ethernetlite` adapter.

Table 2: `xps_ethernetlite` Adapter Options

Attribute	Description	Type	Default
<code>sw_rx_fifo_size</code>	Software Buffer Size in bytes of the receive data between EMAC and processor	integer	8192
<code>sw_tx_fifo_size</code>	Software Buffer Size in bytes of the transmit data between processor and EMAC	integer	8192

## TEMAC Adapter Options

Table 3 provides the configuration parameters for the `xps_ll_temac`, `axi_ethernet` and GigE adapters.

Table 3: `xps_ll_temac/axi-ethernet/GigE` Adapter

Attribute	Default	Type	Description
<code>n_tx_descriptors</code>	64	integer	Number of Tx descriptors to be used. For high performance systems there might be a need to use a higher value for this.
<code>n_rx_descriptors</code>	64	integer	Number of Rx descriptors to be used. For high performance systems there might be a need to use a higher value for this. Typical values are 128 and 256.
<code>n_tx_coalesce</code>	1	integer	Setting for Tx interrupt coalescing <sup>1</sup>
<code>n_rx_coalesce</code>	1	integer	Setting for Rx interrupt coalescing <sup>1</sup>
<code>tcp_rx_checksum_offload</code>	false	boolean	Offload TCP Receive checksum calculation (hardware support required). For GigE in Zynq, the TCP receive checksum offloading is always present, so this attribute does not apply.
<code>tcp_tx_checksum_offload</code>	false	boolean	Offload TCP Transmit checksum calculation (hardware support required). For GigE cores (for Zynq) the TCP transmit checksum offloading is always present, so this attribute does not apply.
<code>tcp_ip_rx_checksum_offload</code>	false	boolean	Offload TCP and IP Receive checksum calculation (hardware support required). Applicable only for AXI systems. For GigE in Zynq the TCP and IP receive checksum offloading is always present, so this attribute does not apply.
<code>tcp_ip_tx_checksum_offload</code>	false	boolean	Offload TCP and IP Transmit checksum calculation (hardware support required). Applicable only for AXI systems. For GigE in Zynq the TCP and IP transmit checksum offloading is always present, so this attribute does not apply.

Table 3: `xps_ll_temac/axi-ethernet/GigE Adapter`

<code>phy_link_speed</code>	enum	CONFIG_LINKSPEED_AUTODETECT	<p>Link speed as auto-negotiated by the PHY. lwIP configures the TEMAC/GigE for this speed setting. This setting must be correct for the TEMAC/GigE to transmit or receive packets.</p> <p><b>Note:</b> The CONFIG_LINKSPEED_AUTODETECT setting attempts to detect the correct link speed by reading the PHY registers; however, this is PHY dependent, and has been tested with the Marvell PHYs present on Xilinx development boards. For other PHYs, select the correct speed.</p>
<code>temac_use_jumbo_frames_experimental</code>	false	boolean	<p>Use TEMAC jumbo frames (with a size up to 9k bytes). If this option is selected, jumbo frames are allowed to be transmitted and received by the TEMAC.</p> <p>For GigE in Zynq there is no support for jumbo frames, so this attribute does not apply.</p>

1. This setting is not applicable for GigE in Zynq.

## Configuring Memory Options

The lwIP stack provides different kinds of memories. Similarly, when the application uses socket mode, different memory options are used. All the configurable memory options are provided as a separate category. Default values work well unless application tuning is required.

The memory parameter options are provided in [Table 4](#):

**Table 4: Memory Parameter Options**

Attribute	Default	Type	Description
mem_size	131072	Integer	Total size of the heap memory available, measured in bytes. For applications which use a lot of memory from heap (using C library malloc or lwIP routine mem_malloc or pbuf_alloc with PBUF_RAM option), this number should be made higher as per the requirements.
memp_n_pbuf	16	Integer	The number of memp struct pbufs. If the application sends a lot of data out of ROM (or other static memory), this should be set high.
memp_n_udp_pcb	4	Integer	The number of UDP protocol control blocks. One per active UDP connection.
memp_n_tcp_pcb	32	Integer	The number of simultaneously active TCP connections.
memp_n_tcp_pcb_listen	8	Integer	The number of listening TC connections.
memp_n_tcp_seg	256	Integer	The number of simultaneously queued TCP segments.
memp_n_sys_timeout	8	Integer	Number of simultaneously active timeouts.
memp_num_netbuf	8	Integer	Number of allowed structure instances of type netbufs. Applicable only in socket mode.
memp_num_netconn	16	Integer	Number of allowed structure instances of type netconns. Applicable only in socket mode.
memp_num_api_msg	16	Integer	Number of allowed structure instances of type api_msg. Applicable only in socket mode.
memp_num_tcpip_msg	64	Integer	Number of tcpip msg structures (socket mode only).

**Note:** Because Sockets Mode support uses Xilkernel services, the number of semaphores chosen in the Xilkernel configuration must take the value set for the `memp_num_netbuf` parameter into account. For FreeRTOS BSP there is no setting for the maximum number of semaphores. For FreeRTOS, you can create semaphores as long as memory is available.

## Configuring Packet Buffer (Pbuf) Memory Options

Packet buffers (Pbufs) carry packets across various layers of the TCP/IP stack. The following are the pbuf memory options provided by the lwIP stack. Default values work well unless

application tuning is required. Table 5 provides the parameters for the Pbuf memory options:

**Table 5: Pbuf Memory Options Configuration Parameters**

Attribute	Default	Type	Description
pbuf_pool_size	256	Integer	Number of buffers in pbuf pool. For high performance systems, you might consider increasing the pbuf pool size to a higher value, such as 512.
pbuf_pool_bufsize	1700	Integer	Size of each pbuf in pbuf pool. For systems that support jumbo frames, you might consider using a pbuf pool buffer size that is more than the maximum jumbo frame size.
pbuf_link_hlen	16	Integer	Number of bytes that should be allocated for a link level header.

## Configuring ARP Options

Table 6 provides the parameters for the ARP options. Default values work well unless application tuning is required.

**Table 6: ARP Options Configuration Parameters**

Attribute	Default	Type	Description
arp_table_size	10	Integer	Number of active hardware address IP address pairs cached.
arp_queueing	1	Integer	If enabled outgoing packets are queued during hardware address resolution. This attribute can have two values: 0 or 1.

## Configuring IP Options

Table 7 provides the IP parameter options. Default values work well unless application tuning is required.

**Table 7: IP Configuration Parameter Options**

Attribute	Default	Type	Description
ip_forward	0	Integer	Set to 1 for enabling ability to forward IP packets across network interfaces. If running lwIP on a single network interface, set to 0. This attribute can have two values: 0 or 1.
ip_options	0	Integer	When set to 1, IP options are allowed (but not parsed). When set to 0, all packets with IP options are dropped. This attribute can have two values: 0 or 1.
ip_reassembly	1	Integer	Reassemble incoming fragmented IP packets.
ip_frag	1	Integer	Fragment outgoing IP packets if their size exceeds MTU.
ip_reass_bufsize	5760	Integer	Reassembly Buffer size.
ip_frag_max_mtu	1500	Integer	Assumed max MTU on any interface for IP fragmented buffer.
ip_default_ttl	255	Integer	Global default TTL used by transport layers.

## Configuring ICMP Options

[Table 8](#) provides the parameter for ICMP protocol option. Default values work well unless application tuning is required.

**Table 8: ICMP Configuration Parameter Option**

Attribute	Default	Type	Description
icmp_ttl	255	Integer	ICMP TTL value. For GigE cores (for Zynq) there is no support for ICMP in the hardware.

## Configuring IGMP Options

The IGMP protocol is supported by lwIP stack. When set true, the following option enables the IGMP protocol.

**Table 9: IGMP Configuration Parameter Option**

Attribute	Default	Type	Description
imgp_options	false	Boolean	Specify whether IGMP is required.

## Configuring UDP Options

[Table 10](#) provides UDP protocol options. Default values work well unless application tuning is required.

**Table 10: UDP Configuration Parameter Options**

Attribute	Default	Type	Description
lwip_udp	true	Boolean	Specify whether UDP is required.
udp_ttl	255	Integer	UDP TTL value.

## Configuring TCP Options

[Table 11](#) provides the TCP protocol options. Default values work well unless application tuning is required.

**Table 11: TCP Options Configuration Parameters**

Attribute	Default	Type	Description
lwip_tcp	true	Boolean	Require TCP.
tcp_ttl	255	Integer	TCP TTL value.
tcp_wnd	2048	Integer	TCP Window size in bytes.
tcp_maxrtx	12	Integer	TCP Maximum retransmission value.
tcp_synmaxrtx	4	Integer	TCP Maximum SYN retransmission value.
tcp_queue_ooseq	1	Integer	Accept TCP queue segments out of order. Set to 0 if your device is low on memory.
tcp_mss	1460	Integer	TCP Maximum segment size.
tcp_snd_buf	8192	Integer	TCP sender buffer space in bytes.



## Configuring DHCP Options

The DHCP protocol is supported by lwIP stack. [Table 12](#) provides DHCP protocol options. Default values work well unless application tuning is required.

**Table 12: DHCP Options Configuration Parameters**

Attribute	Default	Type	Description
lwip_dhcp	false	Boolean	Specify whether DHCP is required.
dhcp_does_arp_check	false	Boolean	Specify whether ARP checks on offered addresses.

## Configuring the Stats Option

lwIP stack has been written to collect statistics, such as the number of connections used; amount of memory used; and number of semaphores used, for the application. The library provides the `stats_display()` API to dump out the statistics relevant to the context in which the call is used. The stats option can be turned on to enable the statistics information to be collected and displayed when the `stats_display` API is called from user code. Use the following option to enable collecting the stats information for the application.

**Table 13: Statistics Option Configuration Parameters**

Attribute	Description	Type	Default
lwip_stats	Turn on lwIP Statistics	int	0

## Configuring the Debug Option

lwIP provides debug information. [Table 14](#) lists all available options.

**Table 14: Debug Option Configuration Parameters**

Attribute	Default	Type	Description
lwip_debug	false	Boolean	Turn on/off lwIP debugging.
ip_debug	false	Boolean	Turn on/off IP layer debugging.
tcp_debug	false	Boolean	Turn on/off TCP layer debugging.
udp_debug	false	Boolean	Turn on/off UDP layer debugging.
icmp_debug	false	Boolean	Turn on/off ICMP protocol debugging.
igmp_debug	false	Boolean	Turn on/off IGMP protocol debugging.
netif_debug	false	Boolean	Turn on/off network interface layer debugging.
sys_debug	false	Boolean	Turn on/off sys arch layer debugging.
pbuf_debug	false	Boolean	Turn on/off pbuf layer debugging.

## Software APIs

lwIP provides two different APIs: RAW mode and Socket mode.

### Raw API

The Raw API is callback based. Applications obtain access directly into the TCP stack and vice-versa. As a result, there is no extra socket layer, and using the Raw API provides excellent performance at the price of compatibility with other TCP stacks.

***Xilinx Adapter Requirements when using RAW API***

In addition to the lwIP RAW API, the Xilinx adapters provide the `xemacif_input` utility function for receiving packets. This function must be called at frequent intervals to move the received packets from the interrupt handlers to the lwIP stack. Depending on the type of packet received, lwIP then calls registered application callbacks.

***Raw API File***

The `$XILINX_EDK/sw/ThirdParty/sw_services/lwip140_v1_03_a/src/lwip-1.4.0/doc/rawapi.txt` file describes the lwIP Raw API.

***Socket API***

The lwIP socket API provides a BSD socket-style API to programs. This API provides an execution model that is a blocking, open-read-write-close paradigm.

***Xilinx Adapter Requirements when using Socket API***

Applications using the Socket API with Xilinx adapters need to spawn a separate thread called `xemacif_input_thread`. This thread takes care of moving received packets from the interrupt handlers to the `tcpip_thread` of the lwIP. Application threads that use lwIP must be created using the lwIP `sys_thread_new` API. Internally, this function makes use of the appropriate thread or task creation routines provided by XilKernel or FreeRTOS.

***Xilkernel/FreeRTOS scheduling policy when using Socket API***

lwIP in socket mode requires the use of the Xilkernel or FreeRTOS, which provides two policies for thread scheduling: round-robin and priority based:

There are no special requirements when round-robin scheduling policy is used because all threads or tasks with same priority receive the same time quanta. This quanta is fixed by the RTOS (Xilkernel or FreeRTOS) being used.

With priority scheduling, care must be taken to ensure that lwIP threads or tasks are not starved. For Xilkernel, lwIP internally launches all threads at the priority level specified in `socket_mode_thread_prio`. For FreeRTOS, lwIP internally launches all tasks except the main TCP/IP task at the priority specified in `socket_mode_thread_prio`. The TCP/IP task in FreeRTOS is launched with a higher priority (one more than priority set in `socket_mode_thread_prio`). In addition, application threads must launch `xemacif_input_thread`. The priorities of both `xemacif_input_thread`, and the lwIP internal threads (`socket_mode_thread_prio`) must be high enough in relation to the other application threads so that they are not starved.

**Using Xilinx Adapter Helper Functions**

The Xilinx adapters provide the following helper functions to simplify the use of the lwIP APIs.

```
void lwip_init()
```

This function provides a single initialization function for the lwIP data structures. This replaces specific calls to initialize stats, system, memory, pbufs, ARP, IP, UDP, and TCP layers.

---

```
struct netif *xemac_add (struct netif *netif, struct
    ip_addr *ipaddr, struct ip_addr *netmask, struct
    ip_addr *gw, unsigned char *mac_ethernet_address
    unsigned mac_baseaddr)
```

The `xemac_add` function provides a unified interface to add any Xilinx EMAC IP as well as GigE core. This function is a wrapper around the lwIP `netif_add` function that initializes the

network interface 'netif' given its IP address `ipaddr`, `netmask`, the IP address of the gateway, `gw`, the 6 byte ethernet address `mac_ethernet_address`, and the base address, `mac_baseaddr`, of the `xps_ethernetlite` or `xps_ll_temac` MAC core.

---

```
void xemacif_input(struct netif *netif)
```

**(RAW mode only)**

The Xilinx lwIP adapters work in interrupt mode. The receive interrupt handlers move the packet data from the EMAC/GigE and store them in a queue. The `xemacif_input` function takes those packets from the queue, and passes them to lwIP; consequently, this function is required for lwIP operation in RAW mode. The following is a sample lwIP application in RAW mode.

```
while (1) {
    /* receive packets */
    xemacif_input(netif);

    /* do application specific processing */
}
```

The program is notified of the received data through callbacks.

---

```
void xemacif_input_thread(struct netif *netif)
```

**(Socket mode only)**

In the socket mode, the application thread must launch a separate thread to receive the input packets. This performs the same work as the RAW mode function, `xemacif_input`, except that it resides in its own separate thread; consequently, any lwIP socket mode application is required to have code similar to the following in its main thread:

```
sys_thread_new("xemacif_input_thread",
    xemacif_input_thread, netif, THREAD_STACK_SIZE, DEFAULT_THREAD_PRIO);
```

The application can then continue launching separate threads for doing application specific tasks. The `xemacif_input_thread` receives data processed by the interrupt handlers, and passes them to the lwIP `tcpip_thread`.

## lwIP Performance

Table 15 provides the maximum TCP throughput achievable by FPGA, CPU, EMAC, and system frequency in RAW modes. Applications requiring high performance should use the RAW API.

Table 15: Library Performance

FPGA	CPU	EMAC	System Frequency	Max TCP Throughput in RAW Mode	
				Rx Side	Tx Side
Virtex®	MicroBlaze	axi-ethernet	100 MHz	182 Mbps	100 Mbps
Virtex	MicroBlaze	xps-ll-temac	100 MHz	178 Mbps	100 Mbps
Virtex	MicroBlaze	xps-ethernetlite	100 MHz	50 Mbps	38 Mbps

## Known Issues and Restrictions

The lwip140\_v1\_03\_a does not support more than one TEMAC within a single xps\_ll\_temac instance. For example, lwip140\_v1\_03\_a does not support the TEMAC enabled by setting C\_TEMAC1\_ENABLED = 1 in xps\_ll\_temac.

## API Examples

Sample applications using the RAW API and Socket API are available on the Xilinx website. This section provides pseudo code that illustrates the typical code structure.

### RAW API

Applications using the RAW API are single threaded, and have the following broad structure:

```
int main()
{
    struct netif *netif, server_netif;
    struct ip_addr ipaddr, netmask, gw;

    /* the MAC address of the board.
     * This should be unique per board/PHY */
    unsigned char mac_ethernet_address[] =
        {0x00, 0x0a, 0x35, 0x00, 0x01, 0x02};

    lwip_init();

    /* Add network interface to the netif_list,
     * and set it as default */
    if (!xemac_add(netif, &ipaddr, &netmask,
        &gw, mac_ethernet_address,
        EMAC_BASEADDR)) {
        printf("Error adding N/W interface\n\r");
        return -1;
    }
    netif_set_default(netif);

    /* now enable interrupts */
    platform_enable_interrupts();

    /* specify that the network if is up */
    netif_set_up(netif);

    /* start the application, setup callbacks */
    start_application();
}
```

```

/* receive and process packets */
while (1) {
    xemacif_input(netif);
    /* application specific functionality */
    transfer_data();
}
}

```

RAW API works primarily using asynchronously called Send and Receive callbacks.

## Socket API

XilKernel-based applications in socket mode can specify a static list of threads that XilKernel spawns on startup in the XilKernel Software Platform Settings dialog box. Assuming that `main_thread()` is a thread specified to be launched by XilKernel, control reaches this first thread from application "main" after the XilKernel schedule is started. In `main_thread`, one more thread (`network_thread`) is created to initialize the MAC layer.

For FreeRTOS (Zynq systems) based applications, once the control reaches application "main" routine, a task (can be termed as `main_thread`) with an entry point function as `main_thread()` is created before starting the scheduler. After the FreeRTOS scheduler starts, the control reaches `main_thread()`, where the lwIP internal initialization happens. The application then creates one more thread (`network_thread`) to initialize the MAC layer.

The following pseudo-code illustrates a typical socket mode program structure.

```

void network_thread(void *p)
{
    struct netif *netif;
    struct ip_addr ipaddr, netmask, gw;

    /* the MAC address of the board.
     * This should be unique per board/PHY */
    unsigned char mac_ethernet_address[] =
        {0x00, 0x0a, 0x35, 0x00, 0x01, 0x02};

    netif = &server_netif;

    /* initialize IP addresses to be used */
    IP4_ADDR(&ipaddr, 192, 168, 1, 10);
    IP4_ADDR(&netmask, 255, 255, 255, 0);
    IP4_ADDR(&gw, 192, 168, 1, 1);

    /* Add network interface to the netif_list,
     * and set it as default */
    if (!xemac_add(netif, &ipaddr, &netmask,
        &gw, mac_ethernet_address,
        EMAC_BASEADDR)) {
        printf("Error adding N/W interface\n\r");
        return;
    }
    netif_set_default(netif);

    /* specify that the network if is up */
    netif_set_up(netif);

    /* start packet receive thread
     - required for lwIP operation */
    sys_thread_new("xemacif_input_thread", xemacif_input_thread,
        netif,
        THREAD_STACKSIZE, DEFAULT_THREAD_PRIO);
}

```

```
/* now we can start application threads */
/* start webserver thread (e.g.) */
sys_thread_new("httpd" web_application_thread, 0,
               THREAD_STACKSIZE DEFAULT_THREAD_PRIO);
}

int main_thread()
{
    /* initialize lwIP before calling sys_thread_new */
    lwip_init();

    /* any thread using lwIP should be created using
     * sys_thread_new() */
    sys_thread_new("network_thread" network_thread, NULL,
                  THREAD_STACKSIZE DEFAULT_THREAD_PRIO);

    return 0;
}
```

## LibXil Isf Library Overview

The LibXil Isf library:

- Allows the user to Write, Read, and Erase the Serial Flash.
- Allows protection of the data stored in the Serial Flash from unwarranted modification by enabling the Sector Protection feature.
- Supports multiple instances of Serial Flash at a time, provided they are of the same device family (Atmel, Intel, STM, Winbond, SST, or Spansion) as the device family is selected at compile time.  
**Note:** Spansion (S25FLXX) devices are not tested. Support for this family of devices is limited to the common commands supported by the other flash families.
- Allows the user application to perform Control operations on Intel, STM, Winbond, SST, and Spansion Serial Flash.
- Requires the underlying hardware platform to contain the xps\_spi, axi\_spi, axi\_quad\_spi, ps7\_spi, or ps7\_qspi device for accessing the Serial Flash.
- Uses the Xilinx® SPI interface drivers in interrupt-driven mode or polled mode for communicating with the Serial Flash. In interrupt mode, the user application must acknowledge any associated interrupts from the Interrupt Controller.
- Requires the user application to track status of initiated operations when in interrupt mode; the transfer is initiated and the control is given back to the user application.
- Added support in the library for SPI PS and QSPI PS. User needs to select one of the interfaces at compile time.

## Supported Devices

Table 1 lists the supported Xilinx In-System Flash and external Serial Flash Memories.

Table 1: Xilinx In-System Flash and External Serial Flash Memories

Device Series	Manufacturer
AT45DB011D AT45DB021D AT45DB041D AT45DB081D AT45DB161D AT45DB321D AT45DB642D	Atmel
S3316MBIT S3332MBIT S3364MBIT M25P05_A M25P10_A M25P20 M25P40 M25P80 M25P16 M25P32 M25P64 M25P128 N25Q32 N25Q64 N25Q128	Intel/ST Microelectronics (STM)/Numonyx <sup>1</sup>
W25Q16 W25Q32 W25Q64 W25Q80 W25Q128 W25X10 W25X20 W25X40 W25X80 W25X16 W25X32 W25X64	Winbond
S25FL004 S25FL008 S25FL016 S25FL032 S25FL064 S25FL128 S25FL129	Spansion <sup>2</sup>
SST25WF080	SST

1. Intel and STM Serial Flash devices are now a part of Serial Flash devices provided by Numonyx.
2. Spansion (S25FLXX) devices are not tested. Support for this family of devices is limited to the common commands supported by the other flash families.



## LibXil Isf Library APIs

This section provides a linked summary and detailed descriptions of the LibXil Isf library APIs.

### API Summary

The following is a summary list of APIs provided by the LibXil Isf library. The list is linked to the API description. Click the API name to go to the description.

[int Xlsf\\_Initialize\(Xlsf \\*InstancePtr, XSpi \\*SpiInstPtr, u32 SlaveSelect, u8 \\*WritePtr\)](#)  
[int Xlsf\\_GetStatus\(Xlsf \\*InstancePtr, u8 \\*ReadPtr\)](#)  
[int Xlsf\\_GetStatusReg2\(Xlsf \\*InstancePtr, u8 \\*ReadPtr\)](#)  
[int Xlsf\\_GetDeviceInfo\(Xlsf \\*InstancePtr, u8 \\*ReadPtr\)](#)  
[int Xlsf\\_Read\(Xlsf \\*InstancePtr, Xlsf\\_ReadOperation Operation, void \\*OpParamPtr\)](#)  
[int Xlsf\\_Write\(Xlsf \\*InstancePtr, Xlsf\\_WriteOperation Operation, void \\*OpParamPtr\)](#)  
[int Xlsf\\_Erase\(Xlsf \\*InstancePtr, Xlsf\\_EraseOperation Operation, u32 Address\)](#)  
[int Xlsf\\_SectorProtect\(Xlsf \\*InstancePtr, Xlsf\\_SpOperation Operation, u8 \\*BufferPtr\)](#)  
[int Xlsf\\_WriteEnable\(Xlsf \\*InstancePtr, u8 WriteEnable\)](#)  
[int Xlsf\\_Ioctl \(Xlsf \\*InstancePtr, Xlsf\\_IoctlOperation Operation\)](#)  
[int Xlsf\\_SetSpiConfiguration\(Xlsf \\*InstancePtr, Xlsf\\_Iface \\*SpiInstPtr, u32 Options, u8 PreScaler\)](#)  
[inline void Xlsf\\_SetTransferMode\(Xlsf \\*InstancePtr, u8 Mode\)](#)

## LibXil Isf API Descriptions

```
int XIsf_Initialize(XIsf *InstancePtr, XSpi *SpiInstPtr,
    u32 SlaveSelect, u8 *WritePtr)
```

Parameters	<p><i>InstancePtr</i> is a pointer to the XIsf instance.</p> <p><i>SpiInstPtr</i> is a pointer to the XSpi instance to be worked on.</p> <p><i>SlaveSelect</i> is a 32-bit mask with a 1 in the bit position of the slave being selected. Only one slave can be selected at a time.</p> <p><i>WritePtr</i> is a pointer to the buffer allocated by the user to be used by the In-system and Serial Flash Library to perform any read/write operations on the Serial Flash device.</p> <p>User applications must initialize the Isf library by passing the address of this buffer to the Initialization API.</p> <p>For Write operations:</p> <ul style="list-style-type: none"> <li>• A minimum of one byte and a maximum of ISF_PAGE_SIZE bytes can be written to the Serial Flash, through a single Write operation.</li> <li>• The buffer size must be equal to the number of bytes to be written to the Serial Flash + XISF_CMD_MAX_EXTRA_BYTES, and must be large enough for use across the applications that use a common instance of the Serial Flash.</li> </ul> <p>For Non Write operations:</p> <ul style="list-style-type: none"> <li>• The buffer size must be equal to XISF_CMD_MAX_EXTRA_BYTES.</li> </ul>
Returns	<p>XST_SUCCESS upon success.</p> <p>XST_DEVICE_IS_STOPPED if the device must be started before transferring data.</p> <p>XST_FAILURE upon failure.</p>
Description	<p>The geometry of the underlying Serial Flash is determined by reading the Joint Electron Device Engineering Council (JEDEC) Device Information and the Serial Flash Status Register.</p> <p>When called, this API initializes the SPI interface with default settings. With custom settings, the user should call XIsf_SetSpiConfiguration() before calling this API.</p> <p><b>Note:</b> The XIsf_Initialize() API is a blocking call (for both polled mode and interrupt mode of the SPI driver). It reads the JEDEC information of the device and waits till the transfer is complete before checking if the information is valid.</p> <p>Support multiple instances of Serial Flash at a time, provided they are of the same device family (either Atmel, Intel, STM, Winbond, or SST) as the device family is selected at compile time.</p>
Includes	xilisf.h

```
int XIsf_GetStatus(XIsf *InstancePtr, u8 *ReadPtr)
```

Parameters	<i>InstancePtr</i> is a pointer to the XIsf instance. <i>ReadPtr</i> is a pointer to the memory where the Status Register content is copied.
Returns	XST_SUCCESS upon success XST_FAILURE upon failure
Description	Reads the Serial Flash Status Register. <b>Note:</b> The status register content is stored at the second byte pointed by the <i>ReadPtr</i> .
Includes	xilif.h

---

```
int XIsf_GetStatusReg2(XIsf *InstancePtr, u8 *ReadPtr)
```

Parameters	<i>InstancePtr</i> is a pointer to the XIsf instance. <i>ReadPtr</i> is a pointer to the memory where the Status Register content is copied.
Returns	XST_SUCCESS upon success XST_FAILURE upon failure
Description	Reads the Serial Flash Status Register2. this API is valid only for Windbond (W25QXX) flash devices. <b>Note:</b> The status register content is stored at the second byte pointed by the <i>ReadPtr</i> .
Includes	xilif.h

---

```
int XIsf_GetDeviceInfo(XIsf *InstancePtr, u8 *ReadPtr)
```

Parameters	<i>InstancePtr</i> is a pointer to the XIsf instance. <i>ReadPtr</i> is a pointer to the memory where the Device information is copied.
Returns	XST_SUCCESS upon success. XST_FAILURE upon failure.
Description	Reads the JEDEC information of the Serial Flash. <b>Note:</b> The Device information is stored at the second byte pointed by the <i>ReadPtr</i> .
Includes	xilif.h

```
int XIsf_Read(XIsf *InstancePtr, XIsf_ReadOperation
Operation, void *OpParamPtr)
```

#### Parameters

*InstancePtr* is a pointer to the XIsf instance.

*Operation* is the type of the read operation to be performed on the Serial Flash.

The *Operation* options are:

XISF\_READ: Normal Read

XISF\_FAST\_READ: Fast Read

XISF\_PAGE\_TO\_BUF\_TRANS: Page to Buffer Transfer

XISF\_BUFFER\_READ: Buffer Read

XISF\_FAST\_BUFFER\_READ: Fast Buffer Read

XISF\_OTP\_READ: One Time Programmable Area (OTP) Read.

XISF\_DUAL\_OP\_FAST\_READ: Dual Output Fast Read

XISF\_DUAL\_IO\_FAST\_READ: Dual Input/Output Fast Read

XISF\_QUAD\_OP\_FAST\_READ: Quad Output Fast Read

XISF\_QUAD\_IO\_FAST\_READ: Quad Input/Output Fast Read

*OpParamPtr* is the pointer to structure variable which contains operational parameter of specified Operation. This parameter type is dependent on the type of Operation to be performed.

When specifying Normal Read (XISF\_READ), Fast Read (XISF\_FAST\_READ) and One Time Programmable Area Read(XISF\_OTP\_READ), Dual Output Fast Read

(XISF\_DUAL\_OP\_FAST\_READ), Dual Input/Output Fast Read

(XISF\_DUAL\_IO\_FAST\_READ), Quad Output Fast Read

(XISF\_QUAD\_OP\_FAST\_READ) and Quad Input/Output Fast Read

(XISF\_QUAD\_IO\_FAST\_READ):

- *OpParamPtr* must be of type struct *XIsf\_ReadParam*.
- *OpParamPtr->Address* is the start address in the Serial Flash.
- *OpParamPtr->ReadPtr* is a pointer to the memory where the data read from the Serial Flash is stored.
- *OpParamPtr->NumBytes* is number of bytes to read.
- *OpParamPtr->NumDummyBytes* is the number of dummy bytes to be transmitted for the Read command. This parameter is only used in case of Dual and Quad reads.

Normal Read and Fast Read operations are supported for Atmel, Intel, STM, Winbond, SST, and Spansion Serial Flash. Dual and quad reads are supported for Winbond (W25QXX), Numonyx (N25QXX) and Spansion (S25FL129) quad flash. OTP Read operation is only supported in Intel Serial Flash.

When specifying Page To Buffer Transfer

(XISF\_PAGE\_TO\_BUF\_TRANS):

- *OpParamPtr* must be of type struct *XIsf\_FlashToBufTransferParam*.
- *OpParamPtr->BufferNum* specifies the internal SRAM Buffer of the Serial Flash. The valid values are XISF\_PAGE\_BUFFER1 or XISF\_PAGE\_BUFFER2. XISF\_PAGE\_BUFFER2 is not valid in the case of AT45DB011D Flash as it contains a single buffer.
- *OpParamPtr->Address* is start address in the Serial Flash.

This operation is only supported in Atmel Serial Flash.

**XIsf\_Read (continued)**

Parameters	<p>When specifying Buffer Read (XISF_BUFFER_READ) and Fast Buffer Read (XISF_FAST_BUFFER_READ):</p> <ul style="list-style-type: none"> <li>• <i>OpParamPtr</i> must be of type struct <i>XIsf_BufferReadParam</i>.</li> <li>• <i>OpParamPtr-&gt;BufferNum</i> specifies the internal SRAM Buffer of the Serial Flash. The valid values are XISF_PAGE_BUFFER1 or XISF_PAGE_BUFFER2. XISF_PAGE_BUFFER2 is not valid in the case of AT45DB011D Flash as it contains a single buffer.</li> <li>• <i>OpParamPtr-&gt;ReadPtr</i> is pointer to the memory where the data read from the SRAM buffer is to be stored.</li> <li>• <i>OpParamPtr-&gt;ByteOffset</i> is byte offset in the SRAM buffer from where the first byte is read.</li> <li>• <i>OpParamPtr-&gt;NumBytes</i> is the number of bytes to be read from the Buffer.</li> </ul> <p>These operations are supported only in Atmel Serial Flash.</p>
Returns	<p>XST_SUCCESS upon success.</p> <p>XST_FAILURE upon failure.</p>
Description	<p>Reads the data from the Serial Flash.</p> <p><b>Note:</b> Application must fill the structure elements of the third argument and pass its pointer by type casting it with void pointer.</p> <p>The valid data is available from the fourth location pointed to by the <i>ReadPtr</i> for Normal Read and Buffer Read operations.</p> <p>The valid data is available from the fifth location pointed to by the <i>ReadPtr</i> for Fast Read, Fast Buffer Read, and OTP Read operations.</p> <p>The valid data is available from the (4 + <i>NumDummyBytes</i>) location pointed to by <i>ReadPtr</i> for Dual/Quad Read operations.</p>
Includes	xilisf.h

```
int XIsf_Write(XIsf *InstancePtr, XIsf_WriteOperation
               Operation, void *OpParamPtr)
```

**Parameters**     *InstancePtr* is a pointer to the XIsf instance.  
                   *Operation* is the type of write operation to be performed on the Serial Flash.  
                   The *Operation* options are:

- XISF\_WRITE: Normal Write
- XISF\_DUAL\_IP\_PAGE\_WRITE: Dual Input Fast Program
- XISF\_DUAL\_IP\_EXT\_PAGE\_WRITE: Dual Input Extended Fast Program
- XISF\_QUAD\_IP\_PAGE\_WRITE: Quad Input Fast Program
- XISF\_QUAD\_IP\_EXT\_PAGE\_WRITE: Quad Input Extended Fast Program
- XISF\_AUTO\_PAGE\_WRITE: Auto Page Write
- XISF\_BUFFER\_WRITE: Buffer Write
- XISF\_BUF\_TO\_PAGE\_WRITE\_WITH\_ERASE: Buffer to Page Transfer with Erase
- XISF\_BUF\_TO\_PAGE\_WRITE\_WITHOUT\_ERASE: Buffer to Page Transfer without Erase
- XISF\_WRITE\_STATUS\_REG: Status Register Write
- XISF\_WRITE\_STATUS\_REG2: 2 byte Status Register Write
- XISF\_OTP\_WRITE: OTP Write.

*OpParamPtr* is the pointer to a structure variable which contains operational parameters of specified operation.

This parameter type is dependant upon the value of first argument (*Operation*).

When specifying Normal Write (XISF\_WRITE): Dual Input Fast Program (XISF\_DUAL\_IP\_PAGE\_WRITE), Dual Input Extended Fast Program (XISF\_DUAL\_IP\_EXT\_PAGE\_WRITE), Quad Input Fast Program (XISF\_QUAD\_IP\_PAGE\_WRITE), Quad Input Extended Fast Program (XISF\_QUAD\_IP\_EXT\_PAGE\_WRITE):

- *OpParamPtr* must be of type struct *XIsf\_WriteParam*.
- *OpParamPtr->Address* is the start address in the Serial Flash.
- *OpParamPtr->WritePtr* is a pointer to the data to be written to the Serial Flash.
- *OpParamPtr->NumBytes* is the number of bytes to be written to the Serial Flash.

This operation is supported for Atmel, Intel, STM, Winbond, and Spansion Serial Flash.

For SST, only normal write is applicable.

## XIsf\_Write (continued)

Parameters	<p>When specifying the Auto Page Write (XISF_AUTO_PAGE_WRITE):</p> <ul style="list-style-type: none"> <li><i>OpParamPtr</i> must be of 32 bit unsigned integer variable. This is the address of page number in the Serial Flash which is to be refreshed.</li> </ul> <p>This operation is only supported in Atmel Serial Flash.</p> <p>When specifying the Buffer Write (XISF_BUFFER_WRITE):</p> <ul style="list-style-type: none"> <li><i>OpParamPtr</i> must be of type struct <i>XIsf_BufferWriteParam</i>.</li> <li><i>OpParamPtr-&gt;BufferNum</i> specifies the internal SRAM Buffer of the Serial Flash. The valid values are XISF_PAGE_BUFFER1 or XISF_PAGE_BUFFER2. XISF_PAGE_BUFFER2 is not valid in the case of AT45DB011D Flash as it contains a single buffer.</li> <li><i>OpParamPtr-&gt;WritePtr</i> is a pointer to the data to be written to the Serial Flash SRAM Buffer.</li> <li><i>OpParamPtr-&gt;ByteOffset</i> is byte offset in the buffer from where the data is to be written.</li> <li><i>OpParamPtr-&gt;NumBytes</i> is number of bytes to be written to the Buffer.</li> </ul> <p>This operation is supported only for Atmel Serial Flash. When specifying Buffer To Memory Write With Erase (XISF_BUF_TO_PAGE_WRITE_WITH_ERASE) or Buffer To Memory Write Without Erase (XISF_BUF_TO_PAGE_WRITE_WITHOUT_ERASE):</p> <ul style="list-style-type: none"> <li><i>OpParamPtr</i> must be of type struct <i>XIsf_BufferToFlashWriteParam</i>.</li> <li><i>OpParamPtr-&gt;BufferNum</i> specifies the internal SRAM Buffer of the Serial Flash. The valid values are XISF_PAGE_BUFFER1 or XISF_PAGE_BUFFER2. XISF_PAGE_BUFFER2 is not valid in the case of AT45DB011D Flash as it contains a single buffer.</li> <li><i>OpParamPtr-&gt;Address</i> is starting address in the Serial Flash memory from where the data is to be written.</li> </ul> <p>These operations are only supported in Atmel Serial Flash.</p> <p>When specifying Write Status Register (XISF_WRITE_STATUS_REG), the <i>OpParamPtr</i> must be an 8-bit unsigned integer variable. This is the value to be written to the Status Register.</p> <p>This operation is supported in Intel, STM, SST, and Winbond Serial Flash only.</p> <p>When specifying Write 2 Byte Status Register (XISF_WRITE_STATUS_REG2), the <i>OpParamPtr</i> must be of type (u8 *) and should point to two 8 bit unsigned integer values. This is the value to be written to the 16 bit Status Register</p> <p><b>Note:</b> This operation is supported only in Winbond (W25QXX) Serial Flash.</p> <p>When specifying One Time Programmable Area Write (XISF_OTP_WRITE):</p> <ul style="list-style-type: none"> <li><i>OpParamPtr</i> must be of type struct <i>XIsf_WriteParam</i>.</li> <li><i>OpParamPtr-&gt;Address</i> is the address in the SRAM Buffer of the Serial Flash to which the data is to be written.</li> <li><i>OpParamPtr-&gt;WritePtr</i> is a pointer to the data to be written to the Serial Flash.</li> <li><i>OpParamPtr-&gt;NumBytes</i> should be set to 1 when performing OTPWrite operation.</li> </ul> <p>This operation is only supported in Intel Serial Flash.</p>
Returns	<p>XST_SUCCESS upon success.</p> <p>XST_FAILURE upon failure.</p>
Description	<p>Writes data to the Serial Flash.</p> <p><b>Note:</b> Application must fill the structure elements of the third argument and pass its pointer by type casting it with void pointer.</p> <p>For Intel, STM, Winbond, SST, and Spansion Serial Flash the user application must call the XIsf_WriteEnable() API by passing XISF_WRITE_ENABLE as an argument before calling the XIsf_Write() API.</p>
Includes	<p>xilisf.h</p>

```
int XIsf_Erase(XIsf *InstancePtr, XIsf_EraseOperation  
Operation, u32 Address)
```

Parameters	<p><i>InstancePtr</i> is a pointer to the XIsf instance.</p> <p><i>Operation</i> is the type of Erase operation to be performed on the Serial Flash.</p> <p>The different operations are</p> <ul style="list-style-type: none"><li>• XISF_PAGE_ERASE: Page Erase</li><li>• XISF_BLOCK_ERASE: Block Erase</li><li>• XISF_SECTOR_ERASE: Sector Erase</li><li>• XISF_BULK_ERASE: Bulk Erase</li></ul> <p><i>Address</i> is the address of the Page/Block/Sector to be erased. The address can be either Page address, Block address or Sector address based on the Erase operation to be performed.</p>
Returns	<p>XST_SUCCESS upon success.</p> <p>XST_FAILURE upon failure.</p>
Description	<p>Erases the contents of the specified memory in the Serial Flash.</p> <p><b>Note:</b> The erased bytes will read as 0xFF.</p> <p>For Intel, STM, Winbond, and Spansion Serial Flash the user application must call <code>XIsf_WriteEnable()</code> API by passing <code>XISF_WRITE_ENABLE</code> as an argument before calling the <code>XIsf_Erase()</code> API.</p> <p>Atmel, Intel, STM Winbond, Numonyx (N25QXX), and Spansion Serial Flash devices support Sector/Block/Bulk Erase operations.</p> <p>SST devices support all Erase commands.</p>
Includes	<code>xilisf.h</code>



```
int XIsf_SectorProtect(XIsf *InstancePtr, XIsf_SpOperation
    Operation, u8 *BufferPtr)
```

Parameters	<p><i>InstancePtr</i> is a pointer to the XIsf instance.</p> <p><i>Operation</i> is the type of Sector Protect operation to be performed on the Serial Flash.</p> <p>The Operation options are</p> <ul style="list-style-type: none"> <li>• XISF_SPR_READ: Read Sector Protection Register</li> <li>• XISF_SPR_WRITE: Write Sector Protection Register</li> <li>• XISF_SPR_ERASE: Erase Sector Protection Register</li> <li>• XISF_SP_ENABLE: Enable Sector Protection</li> <li>• XISF_SP_DISABLE: Disable Sector Protection</li> </ul> <p><i>BufferPtr</i> is a pointer to the memory where the SPR content is read to/written from. This argument can be NULL if the Operation is SprErase, SpEnable and SpDisable.</p>
Returns	<p>XST_SUCCESS upon success.</p> <p>XST_FAILURE upon failure.</p>
Description	<p>Performs Sector Protect operations.</p> <p><b>Note:</b> The SPR content is stored at the fourth location pointed by the BufferPtr when performing XISF_SPR_READ operation.</p> <p>For Intel, STM, Winbond, and Spansion Serial Flash devices the user application must call the XIsf_WriteEnable() API by passing XISF_WRITE_ENABLE as an argument, before calling the XIsf_SectorProtect() API, for Sector Protect Register Write (XISF_SPR_WRITE) operation.</p> <p>Atmel Flash supports all these Sector Protect operations.</p> <p>Intel, STM, Winbond, and Spansion support only Sector Protect Read and Sector Protect Write operations.</p>
Includes	xilisf.h

```
int XIsf_WriteEnable(XIsf *InstancePtr, u8 WriteEnable)
```

Parameters	<p><i>InstancePtr</i> is a pointer to the XIsf instance.</p> <p><i>WriteEnable</i> specifies whether to enable (XISF_CMD_ENABLE_WRITE) or disable (XISF_CMD_DISABLE_WRITE) the writes to the Serial Flash.</p>
Returns	<p>XST_SUCCESS upon success.</p> <p>XST_FAILURE upon failure.</p>
Description	<p>Enables/Disables writes to the Intel, STM, Winbond, SST, and Spansion Serial Flash.</p> <p><b>Note:</b> If this API is called for Atmel Flash, XST_FAILURE is returned.</p>
Includes	xilisf.h

```
int XIsf_Ioctl (XIsf *InstancePtr, XIsf_IoctlOperation
                Operation)
```

Parameters	<p><i>InstancePtr</i> is a pointer to the XIsf instance.</p> <p><i>Operation</i> is the type of Control operation to be performed on the Serial Flash.</p> <p>The control Operations options are:</p> <ul style="list-style-type: none"> <li>• XISF_RELEASE_DPD: Release from Deep Power Down (DPD) Mode</li> <li>• XISF_ENTER_DPD: Enter DPD Mode</li> <li>• XISF_CLEAR_SR_FAIL_FLAGS: Clear the Status Register Fail Flags.</li> </ul>
Returns	<p>XST_SUCCESS upon success.</p> <p>XST_FAILURE upon failure.</p>
Description	<p>This API configures and controls the Intel, STM, Winbond, and Spansion Serial Flash.</p> <p><b>Note:</b> Atmel Serial Flash does not support any of these operations.</p> <p>Intel Serial Flash support Enter/Release from DPD Mode and Clear Status Register Fail Flags.</p> <p>STM, Winbond, and Spansion Serial Flash support Enter/Release from DPD Mode.</p> <p>Winbond (W25QXX) supports Enable High performance mode.</p>
Includes	xilisf.h

```
int XIsf_SetSpiConfiguration (XIsf *InstancePtr, XIsf_Iface
                               *SpiInstPtr, u32 Options, u8 PreScaler)
```

Parameters	<p><i>InstancePtr</i> is a pointer to the XIsf instance.</p> <p><i>SpiInstPtr</i> is a pointer to the XIsf_Iface instance to be worked on.</p> <p><i>Options</i> contains specified options to be set.</p> <p><i>PreScaler</i> is the value of the clock prescaler to set.</p>
Returns	<p>XST_SUCCESS upon success.</p> <p>XST_FAILURE upon failure.</p>
Description	<p>Sets the configuration of SPI. This API can be called before calling XIsf_Initialize() to operate the SPI interface in a mode other than the default options mode.</p> <p><i>PreScaler</i> is only applicable to PS SPI/QSPI.</p>
Includes	xilisf.h

```
inline void XIsf_SetTransferMode (XIsf *InstancePtr, u8
                                   Mode)
```

This API sets the interrupt/polling mode of transfer.

Parameters	<p><i>InstancePtr</i> is a pointer to the XIsf instance.</p> <p><i>Mode</i> is the value to be set.</p>
Returns	None.
Description	By default, the xilisf library is designed to operate in polling mode. User needs to call this API, if operating in Interrupt Mode.

## Libgen Customization

The LibXil Isf library can be integrated with a system using the following snippet in the Microprocessor Software Specification (MSS) file.

```
BEGIN LIBRARY
  parameter LIBRARY_NAME = xilisf
  parameter LIBRARY_VER = 3.00.a
  parameter PROC_INSTANCE = microblaze_0
  parameter serial_flash_family = 1
  parameter serial_flash_interface = 1
END
```

Where:

- LIBRARY\_NAME—Is the library name (xilisf).
- LIBRARY\_VER—Is the library version (3.00.a).
- PROC\_INSTANCE—Is the processor instance (microblaze\_0 | ppc405 | ppc440 | ps7\_cortexa9\_0)
- serial\_flash\_family—Is a numerical value representing the serial flash family, where:
  - 1 = Xilinx In-system Flash or Atmel Serial Flash
  - 2 = Intel (Numonyx) S33 Serial Flash
  - 3 = STM (Numonyx) M25PXX/N25QXX Serial Flash
  - 4 = Winbond Serial Flash
  - 5 = Spansion Serial Flash
  - 6 = SST Serial Flash
- serial\_flash\_interface - Is a numerical value representing the serial flash interface, where:
  - 1 = AXI SPI Interface
  - 2 = SPI PS Interface
  - 3 = QSPI PS Interface

## Additional Resources

- *Spartan-3AN FPGA In-System Flash User Guide* (UG333):  
[http://www.xilinx.com/support/documentation/user\\_guides/ug333.pdf](http://www.xilinx.com/support/documentation/user_guides/ug333.pdf)
- Atmel Serial Flash Memory website (AT45XXXD):  
[http://www.atmel.com/dyn/products/devices.asp?family\\_id=616#1802](http://www.atmel.com/dyn/products/devices.asp?family_id=616#1802)
- Intel (Numonyx) S33 Serial Flash Memory website (S33):  
[http://www.numonyx.com/Documents/Datasheets/314822\\_S33\\_Discrete\\_DS.pdf](http://www.numonyx.com/Documents/Datasheets/314822_S33_Discrete_DS.pdf)
- STM (Numonyx) M25PXX Serial Flash Memory website (M25PXX):  
<http://www.numonyx.com/en-US/MemoryProducts/NORserial/Pages/M25PTechnicalDocuments.aspx>
- Winbond Serial Flash Page:  
<http://www.winbond-usa.com/hq/enu/ProductAndSales/ProductLines/FlashMemory/SerialFlash/>
- Spansion website: <http://www.spansion.com/Support/Pages/DatasheetsIndex.aspx>
- SST SST25WF080: <http://www.sst.com/dotAsset/40369.pdf>

## Revision History

The following table shows the revision history for this document:

Date	Version	Description of Revisions
07/06/2011	v2.03.a	EDK Release 13.2: Added explicit device numbers.
10/19/2011	v2.04.a	EDK Release 13.3: <ul style="list-style-type: none"><li>• Added Spansion Serial Flash support.</li><li>• Added the requirement for axi_spi, or axi_quad_spi devices.</li><li>• APIs throughout the documents specify the inclusion of Spansion, and exceptions for Windbond (W25QXX).</li></ul>
07/25/2012	v3.00.a	EDK Release 14.2: <ul style="list-style-type: none"><li>• Updated to support interfaces SPI PS and QSPI PS.</li><li>• Added support to SST flash.</li></ul>

## Overview

The XilFlash library provides read/write/erase/lock/unlock features to access a parallel flash device. Flash device family specific functionality are also supported by the library. This library requires the underlying hardware platform to contain the following:

- xps\_mch\_emc or similar core for accessing the flash.

This library implements the functionality for flash memory devices that conform to the "Common Flash Interface" (CFI) standard. CFI allows a single flash library to be used for an entire family of parts. This library supports Intel and AMD CFI compliant flash memory devices.

All the calls in the library are blocking in nature in that the control is returned back to user only after the current operation is completed successfully or an error is reported.

The following common APIs are supported for all flash devices:

- Initialize
- Read
- Write
- Erase
- Lock
- UnLock
- IsReady
- Reset
- Device specific control

You must call the "[int XFlash\\_Initialize \(XFlash \\*InstancePtr, u32 BaseAddress, u8 BusWidth, int IsPlatformFlash\)](#)" API before calling any other API in this library.

## XilFlash Library APIs

This section provides a linked summary and detailed descriptions of the LibXil Flash library APIs.

### API Summary

The following is a summary list of APIs provided by the LibXil Flash library. The list is linked to the API description. Click on the API name to go to the description.

[int XFlash\\_Initialize \(XFlash \\*InstancePtr, u32 BaseAddress, u8 BusWidth, int IsPlatformFlash\)](#)  
[int XFlash\\_Reset \(XFlash \\*InstancePtr\)](#)  
[int XFlash\\_Read \(XFlash \\*InstancePtr, u32 Offset, u32 Bytes, void \\*DestPtr\)](#)  
[int XFlash\\_Write \(XFlash \\*InstancePtr, u32 Offset, u32 Bytes, void \\*SrcPtr\)](#)  
[int XFlash\\_Erase \(XFlash \\*InstancePtr, u32 Offset, u32 Bytes\)](#)  
[int XFlash\\_Lock \(XFlash \\*InstancePtr, u32 Offset, u32 Bytes\)](#)  
[int XFlash\\_UnLock \(XFlash \\*InstancePtr, u32 Offset, u32 Bytes\)](#)  
[int XFlash\\_DeviceControl \(XFlash \\*InstancePtr, u32 Command, DeviceControl \\*Parameters\)](#)  
[int XFlash\\_IsReady \(XFlash \\*InstancePtr\)](#)

## XilFlash Library API Descriptions

```
int XFlash_Initialize (XFlash *InstancePtr, u32
    BaseAddress, u8 BusWidth, int IsPlatformFlash)
```

Parameters	<p><i>InstancePtr</i> is a pointer to XFlash Instance.</p> <p>BaseAddress is the base address of the Flash memory.</p> <p>BusWidth is the total width of the Flash memory, in bytes.</p> <p>IsPlatformFlash specifies whether the Flash memory is a Xilinx® Platform Flash configuration memory device.</p>
Returns	<p>XST_SUCCESS if successful.</p> <p>XFLASH_PART_NOT_SUPPORTED if the command set algorithm or the layout is not supported by any flash family compiled into the system.</p> <p>XFLASH_CFI_QUERY_ERROR if the device would not enter the CFI query mode. Either device doesn't support CFI or unsupported part layout exists or a hardware problem exists.</p>
Description	<p>Initializes a specific XFlash Instance.</p> <p>The initialization entails:</p> <ul style="list-style-type: none"> <li>• Issuing the CFI query command</li> <li>• Identifying the Flash family and layout from CFI data</li> <li>• Setting the default options for the instance</li> <li>• Setting up the VTable</li> <li>• Initialize the Xilinx Platform Flash XL to Async mode if the user selects to use the Platform Flash XL. The Platform Flash XL is an Intel CFI complaint device.</li> </ul>
Includes	<p>xilflash.h</p> <p>xilflash_cfi.h</p> <p>xilflash_intel.h</p> <p>xilflash_amd.h</p>

```
int XFlash_Reset (XFlash *InstancePtr)
```

Parameters	<p><i>InstancePtr</i> is a pointer to XFlash Instance.</p>
Returns	<p>XST_SUCCESS if Successful.</p> <p>XFLASH_BUSY if the flash devices were in the middle of an operation and could not be reset.</p> <p>XFLASH_ERROR if the device has experienced an internal error during the operation. XFlash_DeviceControl() must be used to access the cause of the device specific error condition.</p>
Description	<p>Resets the flash device and places it in read mode.</p>
Includes	<p>xilflash.h</p> <p>xilflash_cfi.h</p> <p>xilflash_intel.h</p> <p>xilflash_amd.h</p>

```
int XFlash_Read (XFlash *InstancePtr, u32 Offset, u32
    Bytes, void *DestPtr)
```

Parameters	<p><i>InstancePtr</i> is a pointer to XFlash Instance.</p> <p><i>Offset</i> is the offset into the devices address space from which to read.</p> <p><i>Bytes</i> is the number of bytes to read.</p> <p><i>DestPtr</i> is the destination Address to copy data to.</p>
Returns	<p>XST_SUCCESS if successful.</p> <p>XFLASH_ADDRESS_ERROR if the source address did not start within the addressable areas of the device.</p>
Description	This API reads the data from the flash device and copies it into the specified user buffer. The source and destination addresses can be on any alignment supported by the processor.
Includes	<p>xilflash.h</p> <p>xilflash_cfi.h</p> <p>xilflash_intel.h</p> <p>xilflash_amd.h</p>

```
int XFlash_Write (XFlash *InstancePtr, u32 Offset,
    u32Bytes, void *SrcPtr)
```

Parameters	<p><i>InstancePtr</i> is a pointer to XFlash Instance.</p> <p><i>Offset</i> is the offset into the devices address space from which to begin programming.</p> <p><i>Bytes</i> is the number of bytes to Program.</p> <p><i>SrcPtr</i> is the Source Address containing data to be programmed.</p>
Returns	<p>XST_SUCCESS if successful.</p> <p>XFLASH_ERROR if a write error has occurred. The error is usually device specific. Use <code>XFlash_DeviceControl()</code> to retrieve specific error conditions. When this error is returned, it is possible that the target address range was only partially programmed.</p>
Description	<p>Programs the flash device with the data specified in the user buffer. The source and destination addresses must be aligned to the width of the flash data bus.</p> <p>If the processor supports unaligned access, then the source address does not need to be aligned to the flash width; however, this library is generic, and because some processors (such as MicroBlaze) do not support unaligned access, this API requires that the source address be aligned.</p>
Includes	<p>xilflash.h</p> <p>xilflash_cfi.h</p> <p>xilflash_intel.h</p> <p>xilflash_amd.h</p>

```
int XFlash_Erase (XFlash *InstancePtr, u32 Offset, u32
    Bytes)
```

Parameters	<p><i>InstancePtr</i> is a pointer to XFlash Instance.</p> <p><i>Offset</i> is the offset into the devices address space from which to begin erasure.</p> <p><i>Bytes</i> is the number of bytes to Erase.</p>
Returns	<p>XST_SUCCESS if successful.</p> <p>XFLASH_ADDRESS_ERROR if the destination address range is not completely within the addressable areas of the device.</p>
Description	<p>This API erases the specified address range in the flash device. The number of bytes to erase can be any number as long as it is within the bounds of the devices.</p>
Includes	<p>xilflash.h</p> <p>xilflash_cfi.h</p> <p>xilflash_intel.h</p> <p>xilflash_amd.h</p>

```
int XFlash_Lock (XFlash *InstancePtr, u32 Offset, u32
    Bytes)
```

Parameters	<p><i>InstancePtr</i> is a pointer to XFlash instance.</p> <p><i>Offset</i> is the offset of the block address into the devices address space which need to be locked.</p> <p><i>Bytes</i> is the number of bytes to be locked.</p>
Returns	<p>XST_SUCCESS if successful.</p> <p>XFLASH_ADDRESS_ERROR if the destination address range is not completely within the addressable areas of the device.</p>
Description	<p>Locks a block in the flash device.</p>
Includes	<p>xilflash.h</p> <p>xilflash_cfi.h</p> <p>xilflash_intel.h</p> <p>xilflash_amd.h</p>



```
int XFlash_UnLock (XFlash *InstancePtr, u32 Offset, u32
    Bytes)
```

Parameters	<p><i>InstancePtr</i> is a pointer to XFlash Instance.</p> <p><i>Offset</i> is the offset of the block address into the devices address space which need to be unlocked.</p> <p><i>Bytes</i> is the number of bytes to be unlocked.</p>
Returns	<p>XST_SUCCESS if successful.</p> <p>XFLASH_ADDRESS_ERROR if the destination address range is not completely within the addressable areas of the device.</p>
Description	Unlocks previously locked blocks that are locked.
Includes	<p>xilflash.h</p> <p>xilflash_cfi.h</p> <p>xilflash_intel.h</p> <p>xilflash_amd.h</p>

```
int XFlash_DeviceControl (XFlash *InstancePtr, u32
    Command, DeviceControl *Parameters)
```

Parameters	<p><i>InstancePtr</i> is a pointer to XFlash Instance.</p> <p><i>Command</i> is the device specific command to issue.</p> <p><i>Parameters</i> specifies the arguments passed to the device control function.</p>
Returns	<p>XST_SUCCESS if successful.</p> <p>XFLASH_NOT_SUPPORTED if the command is not supported by the device.</p>
Description	Executes device specific commands.
Includes	<p>xilflash.h</p> <p>xilflash_cfi.h</p> <p>xilflash_intel.h</p> <p>xilflash_amd.h</p>

```
int XFlash_IsReady (XFlash *InstancePtr)
```

Parameters	<i>InstancePtr</i> is a pointer to XFlash instance.
Returns	TRUE if the device has been initialized; otherwise, FALSE.
Description	Checks the device readiness, signifying successful initialization.
Includes	<p>xilflash.h</p> <p>xilflash_cfi.h</p> <p>xilflash_intel.h</p> <p>xilflash_amd.h</p>

## Libgen Customization

XilFlash Library can be integrated with a system using the following snippet in the Microprocessor Software Specification (MSS) file:

```
BEGIN LIBRARY
PARAMETER LIBRARY_NAME = xilflash
PARAMETER LIBRARY_VER = 3.03.a
PARAMETER PROC_INSTANCE = microblaze_0
PARAMETER ENABLE_INTEL = true
PARAMETER ENABLE_AMD = false
END
```

Where:

- LIBRARY\_NAME—Is the library name (xilflash).
- LIBRARY\_VER—Is the library version (3.03.a).
- PROC\_INSTANCE—Is the processor name (microblaze\_0 | ppc405 | ppc440).
- ENABLE\_INTEL—Enables or disables the Intel flash device family (true | false).
- ENABLE\_AMD—Enables or disables the AMD flash device family (true | false).

## Revision History

The following table lists the revision history of XilFlash (3.03.a)

Date	Version	Revision
07/25/2012	3.03.a	14.4 Release.

## Overview

In a typical embedded development environment, one of the tasks is to create software to support the custom hardware on the embedded system for the target operating system. This software that supports embedded custom hardware is often called a Board Support Package (BSP).

In an environment where hardware is defined in a programmable System-on-Chip (SoC), hardware changes can come about much more rapidly, making it difficult for the BSP to remain current with the revisions in hardware.

To ease this situation, Xilinx® provides a process called Automatic BSP Generation that tailors a BSP according to the current hardware configuration of the FPGA.

Automatic generation of a BSP is done using Xilinx SDK, which is available in the Xilinx Embedded Development Kit (EDK) or as separately installed tool. SDK generates BSPs based on the defined hardware configuration.

- For Linux, SDK generates a sparse Linux kernel source tree containing just the hardware specific files for the BSP.
- For Linux 2.6, SDK supports both the MontaVista and Wind River Linux distributions.

In general, the work flow for a Linux OS on an embedded system using FPGAs is as follows:

1. Define the hardware components in Xilinx Platform Studio (XPS) and export the project to the Xilinx SDK.
2. Select a Linux 2.6 distribution as the target operating system in SDK.
3. Specify operating system parameters.
4. Generate the BSP in SDK.
5. Configure the kernel.
6. Define the root file system.
7. Build the kernel.
8. Install the kernel and root file system
9. Develop and run application specific code

This guide describes steps 2 through 5, and 7. The remaining steps are beyond the scope of this guide.

## Getting Started with Linux 2.6

The Linux 2.6 distributions currently supported in SDK are from MontaVista and Wind River. These distributions can be purchased directly from those vendors. The MontaVista product is named as Linux Professional Edition 5.0, which each includes a kernel source tree, development tools, and technical support. The Wind River product is named as General Purpose Platform Linux Edition 2.0. These Linux products provide a PowerPC®405/440 processor cross-development environment that runs on various host operating systems. See the vendor websites for a list of supported host operating systems.

To get started, first install the MontaVista or Wind River Linux distribution CDs for the PowerPC 405/440 processors. If using the FPU on Virtex®-5 FXT, install the compiler tools for the PowerPC 440 processor. Once the main distribution is installed, each vendor provides a Xilinx BSP CD or download image that can be installed on top of the main distribution. Please follow the vendor-specific installation instructions.

MontaVista uses the term LSP instead of BSP. LSP stands for Linux Support Package, but should be considered analogous to Board Support Package. The Linux 2.6 BSPs provided are for specific reference designs for the Xilinx ML507 and ML403 development boards. The reference designs can be found on the Xilinx website at [www.xilinx.com/ml507](http://www.xilinx.com/ml507) and [www.xilinx.com/ml403](http://www.xilinx.com/ml403) respectively. When developing a custom hardware design for these boards or for other boards, use the automatically generated BSP from SDK in conjunction with one of the aforementioned BSPs.

**Note:** Xilinx has tested the BSPs from MontaVista and Wind River for the development boards (ml403 and ml507) without applying any Linux vendor patches or updates. The patches and updates from these Linux vendors is recommended. However, if you are running into problems, try first without the patches and updates.

When building a hardware design on a custom board, the target FPGA must have a PowerPC processor. Either a serial port or some device that can be used as a console device would be useful. Also, unless a ramdisk is going to be used, some device that will be used to access the root file system needs to be considered (for example: Ethernet for an NFS root filesystem or System ACE for a CompactFlash root filesystem).

## Creating a Working Kernel Tree

It is recommended to create a working copy of the Linux kernel tree that is installed with your MontaVista or Wind River distribution. This ensures that the installed copy remains clean.

### MontaVista Linux

When installed on a Linux system, the default install directory for the MontaVista Linux kernel source, for MontaVista Linux Professional Edition, is here:

```
/opt/montavista/pro/devkit/lsp/<target board>/linux-2.6.24_pro5024
```

Some care must be taken to correctly copy the kernel source tree to preserve links and other file attributes. One method is to use *tar* to make a tarball of the source tree and then extract it to the target location. This tar method can even be done using a transitory temporary tar file by piping the output of the tar creation process into the tar extraction process like so:

```
tar cf - source_dir | tar xvf - -C target_dir
```

Here is a specific example:

```
tar cf - /opt/montavista/pro/devkit/lsp/xilinx-ml507-ppc_440/linux-2.6.24_pro5024 | tar xvf - -C my_linux-2.6.24
```

On Windows, perform the copy within a cygwin bash shell so that the Linux file attributes can be preserved, as the Linux kernel build depends on certain soft links to be present.

## Wind River Linux

The steps for creating a working Linux kernel tree for Wind River Linux are different than those for MontaVista Linux. Refer to the Getting Started guide in your Wind River Linux distribution for details on creating a kernel and filesystem using the pre-built RPM method or the source build method, or using the Workbench IDE. The following steps describe creating a working kernel from the command line using the source build method. Note that these steps avoid building a filesystem.

- Create a working directory where you want the kernel tree to reside
- From the working directory, run the configure script to copy and configure a kernel tree for the specific BSP you're targeting. For example, for the ML403 BSP:

```
WINDRIVER_INSTALL_DIR/wrlinux-2.0/wrlinux/configure --enable-kernel=cgl -
-enable-board=xilinx_ml403
```

- Type "make -C dist linux.rebuild" to build the working kernel tree, which will reside in dist/linux-2.6.21-cgl under the working directory (for Wind River GPP LE 2.0).

## Creating a BSP from SDK

SDK is available as a separately installed tool or within the EDK and is a software development environment for developing embedded software around PowerPC 405/440 processors or MicroBlaze™ processor based embedded systems. This section describes the steps needed to create a Linux 2.6 BSP using SDK. These steps are applicable when using The Xilinx 12.1 tools or later.

It is assumed that a valid hardware design has been created and exported to SDK, and SDK has been opened and pointed to the hardware design.

## Creating a Board Support Package Project

Once the hardware components have been defined and configured in XPS, and exported to SDK, a Board Support Package project must be created with the SDK to select the target Operating System. Select the *Board Support Package* item from the **File > New** menu to open the New Board Support Package dialog box, shown in Figure 1.




Figure 1: Create a Board Support Package Project

Enter a project name and select **linux\_2\_6** from the Board Support Package Type drop-down list and click **Finish** to launch the Board Support Package Settings dialog box.

## Configuring the Board Support Package

There are some configuration options available from within the Board Support Package Settings dialog box, shown in [Figure 2](#).




Figure 2: Setting Library/OS Parameters

The options, some of which are required and some that are optional, are:

### linux distribution (required)

This parameter specifies which distribution you are using, either Wind River Linux or MontaVista Linux. The default is WindRiver Linux. Your Linux kernel might not build properly if this parameter is set incorrectly. This parameter determines the contents of a `Kconfig` file.

### memory size (required)

This setting simply lets the OS know how much general-purpose RAM it can use in the system. Obviously this value should be less than or equal to the amount of physical general-purpose RAM available in the system. Though, it can be set to a value less than the amount of physical general-purpose RAM if simulating a smaller amount of RAM, or if some area of RAM is reserved for other purposes.

Note that the hardware configuration should be set so that memory starts at address 0x0.

### UART16550 bus clock freq (optional)

This parameter specifies the frequency of the bus (in HZ) to which the console serial device is attached. The Linux kernel uses this value to program a 16550/16450 UART baud rate. Note that this setting is only required if a UART 16550 is included in the hardware design.

### target directory (optional)

The target directory where the BSP is created can be specified. Typically, the value points to a copy of the Linux kernel source tree so that the generated BSP will directly overlay a working kernel tree with the new drivers. For such an overlay to work correctly, *target\_dir* should point to the top-most directory in the working kernel tree.

If this target directory is left blank, it defaults to:

```
project directory/processor name/libsrc/linux_2_6_v1_05_a/linux
```

This directory will contain a sparse kernel tree with updated device drivers configured to match the hardware design. This directory should then be copied over the user's working Linux kernel tree. Use forward slashes to delimit directory names.

### rootfs type (optional)

The `rootfs type` parameter specifies which type of root filesystem will be used for this kernel tree. Note that this is an initial default type and it can always be changed in your kernel `.config`. The drop-down list in the Current Value column gives the user a selection of **nfs**, **ramdisk**, or **sysace**. The selection shows in the default kernel command line. The default value is **sysace**. Wind River Linux does not support a ramdisk rootfs.

### ramdisk size (optional)

This parameter specifies the size of the ramdisk if **ramdisk** was chosen for the rootfs type. The default value is 8192 1K byte blocks (8 MB). This is an initial default value that can be changed in your kernel `.config`.

### NFS info source (optional)

This parameter specifies how the NFS root filesystem will be retrieved during boot if **nfs** was chosen for the rootfs type. The default value is **dhcp**, which means the NFS information will be taken from the DHCP server. The other option is to select kernel command line to get the NFS information directly from the kernel command string (for example, `nfsroot=`).

### NFS server (optional)

This parameter specifies the name of the NFS server from which the root filesystem will be mounted during boot if **nfs** is chosen for the rootfs type and kernel command line is chosen for the NFS info source.

### NFS share (optional)

This parameter specifies the name of the NFS share on the NFS server. This parameter is only used if an NFS server name is provided and **nfs** is chosen for the rootfs type and kernel command line is chosen for the NFS info source.

### sysace partition (optional)

This parameter specifies the CompactFlash card partition which contains the root filesystem. This parameter is only used if **sysace** was chosen for the rootfs type. The default value is 2.

### IP Address (optional)

This parameter can be set to **on**, **off**, or a static IP address.

- If **on**, DHCP is used to retrieve the IP address of the target during boot.
- If **off**, the network is disabled during boot.
- If a static IP address is specified, this IP address is assigned to the primary Ethernet interface during boot. The default value is **on**.

### Additional kernel command line items (optional)

This parameter can be used to specify additional command line options if not addressed by the options addressed above. For example, options for kgdb configuration or changing the console device could be specified here.

### powerdown Parameters (optional)

The `powerdown` parameters are placeholders to aid in creating a soft power down feature in your board. Some Xilinx boards support a soft power down feature through a GPIO address.

**Note:** This parameter applies only if you have a powerdown feature on the board and it is accessible through a memory-mapped address (for example: GPIO). See your board user guide as a reference.

These values are intended to support a power down method where the powerdown value is written to the `powerdown baseaddr` to initiate the hardware power down sequence. The `powerdown highaddr` indicates a memory range used to map pages to a set of physical pages.

### IIC Parameters (optional)

The IIC parameters are based around the hardware on the Xilinx ML403 and ML507 boards. The boards have an EEPROM attached to an I2C bus. In addition, Linux is set up to read the MAC address for the Ethernet driver from an address on this EEPROM. The IIC parameters specify which addresses in the EEPROM are to be used to read this MAC address as well as specify the device ID of the EEPROM on the I2C bus.

If your board does not have an EEPROM on an I2C bus, these parameters can be safely ignored. The:

- `IIC persistent baseaddr` value specifies the base address in the EEPROM where the MAC address is stored.
- `IIC persistent highaddr` value is not used for booting up. This value is used by other utilities available with the Xilinx boards that write to the EEPROM.
- `IIC persistent eepromaddr` value specifies the I2C bus device ID of the EEPROM.

### PCI Board (optional)

This parameter specifies the target board for a PCI system. Currently, only the Xilinx ML410 and ML510 boards are supported. When this parameter is set to "ml410", for example, the most common on-board PCI peripherals are enabled in the Linux kernel configuration through the automatic kernel configuration in SDK (see Linux Kernel Configuration section).

### connected\_periphs (required)

This parameter specifies which hardware devices are to be supported in Linux through the generated BSP. See [Table 1, page 21](#). Clicking in the Current Value column will bring up a dialog box in which you can specify which peripherals are to be *connected* to the OS. By default, this parameter has the list of all peripherals in the hardware design. In most cases, this parameter can be left unchanged

## Generating the BSP

Click **OK** on the Board Support Package Settings dialog box to generate the BSP.



## Directory Structures

If the target directory is left blank, the target directory defaults to

```
project_directory\processor name\libsrc\linux_2_6_v1_05_a\linux.
```

The Linux directory shown in [Figure 3](#) contains a directory tree of various Linux drivers for the currently configured hardware devices. If the specified target directory does not refer to the same directory as the working Linux kernel source tree, copy this directory into the working Linux kernel source tree.




Figure 3: Example Directory Structure for a Generated Linux BSP

### Copying the BSP to the Linux Kernel Source Tree

If the target directory option in the Board Support Package settings refers to your working Linux kernel source tree, the generated BSP does not need to be copied. Otherwise the generated BSP needs to be copied over the top of a working kernel source tree. The top-most directories in the generated BSP match some of those in the working Linux kernel directory structure. Copy the generated BSP files so that the files in the `/arch` directory and `/drivers` directory go into the `/arch` directory and `/drivers` directory in the working kernel source tree respectively.

Care should be taken when copying the BSP using the SMB (Windows Networking) protocol. When using this file sharing protocol, symbolic links to directories on the target can be overwritten as separate directories. The Linux kernel build requires the symbolic links to be present rather than having separate directories. In particular, pay attention to the `/asm` directories.

## Configuring the Linux Kernel

The Linux 2.6 BSP generation process through SDK does kernel customization and the user needs to do very little, if any, kernel customization other than application-specific customization. For WindRiver Linux 2.0, the kernel configuration can be updated to enable the drivers for the device in the hardware design. For MontaVista Linux 5.0, all Xilinx-related drivers are enabled by default and devices are enabled at run-time through the use of the device-tree structure.

There are three methods for configuring your kernel to match the FPGA hardware design:

1. The *target directory* points to a valid Linux 2.6 kernel tree.

This method is recommended if starting with unmodified Linux kernel source because it automatically updates the kernel `.config` file to match the hardware design. This method is not recommended if kernel modifications have been made which need to be preserved. Users do not need to manually configure the kernel (for example by running `make menuconfig`) to change individual menu options/setting hiding in different menus and sub-menus. Instead, simply generating the BSP from SDK followed by a kernel compilation will generate a kernel that will work on the specific hardware design. (Note this does not prevent users from running traditional `make menuconfig` to change individual kernel settings). A copy of the old `.config` is saved before updating it with the design-specific configuration. The saved `.config` is named `.config.bak.month_day_year_hour_min_sec`. (Note that if generating the BSP for MontaVista Linux 5.0, `.config` is not updated and is also not copied to a backup file.)

To compile the kernel tree in MontaVista Linux, change the directory to the Linux kernel source tree, and type:

```
make oldconfig bzImage
```

To compile the kernel tree in Wind River Linux, change the directory to the Linux working directory (the directory that contains the `/dist` subdirectory), and type:

```
make -C dist linux.rebuild
```

or, from the root of the Linux kernel source tree, type:

```
make ARCH=ppc CROSS_COMPILE=powerpc-wrs-linux-gnu- oldconfig  
bzImage
```

When first running `make oldconfig` or when first using `xmake` (described in the following method), especially when there is a change in the board architecture from the base BSP, you may be prompted for configuration options on the command line. If this happens, just press enter to accept the default for all of the questions.

To accomplish this customization, more options were made available in the Board Support Package Settings dialog box within SDK, as described earlier in this document.

**Note:** If you want SDK to leave your kernel `.config` file alone, then leave the `target_dir` parameter blank and copy the resulting sparse tree from the SDK project into your working kernel tree.

2. Target directory is left blank and the config updater tool provided by Xilinx is used.

### For WindRiver Linux 2.0:

If the target directory is left blank or does not point to a valid Linux kernel source tree, the user must copy the `sparse` Linux tree from the project area to the working kernel tree. Xilinx provides a Tcl command script that can be run after the sparse tree copy to update the `.config` to match the XPS hardware design.

To run the command, be sure an appropriate Tcl/TK interpreter is installed on the host system where the working Linux kernel tree resides. If this host system has the Xilinx EDK tools installed, then the appropriate interpreter is already installed and you can use the EDK/cygwin shell to perform the next step. Otherwise, be sure the host has a Tcl/TK interpreter 8.0 or newer installed.

To update the `.config` file, change directory to the Linux kernel source tree, then type:

```
$ tclsh cow.tcl
```

Once the Tcl script is run once, there is no need to run it again unless a new BSP is generated from SDK. Also, the user must compile the kernel after the script is run.

Note that you can alternatively use `xmake` in place of the standard `make` command to update the `.config` file. You would, for example, type:

```
./xmake bzImage
```

in the root of the Linux kernel source tree. The `xmake` tool first invokes the `cow.tcl` script and then invokes the standard Linux `make` command.

#### For MontaVista Linux 5.0:

If the target directory is left blank or does not point to a valid Linux kernel source tree, copy the sparse Linux tree from the project area to the working kernel tree.

The default Linux kernel source tree for MontaVista Linux 5.0 has all of the Xilinx-related drivers enabled. Specific drivers are then enabled when the system probes the device tree, that describes the hardware in the system. There is no need for the Xilinx tools or the user to enable specific drivers in the Linux kernel.

To build the kernel, first type:

```
make ml403_defconfig (for virtex4 boards)
```

or

```
make ml507_defconfig (for virtex5 boards)
```

This sets up the kernel for the processor on the board (PowerPC 405 or PowerPC 440).

Then, if using a ramdisk, type:

```
make zImage.initrd
```

otherwise:

```
make zImage
```

3. The *target directory* is left blank and the kernel is configured manually.

If the target directory is left blank, copy the `sparse` Linux tree from the project area to the working kernel tree. Then, manually configure the kernel using `make menuconfig` or its equivalent. See the following section on [“Manually Configuring the Kernel”](#).

## Manually Configuring the Kernel

This section gives details on manually configuring the kernel for Xilinx-related IP. If you are using MontaVista Linux 5.0 or if the target directory specified points to a valid Linux kernel tree, you might not need to use these steps, which means the kernel `.config` was updated during the BSP generation process to match the hardware design.

The default kernel configuration file that comes with a Linux 2.6 distribution contains a general set of kernel options. MontaVista Linux kernel source comes with predefined kernel configuration files for various development boards. One of these other configuration files may be a better starting point for your needs. These other configuration files can be found at:

```
linux/arch/ppc/configs
```

in the Linux kernel source tree. To use one of these configuration files, copy the desired configuration file to:

```
linux/.config
```

It is a good idea to first save a copy of the original configuration file, `.config`, in case the original configuration needs to be restored in the future.

One of the common methods for configuring the Linux kernel is to use the `make menuconfig` command. There are several other methods for configuring the Linux kernel, but for this guide, configuration options are described using the `make menuconfig` method.

Covering every kernel configuration option for the various versions of the Linux kernel is beyond the scope of this guide; however, information on using WindRiver Linux 2.0 is included as an example on how to accomplish some of the initial development tasks that will likely be encountered in your project. Configuration options for other Linux distributions and other kernel versions may vary from the examples.

## Booting From a Compact Flash Card (using System ACE)

There are various boot loaders that can be selected for booting Linux from a Compact Flash (CF) card. However, Xilinx and related boards often provide an alternative boot method called Booting from SystemACE™. Booting from SystemACE is different from other boot loaders in that it also loads a hardware bitstream into the FPGA.

Booting from System ACE involves the following steps:

1. Generate the hardware bitstream.
2. Build the Linux kernel.
3. Create the System ACE file.
4. Partition the CF card.
5. Copy the System ACE file to the CF card.

Boards that provide booting from System ACE have a chip, called a System ACE chip, which will read an inserted CF card and look for a file with an `.ace` extension. This ace file contains the hardware bitstream along with possibly an executable program. The System ACE chip then loads the FPGA with the hardware bitstream, and if there is an executable program, it will load the program into memory and begin executing the program.

Keep in mind that the hardware bitstream can also have an application that runs in block RAM in the FPGA. When booting from System ACE, it is recommended to have such an application in the hardware bitstream such as a bootloader or bootloop application. This will ensure that the processor does not execute random instructions in the timing window between when the FPGA is programmed and when the application in the ace file is loaded and run. When in doubt, just use the EDK processor bootloop program.

To boot from System ACE, the ace file needs to be in the first partition on the CF card. This partition needs to be formatted to have the DOS file system. This DOS partition might need to be created on the CF card and should be large enough to hold the ace file. Extra space for additional ace files may be desired as well. 10 megabytes should be sufficient for most situations. If multiple ace files are being managed on the CF card, refer to the *SystemACE Compact Flash Solution* data sheet (DS080), which can be found on the Xilinx web site ( <http://www.xilinx.com> ).

**Note:** CF card images can be found for the Xilinx ML403 and ML507 boards at <http://www.xilinx.com/ml403> and <http://www.xilinx.com/ml507> under the Demos and Reference Designs link.

Finally, the ace file needs to be copied to the DOS partition on the CF card. Refer to the Xilinx System ACE datasheet for information on where in the DOS partition the ace file needs to reside. To boot the system, ensure that the CF card is in the proper card reader slot before powering on the board. If everything is in proper order, the System ACE chip boots accordingly.

## Setting Up Ethernet

This section describes the steps required to setup ethernet on Xilinx boards. Other development boards could be set up similarly, so this section might be useful for other boards.

In the Xilinx ML403 and ML507 boards, a unique ethernet MAC address for the board is stored in an EEPROM. The EEPROM is accessed from the FPGA using an I2C bus, and therefore an I2C controller within the FPGA. The Linux BSPs for these Xilinx boards attempt to read the MAC address over I2C during initialization. In Linux, if the MAC address cannot be found, a default MAC address is used, although, it is not very convenient if your network has many of these development boards attached, as each board needs a different kernel software with each different default MAC address. The default MAC address is defined in

`arch/ppc/boot/simple/embedded_config.c`.

In many cases there is a need to use Ethernet without an I2C bus, thus the I2C driver is not present. In other cases, other methods of retrieving the MAC address are desired. If, for there is a need to use Ethernet without the I2C driver, in

`arch/ppc/boot/simple/embed_config.c`, the line

```
#error I2C needed for obtaining the Ethernet MAC address
```

might need to be removed or changed into a warning or comment line to avoid a compilation error.

To retrieve the MAC address, the I2C bus is used to read the EEPROM containing the MAC address. To use Ethernet with the stored MAC address, use the following steps to configure the Linux kernel:

1. Enable the I2C driver in the kernel.
2. Enable the Ethernet driver in the kernel.

**Note:** A common mistake is to get to this section of the document, and try to enable the I2C driver while forgetting that the I2C IP core is not included in the hardware design of the FPGA. Remember to make sure the I2C IP core is included in the hardware configuration.




Figure 4: Enabling I2C in the Kernel

The I2C driver can be enabled in the kernel by selecting **Device Drivers > I2C Support > I2C Algorithms**, then **I2C IP** from Xilinx EDK in the **make menuconfig** menus.

If the root filesystem is to reside on NFS, it is best to have the I2C driver included in the kernel. Otherwise the I2C driver can be built as a module.




Figure 5: Enabling 10/100/1000 Ethernet in the Kernel

You can enable the ethernet driver in the kernel from *make menuconfig* by selecting **Device Drivers > Networking support > Ethernet (10 or 100Mbit) then Xilinx 10/100 Mbit EMAC support or Ethernet (1000 Mbit) then Xilinx 10/100/1000 Mbit TEMAC support**. If the root file system will reside on NFS, this driver should be built into the kernel. Otherwise it can be built as a module. By default, the BSPs for the Xilinx boards in Linux have 10/100 Ethernet enabled in the kernel (not as a module).

## Linux Root Filesystem Setup

The location of the root filesystem can reside in a number of different places irrespective of how the system boots. The root filesystem may reside on an NFS network share, on a CF card, or even get loaded into RAM, among other choices.

There are various methods for creating the root filesystem contents including using vendor tools. Describing how to create a root filesystem or even describing what executables are needed on the root filesystem is beyond the scope of this guide. Some good resources for getting help in this area are:

*Building Embedded Linux Systems:* (<http://www.oreilly.com/catalog/belinuxsys/index.html>)

*Linux From Scratch Project:* (<http://www.linuxfromscratch.org>)

*Filesystem Hierarchy Standard:* (<http://www.pathname.com/fhs/>)

**Note:** If the Xilinx ML403 or ML507 is being used and you are using MontaVista Linux, you can start with the root filesystem that is on the CompactFlash card that comes with the board. Note that the root filesystem on the CF card was built for MontaVista Linux and is not guaranteed to work with Wind River Linux.

In an embedded system, there is often a requirement to separate the static root filesystem (used for boot-up processes) from an area that is storing transient, field-use data or end-user data. This separation can prevent dynamic data from accidentally overwriting system files or simply filling up the root filesystem preventing the system from booting.

Linux supports a range of file systems such as Ext2, Ext3, ReiserFS, JFS, XFS, and others. The root filesystem for many embedded systems remains mostly static. In this case a good filesystem to use is Ext2, which is widely used and is well tested.

If the embedded system will be writing many files, in particular large files, the XFS file system is a good choice. Ext3 is also commonly used.



**Note:** Using Ext3 or XFS on a CF card is not particularly useful, as CF cards are relatively slow and have a relative low capacity. If all that is being written or modified is configuration data written through well-defined methods, using a single root partition should be sufficient. Use of Ext3, XFS, or some other filesystems is more beneficial when there is a fairly fast or large-capacity storage medium in the embedded system, such as a hard disk.

### Using the Root Filesystem on a Compact Flash Card

This section explains how to use a root filesystem on a CF card, accessed through System ACE. If the root file system is to reside on the CF card, the following steps are needed:

1. Partition the CF card.
2. Create file systems on the CF card.
3. Copy the root filesystem files and directories.
4. Configure the kernel to compile in the CF card drivers.
5. Configure the kernel boot parameters to use the root file system on the CF card.

If a CF card needs to be re-partitioned to hold the root filesystem, an easy way to partition it is to attach a CF card reader to a Linux workstation and use the Linux tools for partitioning drives. Linux *fdisk* seems to work well. On a system here, the CF card could be accessed through */dev/sda*, though this may be different on your system.

**Note:** If the CF card is also going to be used to boot from System ACE, remember to leave the first partition as a DOS partition.

Technically, a swap partition is not needed. However, having a swap partition increases the amount of virtual memory available. The recommended swap partition size is usually twice the size of RAM. Though, more or less swap space might be specified depending on the system needs. When creating a swap partition, remember to set the partition type to Linux Swap (type 82).

The partitions for the root filesystem should be large enough to hold the files being placed in the root filesystem. A helpful utility for determining the root filesystem size, if it's in a staging area, is *du*. When creating the root partition, remember to set the partition type to Linux (type 83).

After the partitions are created, the file system on the Linux partitions must be created. Some Linux tools such as *parted* are capable of creating the empty filesystem at the time each partition is created. Otherwise, a tool such as *mkfs* is required.

Often the root filesystem contents are placed in a staging area allowing a whole directory tree to be copied over at once. When copying such a directory tree, it is a good idea to get the file and directory attributes set correctly before performing the copy. Make sure when performing the copy to use a command that preserves the attributes such as *cp -a*, or *tar*.

After the root filesystem files are copied to the CF card, the kernel must be configured to use that root filesystem. For the kernel to be able to read the CF card, the System ACE kernel driver must be enabled.

**Note:** A common mistake at this point might be to have forgotten to include the System ACE IP core in your hardware project.




Figure 6: Selecting SystemACE kernel support

The System ACE driver can be enabled by selecting **Device Drivers > Block Devices**, then **Xilinx on-chip SystemACE** in the menu from `make menuconfig`. Make sure support for this device is included in the kernel, not as a module. See Figure 4, page 11. By default in the BSP for the Xilinx boards in Linux, this option is enabled.




Figure 7: Initial Kernel Command String Option



Next, edit the initial kernel command string option. This option can be found by selecting **Platform options** in the main menu of **make menuconfig** to tell the kernel where the root filesystem resides. **Default bootloader kernel arguments** must also be selected for this option to appear. The `root=` item of this initial kernel command string should, among other options, contain

```
root=/dev/xsysace2 rw
```

where `N` is the partition number of the root file system on the CF card.

By default in the BSPs for the Xilinx boards, this option is set up to use the root filesystem on a CF card.

## Using the Root Filesystem in a RAM disk

When using a RAM disk for the root filesystem, the RAM disk image gets linked in with the kernel image. The process for using a root filesystem is nearly identical to using an initial RAM disk (`initrd`). The only difference is that in the boot sequence instead of performing a pivot root to the root filesystem on a different medium, the kernel performs a pivot root back to the RAM disk file system. Note that as of this writing Wind River Linux does not officially support a ramdisk rootfs.

The steps needed to use a RAM disk root filesystem are:

1. Create the RAM disk file.
2. Configure the kernel to have the RAM disk driver.
3. Configure the kernel initial command string to use the root from RAM disk.
4. Build the kernel so it includes the ram disk.

Directions for how to make use of this pre-built image are described below. If for some reason this RAM disk image will not work for your project, a different RAM disk image will have to be created. The Wind River Linux distribution does not contain a pre-built RAM disk image.

The RAM disk starts out as an image file containing the file system to be loaded into memory at boot time. This RAM disk image should hold a standard ext2 filesystem.

The easiest way to create the image file is to use an available Linux workstation and the following commands.

1. Create an empty RAM disk image:

```
dd if=/dev/zero of=initrd.img bs=1k count=kbytes size
mke2fs -F -v -m0 initrd.img
```

2. Mount that image file, and copy the root filesystem files to the image files. To mount the image file to `/mnt/tmp`, use:

```
mount -o loop initrd.img /mnt/tmp
```

3. Copy the files and directories, preserving their attributes, to the RAM disk root filesystem, and then unmount it.

Remember to use `cp -a` or `tar` when performing the copy so that file and directory attributes can be preserved. The `umount` program is used to unmount a filesystem.

4. If your image is mounted on `/mnt/tmp` as in the example above, use the following command to unmount the file system in the image file

```
umount /mnt/tmp
```

5. Compress the image file using the following command:

```
gzip -9 initrd.img ramdisk.image.gz
```

6. Copy `ramdisk.image.gz` to the following directory in your working Linux kernel source tree: `arch/ppc/boot/images`.

Now that the RAM disk image file is created and is in the right place, the kernel must be configured to use that file. The RAM disk driver must be enabled and the kernel initial command string must be set so it uses the RAM disk as the `/root` filesystem. Figure 8 shows the RAM disk option selection.




Figure 8: RAM Disk Options

The options for enabling RAM disk support in the kernel can be found in **make menuconfig** by selecting **Device Drivers > Block devices** in the top-level menu as shown in Figure 6, page 14. To set up the kernel for a RAM disk root, **RAM disk support** as well as **Initial RAM disk (initrd) support** must both be enabled in the kernel (not as a module). The **Default RAM disk size** should be set to a value a little larger than the actual RAM disk image uncompressed size so that there is room for temporary files used during boot up. Making the RAM disk size in the kernel 8K larger than the image uncompressed size has been observed to work well.

To configure the kernel to use the RAM disk as the root file system, the **Initial kernel command string** must be modified. This option can be found in **make menuconfig** by selecting **Platform options** in the main menu as shown in Figure 5, page 12. Note that **Default bootloader kernel arguments** must also be selected for this option to appear.

To continue using the initial RAM disk as your root file system, set the **root=** item of the **initial kernel command string** to have:

```
root=/dev/ram rw
```

**Note:** There should be no other **root=** options on this command string. Wind River Linux might use `root=/dev/ram0 rw` instead.

By default in the BSPs Xilinx boards in Linux, this option is not set up to use a RAM disk root filesystem. The part of the line that reads:

```
root =/dev/xsysace2
```

must be replaced with the correct text, as described.

## Configuring an NFS Root Filesystem

Most embedded systems do not use NFS to store the root filesystem in the final product. However, using NFS for the root filesystem during development can be useful. With an NFS root filesystem, size requirements are not an issue. This is especially useful when working with temporary debug files. It is also much easier to update an NFS root filesystem, as opposed to CF cards or RAM disk images, when, during development, new programs are discovered to be necessary.

To use an NFS share for the root file system, there are three steps:

1. Create the root filesystem on an NFS share.
2. Setup Ethernet (see above).
3. Configure the kernel boot parameters to use an NFS root.

To create the root filesystem on an NFS share, put the target root file system files in a directory tree that is to be exported through NFS. Keep in mind that the files for this share are not necessarily the same as those that run on the host system. In fact, most of the time, the system hosting the NFS will not have the same processor architecture as the target system. There are many resources available that describe how to share a directory through NFS. NFS is not fully covered here. A basic NFS share can be created on a Linux host system by adding:

```
directory path *(rw)
```

to the `/etc/exports` file and then restart the NFS daemon. Keep in mind that you have to be logged in as `root` to edit that file and to restart the NFS daemon.

To set up ethernet in the kernel see the section, “[Setting Up Ethernet](#),” page 10. Figure 9 shows the Root File System option.




Figure 9: Root File System on NFS

Last, the kernel must be told to use NFS for the root filesystem along with the location on the network of the NFS to use. In **File systems > Network File Systems**, enable **Root file system on NFS**. See [Figure 7, page 14](#). The **Initial kernel command string** is again modified to complete the settings to use the root filesystem over NFS. This option can be found in **make menuconfig** by selecting **Platform options** in the main menu as shown in [Figure 5, page 12](#).

If using an NFS server and share, replace the `root=` item of the initial kernel command string with:

```
ip=on nfsroot=nfs share rw
```

Here is an example:

```
ip=on nfsroot=192.168.1.10:/export/virtex5_root rw
```

If using DHCP to retrieve the NFS server and share name, the `root=` item should contain:

```
ip=on root=/dev/nfs
```

By default in the BSPs for the Xilinx boards in Linux, this option is not set up to use the root filesystem over NFS. The part of the line that reads

```
root =/dev/xsysace2
```

needs to be replaced with the correct text as described.

## Configuring a Serial/UART Main Console

Linux provides for various consoles to be connected. Some may be over a serial port while others are through a keyboard and monitor. The main console is the console on which the kernel displays messages. Other consoles merely provide additional login sessions.

To have the main console use a serial port, there are three steps:

1. Configure the kernel to include a UART driver.
2. Configure the UART driver to include support for the main console.
3. Configure the kernel boot parameters to use UART as the primary console.

To set up the kernel so that it uses the serial port for the main console, the correct UART driver needs to be enabled according to the hardware configuration. The UART Lite driver is for the UART Lite IP core that may be present in your hardware configuration. Otherwise the standard Linux UART driver is used. [Figure 10, page 19](#) shows the Kernel configuration for a UARTLite serial port.




Figure 10: Kernel Configuration for UART Lite

The option to enable the **Xilinx UART Lite** driver can be found under the **Device Drivers > Character devices > Serial drivers** menu in **make menuconfig**. If using the UART Lite driver for the main console over a serial port, this driver must be enabled in the kernel, as opposed to being a module. After Xilinx UART Lite is enabled, select **Console on UART Lite port**, as shown in Figure 11.




Figure 11: Kernel Configuration for UART 16550

If, instead of the UART Lite IP core, the UART16550 IP core is used, use the standard Linux 16550 serial driver. This option is in the **Device Drivers > Character devices > Serial drivers** menu. As with the UART Lite, this driver must be included in the kernel instead of being a module, and the **Console on 8250/16550 and compatible serial port** option must be enabled also.

After a UART driver is enabled and configured to allow a serial console, the **Initial kernel command string** option must be modified. See Figure 5, page 12.

Ensure the Initial kernel command string option contains the following text:

For UART Lite (WR GPP LE 2.0):

```
console=ttyULport number
```

For UART 16550:

```
console=ttyS port number,baud rate
```

where:

- *port number* refers to which serial port is used.
- *baud rate* is the speed of the serial port.

For example, for a 16550 serial console on the first serial port with a baud rate of 9600, the string looks like

```
console=ttyS0,9600
```

When using a string, as in the example above, a client terminal application should connect using 9600 bps, 8 data bits, no parity, and 1 stop bit. Note that the UART Lite baud rate is fixed at hardware build time, so there is no need to specify it in software.

Sometimes there is uncertainty about how the main console is set up and how subsequent consoles are set up. With the main console on the serial port, all of the boot messages are sent to the serial port. This is generally the desired outcome for embedded development. Error messages can be seen during the boot up sequence. The method described here to set up the main serial console should not be confused with methods for attaching additional console through the `/etc/inittab` file.

## Configuring PCI and Related Peripherals

This section describes the configuration options for the ML410 board. If you are using the automatic configuration update feature in SDK (`cow.tcl` or `xmake`), you can ignore this section.

The following is a quick list of the **make menuconfig** options for each of the PCI devices on the ML410 using WindRiver Linux 2.0.

- Enable:
  - Bus Options > PCI Support
  - Device Drivers > ATA/ATAPI/MFM/RLL support > ATA/ATAPI/MFM/RLL support
  - Enhanced IDE/MFM/RLL disk/cdrom/tape/floppy/support
  - Include IDE/ATA-2 DISK support
  - Include IDE/ATAPI CDROM support
  - Include IDE/ATAPI TAPE support
  - PCI IDE chipset support
  - Sharing PCI IDE interrupts source
  - Boot off-board chipsets first support
  - Generic PCI IDE chipset support
  - Generic PCI bus-master DMA support
  - ALI M15x3 chipset support
  - PROMIS PDC202{46|62|65|
  - Device Driver > SCSI device support > SCSI device support
  - SCSI generic support

If using a 3COM Ethernet card:

- Enable:
  - Device Driver > Networking support > Ethernet (10 or 100Mbit) > 3COM cards
  - 3c590/3c900 series (592/595/597) Vortex/Boomerang support
  - Device Driver > USB support > Support for Host-side USB
  - USB device filesystem

**Note:** Options might vary based upon your needs.

## Linux Devices Reference

**Table 1** provides the relationship between driver modules, Xilinx provided IP cores, location of driver source files, and kernel config items.

**Table 1: Drivers and IP cores supported in Linux**

Xilinx Driver	Xilinx IP Core	Driver Location in LSP	Linux Kernel Config Item
n/a	opb_uart16550 plb_uart16550 xps_uart16550	linux/drivers/serial/8250.c	Device Drivers/Character devices/Serial drivers/ 8250/16550 and compatible serial support
uartlite	opb_uartlite xps_uartlite	linux/drivers/serial/uartlite.c	Device Drivers/Character devices/Serial drivers/Xilinx UART Lite support
emac	opb_ethernet plb_ethernet	linux/drivers/net/xilinx_emac	Device Drivers/Networking support/Network device support/Ethernet (10 or 100Mbit)/Xilinx 10/100 Mbit EMAC support
temac	plb_temac	linux/drivers/net/xilinx_temac	Device Drivers/Networking support/Network device support/Ethernet (1000 Mbit)/Xilinx 10/100/1000 Mbit TEMAC support
litemac	xps_ll_temac	linux/drivers/net/xilinx_temac	Device Drivers/Networking support/Network device support/Ethernet (1000 Mbit)/Xilinx 10/100/1000 Mbit TEMAC support
llfifo	xps_ll_fifo	linux/drivers/xilinx_common	n/a
lldma	mpmc w/ sdma ppc440 dma	linux/drivers/xilinx_common	n/a
n/a	opb_intc dcr_intc xps_intc	linux/arch/ppc/syslib/xilinx_pic.c	n/a
iic	opb_iic xps_iic	linux/drivers/i2c/algos/xilinx_iic	Device Drivers/I2C support/I2C Algorithms/I2C IP from Xilinx EDK
n/a	plb_tft_cntlr_ref	linux/drivers/video/xilinuxfb.c	n/a
touchscreen_ref	opb_tsd_ref	linux/drivers/char/xilinux_ts	n/a
ps2_ref	opb_ps2_dual_ref opb_ps2_ref	linux/drivers/input/serio/xilinx_ps2	Device Drivers/Input device support/Xilinx PS/2 Controller Support
spi	opb_spi xps_spi	linux/drivers/char/xilinx_spi	Device Drivers/Character devices/Xilinx SPI
sysace	opb_sysace xps_sysace	linux/drivers/block/xilinx_sysace	Device Drivers/Block devices/Xilinx on-chip System ACE

Table 1: Drivers and IP cores supported in Linux (Cont'd)

Xilinx Driver	Xilinx IP Core	Driver Location in LSP	Linux Kernel Config Item
gpio	opb_gpio plb_gpio xps_gpio	linux/drivers/char/xilinx_gpio	Device Drivers/Character devices/Xilinx GPIO support
common	n/a	linux/drivers/xilinx_common	n/a

## Driver Configuration and the Platform Bus

The Linux 2.6 distributions and Xilinx device drivers have begun to move toward the platform bus model for driver initialization. This means that (almost) all Xilinx drivers no longer depend on `xparameters.h`, nor do they use the `_g.c` file for driver configuration. Instead, the files `virtex.c` and `virtex.h` in `arch/ppc/platforms/4xx` and `xilinx_devices.h` in `include/linux` specify the Xilinx driver configurations. Device drivers get their configuration from the platform bus structures populated in the `virtex.c` file. The `virtex.*` files currently depend on `xparameters.h`, but in the future could be made to depend instead on non-static configuration data, such as data passed to the kernel from a bootloader. The ultimate intent being that the kernel tree need not be recompiled in order to reconfigure Xilinx device drivers.

## Additional Resources

If you have a question or problem associated with the Xilinx IP or drivers associated with such IP, contact Xilinx Support. The Xilinx support web site is here: <http://support.xilinx.com>.

If you have purchased MontaVista or Wind River Linux, you are entitled to support from those vendors.

The Internet contains information on Linux. A few Internet resources can be found here:

- *Linux From Scratch Project* (<http://www.linuxfromscratch.org>)
- *Filesystem Hierarchy Standard* (<http://www.pathname.com/fhs>)

In addition to just using web searches, there are also various e-mail lists you can search or join. At the time of this writing, one such list called *linuxppc-embedded*, can be found here:

<https://ozlabs.org/mailman/listinfo/linuxppc-embedded>

The archives for this list can be found here: <http://ozlabs.org/pipermail/linuxppc-embedded/>

O'Reilly also publishes several good books on using and developing software for Linux. Here are some such books that you might find useful:

- *Running Linux*, 4th Edition (<http://www.oreilly.com/catalog/runux4/>)
- *Building Embedded Linux Systems* (<http://www.oreilly.com/catalog/belinuxsys/index.html>)
- *Understanding the Linux Kernel*, 3rd Edition (<http://www.oreilly.com/catalog/understandlk/index.html>)
- *Linux Device Drivers*, 3rd Edition (<http://www.oreilly.com/catalog/linuxdrive3/index.html>)
- *Linux Network Administrator's Guide* (<http://www.oreilly.com/catalog/linag3/index.html>)



## Overview

One of the key embedded system development activities is the development of the BSP. The creation of a BSP can be a lengthy and tedious process that must be incurred when there is a change in the microprocessor complex which is comprised of the processor and associated peripherals. Although the management of these changes applies to any microprocessor-based project, now the changes can be accomplished more rapidly with the advent of programmable System-on-Chip (SoC) hardware.

This document describes automatic generation of a customized VxWorks 6.3 BSP for the IBM PowerPC<sup>®</sup> 405/440 processors and peripherals as defined within a Xilinx<sup>®</sup> FPGA. An automatically generated BSP enables embedded system designers to:

- Decrease the development cycles, thereby decreasing the time-to-market
- Create a customized BSP to match the hardware and the application
- Eliminate BSP design bugs (automatically created based on certified components)
- Enable application software development by eliminating the wait for BSP development

The VxWorks 6.3 BSP is generated from the Software Development Toolkit (SDK), an IDE delivered as part of the Xilinx Embedded Development Kit (EDK) or available separately from Xilinx. SDK is used to create software applications for embedded systems within Xilinx FPGAs. The VxWorks BSP contains all the necessary support software for a system, including boot code, device drivers, and RTOS initialization. The BSP is customized based on the peripherals chosen and configured by the user for the FPGA-based embedded system.

Experienced BSP designers should readily integrate a generated BSP into their target system. Conversely, less experience users might encounter difficulties because even though SDK can generate an operational BSP for a given set of IP hardware, there is additional configuration and adjustments required to produce the best performance out of the target system. It is recommended that the user have available the *Wind River VxWorks BSP Developer's Guide* and the *VxWorks Application Programmer's Guide* or consider the Wind River classes on BSP design, available at an additional cost.

## Requirements

The Wind River Workbench 2.5 development kit must be installed on the host computer. Because SDK generates re-locatable BSPs that are compiled and configured outside the SDK environment, the host computer need not have both the Xilinx SDK and Workbench installed.

## Microprocessor Library Definition

SDK supports a plug-in interface for 3rd party libraries and operating systems through the Microprocessor Library Definition (MLD) interface, thereby allowing 3rd party vendors to have their software available to SDK users. In addition, it provides the vendors a means for tailoring their libraries or BSPs to the FPGA-based embedded system. Because the system can change easily, this capability is critical in properly supporting embedded systems in FPGAs.

Xilinx develops and maintains the VxWorks 6.3 MLD in its SDK releases. The MLD is used to automatically generate the VxWorks 6.3 BSP.

## Template-Based Approach

A set of VxWorks 6.3 BSP template files are released with the SDK. These template files are used during automatic generation of the BSP and appropriate modifications are made based on the makeup of the FPGA-based embedded system.

These template files could be used as a reference for building a BSP from scratch if the user chooses not to automatically generate a BSP.

## Device Drivers

A set of device driver source files are released with the SDK and reside in an installation directory. During creation of a customized BSP, device driver source code is copied from this installation directory to the BSP directory. Only the source code pertaining to the devices built into the FPGA-based embedded system are copied. This copy provides the user with a self-contained, standalone BSP directory which can be modified or relocated. If the user makes changes to the device driver source code for this BSP, then later wishes to undo the changes, the SDK tools can be used to regenerate the BSP. At that point, the device driver source files are recopied from the installation directory to the BSP.

## Generating the VxWorks 6.3 BSP

### Using SDK

SDK is available as a standalone executable or within the EDK and is a software development environment for embedded software around Xilinx PowerPC 405/440 processors or MicroBlaze™ processor-based embedded systems. This section describes the steps needed to create a VxWorks 6.3 BSP using SDK. These steps are applicable when using The Xilinx 11.1 tools or later.

It is assumed that a valid hardware design has been created and exported to SDK, and SDK has been opened and pointed to the hardware design.

1. Using **File > New**, create a new Board Support Package project. In the dialog box, enter a project name, and select **vxworks6\_3** as the Board Support Package Type. Note that SDK can manage multiple projects of different BSP types.

The Board Support Package Settings... dialog box, displays.

2. Configure the VxWorks console device:

If a serial device, such as a Uart is used as the VxWorks console, select or enter the instance name of the serial device as the STDIN/STDOUT peripheral in the Board Support Package Settings dialog box. It is important to enter the same device for both STDIN and STDOUT. Currently, only the Uart 16550/16450 and UartLite devices are supported as VxWorks console devices.

3. Integrate the device drivers:

- a. Connect to VxWorks:

The **connected\_periphs** dialog is in the **Board Support Package Settings** dialog box. Peripherals have been pre-populated for user convenience. Use this dialog box to modify those peripherals to be tightly integrated with the OS, including the device that was selected as the STDIN/STDOUT peripheral. See [“Device Integration,” page 6](#) for more details on tight integration of devices.

- b. Memory Size:

This field is used to configure the BSP to match the actual hardware memory size on your board.

- c. Uart16550\_baud\_rate:

This field is used to input the baud rate for projects with the UART 16550/16450 core. It is not necessary to enter a value here for projects with the UART Lite core since the baud rate is set for a UART Lite at hardware build time.

#### 4. Generate the VxWorks 6.3 BSP:

Click **OK** in the **Board Support Package Settings** dialog box to generate the BSP. The output of this invocation shows in the SDK console window. When complete, the resulting VxWorks 6.3 BSP is in your SDK workspace, under the project directory name you created in step 1 under the PowerPC 405/440 instance subdirectory. For example, if in the hardware design is the PowerPC 405 processor instance, **ppc405\_0**, the BSP resides at `<SDK workspace>/<SDK project name>/ppc405_0/bsp_ppc405_0`.

## Backups

To prevent the loss of changes to BSP source files, existing files in the directory location of the BSP are copied into a backup directory before being overwritten. The backup directory is named `backup_timestamp` where *timestamp* represents the current date and time, and is located in the BSP directory. Because the BSP that is generated by SDK is re-locatable, it is recommended to relocate the BSP from the SDK project directory to an appropriate BSP development directory as soon as the hardware platform is stable.

## The VxWorks 6.3 BSP

This section describes the VxWorks 6.3 BSP output by SDK. Familiarity with the Wind River Workbench 2.5 IDE and a set up workbench environment is assumed. You can use the Wind River environment utility command-line **wrenv** on a Windows platform. See the *Wind River Workbench Command-Line Users Guide*: “Creating a Development Shell With wrenv” for more information on using the command-line utilities.

The automatically-generated BSP is integrated into the Workbench IDE. The BSP can be compiled from the command-line using the Workbench make tools, or from the Workbench Project facility (also referred to as the Workbench IDE). Once the BSP has been generated, type **make vxWorks** from the command-line to compile a bootable RAM image.

If using the Workbench Project facility, you can create a project based on the newly-generated BSP, then use the build environment provided through the IDE to compile the BSP.

In Workbench 2.5, the **diab** compiler is supported in addition to the GNU compiler. You can modify the VxWorks 6.3 BSP **Makefile** created by SDK to use the **diab** compiler instead of the **gnu** compiler. Look for the make variable named **TOOLS** and set the value to **sfdiab** instead of **sfgnu**. For a PowerPC 440 processor with hard Floating-Point Unit (FPU) systems, select either **diab** or **gnu**. If using the Workbench Project facility, you can select the desired tool when the project is first created.

## Driver Organization

This section briefly discusses how Xilinx drivers are compiled and linked and eventually used by Workbench makefiles to be included into the VxWorks image.

Xilinx drivers are implemented in C programming language and can be distributed among several source files unlike traditional VxWorks drivers, which consist of single C header and implementation files.

There are up to three components for Xilinx drivers:

- Driver source inclusion
- OS independent implementation
- OS dependent implementation (optional)

*Driver source inclusion* refers to how Xilinx drivers are compiled. For every driver, there is a file named `procname_drv_dev_version.c`. Using the **#include** command will include the source file(s) (\*.c) for each driver for each given device.

This process is analogous to how the VxWorks `sysLib.c` #include's source for Wind River supplied drivers.

Xilinx files are not included in `sysLib.c`, because of namespace conflicts and maintainability issues. If all Xilinx files were part of a single compilation then the unit, static functions, and data are no longer private. This places restrictions on the device drivers and would negate their operating system independence.

The OS-independent part of the driver is designed for use with any operating system or any processor. It provides an API that uses the functionality of the underlying hardware. The OS-dependent part of the driver adapts the driver for use with VxWorks. Such examples are SIO drivers for serial ports, or END drivers for ethernet adapters. Not all drivers require the OS dependent drivers, nor is it required to include the OS-dependent portion of the driver in the VxWorks build.

## Device Driver Location

The automatically-generated BSP resembles most other Workbench BSPs except for the placement of device driver code. Off-the-shelf device driver code distributed with the Workbench IDE typically resides in the `vxworks-6.3/target/src/drv` directory in the Workbench installation directory. Device driver code for a BSP that is automatically generated resides in the BSP directory. This minor deviation is because of the dynamic nature of FPGA-based embedded system. Because the FPGA-based embedded system can be reprogrammed with new or changed IP, the device driver configuration can change, calling for a more dynamic placement of device driver source files.

The directory tree for the automatically generated BSP is shown in [Figure 1](#).




Figure 1: Driver Directory Location

The top-level directory is named according to the name of the processor instance in the hardware design project. The customized BSP source files reside in this directory. There is a subdirectory within the BSP directory named according to the processor instance with `_drv_csp` as a suffix. The driver directory contains two subdirectories. The `xsrc` subdirectory contains all the device driver related source files. If building from the Workbench Project facility, the files generated during the build process reside at `$PRJ_DIR/$BUILD_SPEC`.

## Configuration

BSPs generated by SDK are configured like any other VxWorks 6.3 BSP. There is little configurability to Xilinx drivers because the IP hardware has been pre-configured. The only configuration available generally is whether the driver is included in the VxWorks build at all. The process of including/excluding drivers depends on whether the Project facility or the command-line method is being used to perform the configuration activities.

**Note:** Including a Xilinx device driver does not mean that the driver is used automatically. Most drivers with VxWorks adapters have initialization code. In some cases the user is required to add the proper driver initialization function calls to the BSP.

When using SDK to generate a BSP, the resulting BSP files might contain “TODO” comments. These comments, many of which originate from the PowerPC 405/440 processor BSP template provided by Wind River, provides suggestions about what the user must provide to configure the BSP for the target board. The *VxWorks BSP Developer Guide* and *VxWorks Application Programmer's Guide* are resources for BSP configuration.

## Command-Line Driver Inclusion/Exclusion

Within the BSP, a set of constants (one for each driver) are defined in *procname\_drv\_config.h* and follow the format:

```
#define INCLUDE_<XDRIVER>
```

This file is included near the top of *config.h*. By default all drivers are included in the build. To exclude a driver, add the following line in *config.h* after the inclusion of the *procname\_drv\_config.h* header file.

```
#undef INCLUDE_<XDRIVER>
```

This exclusion prevents the driver from being compiled and linked into the build. To re-instate the driver, remove the *#undef* line from *config.h*. Some care is required for certain drivers. For example, Ethernet might require that a DMA driver be present. Undefined the DMA driver will cause the build to fail.

## Project Facility Driver Inclusion/Exclusion

The file *50<csp\_name>.cdf* resides in the BSP directory and is tailored during creation of the BSP. This file integrates the Xilinx device drivers into the Workbench IDE. The Xilinx device drivers are hooked into the IDE at the *hardware/peripherals* sub-folder of the components tab. Below this are individual device driver folders. An example of the GUI with Xilinx drivers is shown in [Figure 2](#).

To add or delete Xilinx drivers, include or exclude driver components as with any other VxWorks component.




Figure 2: Workbench 2.5 Project IDE - VxWorks

**Note:** Whatever configuration specified in *procname\_drv\_config.h* and *config.h* is overridden by the project facility.

## Building VxWorks

The automatically generated BSPs follow the standard Workbench conventions when it comes to creating VxWorks images. Refer to Workbench documentation on how to make a VxWorks image.

## Command-Line BSP Build Extensions

The Xilinx drivers are compiled/linked with the same toolchain VxWorks is built with. Minor additions to the Makefile were required to help Workbench find the location of driver source code files.

## Project BSP Build Extensions

The number of new files used to integrate the Xilinx device drivers into the Workbench build process can be seen in the *bsp\_name* directory. As stated earlier, these files are automatically created by SDK. The user need only be aware of that the files exist. These files are prefixed with the instance name of the processor.

## Device Integration

Devices in the FPGA-based embedded system have varying degrees of integration with the VxWorks operating system. The degree of integration is selectable by the SDK user in the Connected Peripherals dialog box of the Library/OS Parameters tab. Below is a list of currently supported devices and their level of integration.

- One or more UART 16450/16550/Lite devices can be integrated into the VxWorks Serial I/O (SIO) interface. This makes a UART available for file I/O and printf/stdio. Only one UART device can be selected as the console, where standard I/O (stdin, stdout, and stderr) is directed. A UART device, when integrated into the SIO interface, must be capable of generating an interrupt. Reference the *sysSerial.c* file of the BSP to see details of this integration.
- Ethernet 10/100 MAC, Ethernet Lite 10/100, Gigabit Ethernet controller and MAC, and 10/100/1000 Tri-speed Ethernet MAC devices can be integrated into the VxWorks Enhanced Network Driver (END) interface. This makes the device available to the VxWorks network stack and thus socket-level applications. An Ethernet device, when integrated into the END interface, must be capable of generating interrupts. Reference the *configNet.h* and *sysNet.c* files of the BSP to see details of this integration. Also, the user might need to modify the default bootline values in *config.h* for the Ethernet device to be used as the boot device.
- An Interrupt controller can be connected to the VxWorks intLib exception handling and the PowerPC 405/440 external non-critical interrupt pin. The generated BSP does not currently handle interrupt controller integration for the critical interrupt pin of the PowerPC 405/440, nor does it support direct connection of a single interrupting device (other than the intc) to the processor. However, the user is always able to add manually this integration in the *sysInterrupt.c* file of the BSP.
- A System ACE™ controller can be connected to VxWorks as a block device, allowing the user to attach a filesystem to the CompactFlash device connected to the System ACE controller. The user must call manually the BSP functions to initialize the System ACE/CompactFlash as a block device and attach it to the DOS operating system. The functions currently available to the user are: *sysSystemAceInitFS()* and *sysSystemAceMount()*. A system ACE controller, when integrated into the block device interface, must be capable of generating an interrupt. Reference the file *sysSystemAce.c* in the BSP for more details. The BSP will mount the compact flash as a DOS FAT disk partition using the Wind River DosFs2.0 add-on.



For the VxWorks libraries to be included into the image, the following packages must be defined in `config.h` or by the Project Facility:

- `INCLUDE_DOSFS_MAIN`
- `INCLUDE_DOSFS_FAT`
- `INCLUDE_DISK_CACHE`
- `INCLUDE_DISK_PART`
- `INCLUDE_DOSFS_DIR_FIXED`
- `INCLUDE_DOSFS_DIR_VFAT`
- `INCLUDE_XBD_BLK_DEV`
- `INCLUDE_XBD_PART_LIB`

Programmatically, an application can mount the DOS file system using the following API calls:

```
FILE *fp;

sysSystemAceInitFS();
if (sysSystemAceMount("/cf0", 1) != OK)
{
    /* handle error */
}

fp = fopen("/cf0/myfile.dat", "r");
```

- A PCI bridge can be initialized and made available to the standard VxWorks PCI driver and configuration functions. The user is required to edit the `config.h` and `sysBusPci.c` BSP files to tailor the PCI memory addresses and configuration for their target system. Note that PCI interrupts are not automatically integrated into the BSP.
- A USB device controller can be integrated into the USB peripheral controller interface of the VxWorks BSP components. To test the USB peripheral controller using the existing Mass Storage emulator component of VxWorks, the following changes are to be done in the VxWorks source file `usbTargMsLib.c` and in the BSP file `config.h`. These changes are to be done before the VxWorks project is created.
  - Modify the `MS_BULK_OUT_ENDPOINT_NUM` constant value as "2" in `usbTargMsLib.c` file. This file is located in the *WindRiver-Installed-Directory/Vx-Works6.3/target/src/drv/usb/target/* directory.
  - After the modification, the VxWorks source is to be compiled at this directory. The compiler command for a PowerPC 440 processor based system is **make CPU=PPC32** and for a PowerPC 405 processor based system it is **make CPU=PPC405**.
  - USB MassStorage emulator uses the local memory for the storage area. The user needs to provide a minimum of 4MB space (modify the `LOCAL_MEM_SIZE` constant value in the `config.h` file as 0x400000) in the RAM. The MassStorage emulator code emulates a default storage area of 32k.
- All other devices and associated device drivers are not tightly integrated into a VxWorks interface. Instead, they are loosely integrated and access to these devices is available by directly accessing the associated device drivers from the user's application.
- User cores and associated device drivers, if included in the SDK project, are supported through the BSP generation flow. The user core device drivers will be copied into the BSP in the same way the Xilinx device drivers are copied. This assumes the directory structure of the user core device driver matches the structure of the Xilinx device drivers. The */data* and */build* sub-directories of the device driver must exist and be formatted in the same way as the Xilinx device drivers. This includes the CDF snippet and xtag files in the */build/vxworks5\_4* sub-directory. User device drivers are not automatically integrated into any OS interface (for example SIO), but they are available for direct access by an application.

## Deviations

The following list summarizes the differences between SDK generated BSPs and traditional BSPs.

- An extra directory structure is added to the root BSP directory to contain the device driver source code files.
- To keep the BSP buildable while maintaining compatibility with the Workbench Project facility, a set of files named `procname_drv_driver_version.c` populate the BSP directory that simply `#include` the source code from the driver subdirectory of the BSP.
- The BSP Makefile has been modified so that the compiler can find the driver source code. The Makefile contains more information about this deviation and its implications.
- SystemACE usage could require changes to VxWorks source code files found in the Workbench distribution directory. Refer to [“Bootrom with SystemACE as the Boot Device,” page 12](#).

## Limitations

The automatically-generated BSP is a good starting point, but should not be expected to meet all requirement without configuration. Due to the potential complexities of a BSP, the variety of features that can be included in a BSP, and the support necessary for board devices external to the FPGA, the automatically-generated BSP will likely require enhancements. However, the generated BSP is able to compile and contains the necessary device drivers represented in the FPGA-based embedded system. Some of the commonly used devices are also integrated with the operating system. Specific limitations are listed below.

- An interrupt controller connected to the PowerPC 405/440 processor critical interrupt pin is not automatically integrated into VxWorks' interrupt scheme. Only the external interrupt is currently supported.
- Bus error detection from bus bridges or arbiters is not supported.
- The command-line VxWorks 6.3 BSP defaults to use the GNU compiler. The user must manually change the `Makefile` to use the `DIAB` compiler, or specify the `DIAB` compiler when creating a Workbench project based on the BSP.
- Memory address ranges might need to be tailored in `config.h` to match specific memory devices and their address ranges.
- PowerPC 405/440 processor caches are disabled by default. You must manually enable caches through the `config.h` file or the Workbench project menu.
- When SystemACE is setup to download VxWorks images into RAM using JTAG, all boots are cold (no warm boots). This is because the System ACE controller resets the processor whenever it performs an ace file download. An effect of this could cause exception messages generated by VxWorks to not be printed on the console when the system is rebooted due to an exception in an ISR or a kernel panic.

**Note:** No compressed images can be used with SystemACE. This applies to standard compressed images created with Workbench such as bootrom. Compressed images cannot be placed on SystemACE as an ace file. SystemACE cannot decompress data as it writes it to RAM. Starting such an image will lead to a system crash.

- A command-line build cannot initialize the network when SystemACE is the boot device. This requires that the application provide code to initialize the network when SystemACE is the boot device. To circumvent this issue see the discussion of `$WIND_BASE/target/src/config/usrNetwork.c` in the [“Bootrom with SystemACE as the Boot Device,” page 12](#).
- On the PowerPC 405/440 processor, the reset vector is at physical address `0xFFFFFFF0`. There is a short time window where the processor will attempt to fetch and execute the instruction at this address while SystemACE processes the ace file.



The processor needs to be given something to do during this time even if it is a spin loop:

```
FFFFFFFFC    b .
```

If block RAM occupies this address range, then the designer who creates the bitstream should place instructions here with the ELF to block RAM utility found in the Xilinx Integrated Software Environment (ISE®) tools.

- VxBus is not supported.

## Booting VxWorks

### VxWorks Bootup Sequence

There are many variations of VxWorks images with some based in RAM, some in ROM. Depending on board design, not all these images are supported. The following list discusses various image types:

- ROM compressed images - These images begin execution in ROM and decompress the BSP image into RAM, then transfer control to the decompressed image in RAM. This image type is not compatible with SystemACE because SystemACE doesn't know the image is compressed and will dutifully place it in RAM at an address that will be overwritten by the decompression algorithm when it begins. It may be possible to get this type of image to work if modifications are made to the standard Workbench makefiles to handle this scenario.
- RAM based images - These images are loaded into RAM by a bootloader, SystemACE, or an emulator. These images are fully supported.
- ROM based images - These images begin execution in ROM, copy themselves to RAM then transfer execution to RAM. In designs with SystemACE as the bootloader, the image is automatically copied to RAM. The hand-coded BSP examples short-circuit the VxWorks copy operation so that the copy does not occur again after control is transferred to RAM by SystemACE (see `romInit.s`).
- ROM resident images - These images begin execution in ROM, copy the data section to RAM, and execution remains in ROM. In systems with only a SystemACE, this image is not supported. Theoretically block RAM could be used as a ROM, however, the current FPGAs being used in the evaluation boards may not have the capacity to store a VxWorks image which could range in size from 200KB to over 700KB.

### VxWorks Boot Sequence

This standard image is designed to be downloaded to the target RAM space by some device. Once downloaded, the processor is setup to begin execution at function `_sysInit` at address `RAM_LOW_ADRS`. (this constant is defined in `config.h` and `Makefile`). Most of the time, the device performing the download will do this automatically as it can extract the entry point from the image.

1. `_sysInit` : This assembly language function running out of RAM performs low level initialization. When completed, this function will setup the initial stack and invoke the first C function `usrInit()`. The `_sysInit` is located in source code file `<bspname>/sysALib.s`.
2. `usrInit()` : This C function running out of RAM sets up the C runtime environment and performs pre-kernel initialization. It invokes `sysHwInit()` (implemented in `sysLib.c`) to place the HW in a quiescent state. When completed, this function will call `kernelInit()` to bring up the VxWorks kernel. This function will in turn invoke `usrRoot()` as the first task.
3. `usrRoot()` : Performs post-kernel initialization. Hooks up the system clock, initializes the TCP/IP stack, etc. It invokes `sysHwInit2()` (implemented in `sysLib.c`) to attach and enable HW interrupts. When complete, `usrRoot()` invokes user application startup code `usrAppInit()` if so configured in the BSP.

Both `usrInit()` and `usrRoot()` are implemented by Wind River. The source code files they exist in are different depending on whether the command line or the Workbench Project facility

is being used to compile the system. Under the command line interface, they are implemented at `$WIND_BASE/target/config/all/usrConfig.c`. Under the project facility, they are maintained in the project directory.

### "bootrom\_uncmp" Boot Sequence

This standard image is ROM based but in reality it is linked to execute out of RAM addresses. While executing from ROM, this image uses relative addressing tricks to call functions for processing tasks before jumping to RAM.

1. Power on. Processor vectors to `0xFFFFFFFFC` where a jump instruction should be located that transfers control to the bootrom at address `_romInit`.
2. `_romInit` : This assembly language function running out of ROM notes that this is a cold boot then jumps to start. Both `_romInit` and `start` are located in source code file `bspname/romInit.s`.
3. `start` : This assembly language function running out of ROM sets up the processor, invalidates the caches, and prepares the system to operate out of RAM. The last operation is to invoke C function `romStart()` which is implemented by Wind River and is located in source code file `$WIND_BASE/target/config/all/bootInit.c`.
4. `romStart()` : This C function running out of ROM copies VxWorks to its RAM start address located at `RAM_HIGH_ADRS` (this constant is defined in `config.h` and `Makefile`). After copying VxWorks, control is transferred to function `usrInit()` in RAM.
5. Follows steps 2 and 3 of the "[VxWorks Boot Sequence](#)".

### "bootrom\_uncmp" Boot Sequence with SystemACE

This non-standard image is similar to the image discussed in the previous section except that SystemACE is used to load it. Several changes have to be made to the boot process. More information can be found in section "[Bootrom with SystemACE as the Boot Device](#)," [page 12](#).

1. Power on. SystemACE loads the image into RAM at `RAM_HIGH_ADRS` (this constant is defined in `config.h` and `Makefile`) and sets the processor to begin fetching instructions at address `_romInit`.
2. `_romInit` : This assembly language function running out of RAM notes that this is a cold boot then jumps to start. Both `_romInit` and `start` are located in source code file `<bspname>/romInit.s`.
3. `start` : This assembly language function running out of RAM simply jumps to function `_sysInit`. The call to `romStart()` is bypassed because SystemACE has already loaded the bootrom into its destination RAM address.

Follow steps 1, 2, and 3 of the "[VxWorks Boot Sequence](#)," [page 9](#).

## Bootroms

The bootrom is a scaled down VxWorks image that operates in much the same way a PC BIOS. Its primary function is to find and boot a full VxWorks image. The full VxWorks image can reside on disk, in flash memory, or on some host using the Ethernet. The bootrom must be compiled in such a way that it has the ability to retrieve the image. If the image is retrieved from an Ethernet network, then the bootrom must have the TCP/IP stack compiled in, if the image is on disk, then the bootrom must have disk access support compiled in, and so forth. The bootroms do little else than retrieve and start the full image and maintain a bootline. The bootline is a text string that sets certain user characteristics such as the IP address target when using Ethernet and the file path to the VxWorks image to boot.

Bootroms are not a requirement. They are typically used in a development environment then replaced with a production VxWorks image.

## Creating Bootroms

At a command shell in the BSP directory, issue the following command to create an uncompressed bootrom image (required for SystemACE):

```
make bootrom_uncmp
```

or

```
make bootrom
```

to create a compressed image suitable for placing in a flash memory array.

## Bootrom Display

Upon cycling power, if the bootroms are working correctly, output similar to the following should be seen on the console serial port:

```
VxWorks System Boot

Copyright 1984-2006 Wind River Systems, Inc.

CPU: ppc405_0 VirtexII Pro PPC405
Version: VxWorks 6.3
BSP version: 1.2/0
Creation date: Aug 11, 2006, 16:40:32

Press any key to stop auto-boot...
3

[VxWorks Boot]:
```

Typing **help** at this prompt lists the available commands.

## Bootline

The bootline is a text string that defines user serviceable characteristics such as the IP address of the target board and how to find a VxWorks image to boot. The bootline is maintained at runtime by the bootrom and is typically kept in some non-volatile (NVRAM) storage area of the system such as an EEPROM or flash memory. If there is no NVRAM, or an error occurs reading it, then the bootline is hard-coded with `DEFAULT_BOOT_LINE` defined in the `config.h` source code file of the BSP. In new systems where NVRAM has not been initialized, the bootline may be undefined data.

The bootline can be changed if the auto-boot countdown sequence is interrupted by entering a character on the console serial port. The **c** command can then be used to interactively edit the bootline. Enter **p** to view the bootline. On a non-bootrom image, the bootline can be changed by entering the `bootChange` command at a host or target shell prompt.

The bootline fields are defined below:

- boot device : Device from which to boot. This could be ethernet, or a local disk.
- When changing the bootline, the unit number can be shown appended to this field (`xemac0` or `sysace=10`) when prompting for the new boot device. This number can be ignored.
- processor number : Always 0 with single processor systems.
- host name : Name as needed.
- file name : The VxWorks image to boot.
- inet on ethernet (e) : The IP internet address of the target. If there is no network interface, then this field can be left blank.

- host inet (h) : The IP internet address of the host. If there is no network interface, then this field can be left blank.
- user (u) : User name for host file system access. Pick whatever name suites you. Your FTP server must be setup to allow this user access to the host file system.
- ftp password (pw) : Password of your choice for host file system access. Your FTP server must be setup to allow this user access to the host file system.
- flags (f) : For a list of options, enter the **help** command at the [VxWorks Boot]: prompt.
- target name (tn) : Name as needed. Set according to network requirements.
- other (o) : This field is useful when you have a non-ethernet device as the boot device. When this is the case, VxWorks will not start the network when it boots. Specifying an ethernet device here will enable that device at boot time with the network parameters specified in the other bootline fields.
- inet on backplane (b) : Typically left blank if the target system is not on a VME or PCI backplane.
- gateway inet (g) : Enter an IP address here if you have to go through a gateway to reach the host computer. Otherwise leave blank.
- startup script (s) : Path to a file on the host computer containing shell commands to execute once bootup is complete. Leave blank if not using a script. Examples are:
  - SystemACE resident script: /cf0/vxworks/scripts/myscript.txt
  - Host resident script: c:/temp/myscript.txt

### Bootrom with SystemACE as the Boot Device

SystemACE enabled bootroms are capable of booting VxWorks images directly off the Compact Flash device either as a regular elf file or an ace file.

#### Required Modifications to VxWorks Source

While the SDK is capable of generating a BSP that uses SystemACE in a VxWorks image that can open and close files in a DOS filesystem, it cannot generate a BSP that uses SystemACE as a bootrom boot device. To use SystemACE in this way requires extensive modifications to bootrom code provided by Wind River. Wind River allows BSP developers to change Workbench source code files provided they keep the changes local to the BSP and leave the original code as is. The two files that have to be modified from their original version are:

1. \$WIND\_BASE/target/config/all/bootConfig.c: This file is overridden with one found in the *bspname* directory. The changes needed are to add code to properly parse the bootline and to initialize and use SystemACE as a JTAG and DOS boot device. To override the default bootConfig.c, the following line must be added to the Makefile for the BSP:  
 BOOTCONFIG = ./bootConfig.c.
2. \$WIND\_BASE/target/config/comps/src/net/usrNetBoot.c: This file is overridden with one found in the *bspname/net/usrNetBoot.c* directory. The changes needed are to add code to make VxWorks aware that SystemACE is a disk based system like IDE, SCSI, or floppy drives. This change allows a BSP built from the Workbench Project downloaded with a SystemACE enabled bootrom to properly process the other field of the bootline. The existence of the modified file in the BSP directory automatically overrides the original.

Neither of these files are provided by the SDK because they are maintained in their original form by Wind River.

A third file, \$WIND\_BASE/target/src/config/usrNetwork.c, cannot be overridden because of the architecture of the command line BSP build process. This affects network capable BSPs built from the command line that are downloaded with a SystemACE enabled bootrom. Without modifying *usrNetwork.c*, affected BSPs are unable to initialize their network device and must rely on application code to perform this function.

If the user desires, they can make the change to this file in their Workbench installation. There are disadvantages to this approach because any edits made to this file affect all users of that installation and may be lost if the user upgrades or re-installs Workbench. The change to `usrNetwork.c` occurs in function `usrNetDevStart()`.

from:

```
if ((strcmp (params.bootDev, "scsi", 4) == 0) ||
    (strcmp (params.bootDev, "ide", 3) == 0) ||
    (strcmp (params.bootDev, "ata", 3) == 0) ||
    (strcmp (params.bootDev, "fd", 2) == 0) ||
    (strcmp (params.bootDev, "tffs", 4) == 0))
```

to

```
if ((strcmp (params.bootDev, "scsi", 4) == 0) ||
    (strcmp (params.bootDev, "ide", 3) == 0) ||
    (strcmp (params.bootDev, "ata", 3) == 0) ||
    (strcmp (params.bootDev, "fd", 2) == 0) ||
    (strcmp (params.bootDev, "sysace", 6) == 0) ||
    (strcmp (params.bootDev, "tffs", 4) == 0))
```

**Note:** Edit this code at your own risk.

### Special Configuration

Preparing a `bootrom_uncmp` image downloadable by SystemACE as an ace file requires special configuration. These changes are required because the bootrom is linked to begin running out of a non-volatile memory device, copy itself to RAM, then transfer control to the RAM copy. The changes will prevent the copy operation since SystemACE has already placed the bootrom into a RAM device at reset.

- Change the definitions of `ROM_TEXT_ADRS` and `ROM_WARM_ADRS` to a value equivalent to `RAM_HIGH_ADRS` in both `config.h` and `Makefile`.
- Change the assembly language code at the start label in `romInit.s` to jump to function `_sysInit`:

```
start:
    LOADPTR (r1, _sysInit)
    mtlr    r1
    blrl
```

### Bootline Format

The boot device field 6\_3 of the bootline is specified using the following syntax:

*sysace=partition number*

where *partition number* is the partition from which to boot. Normally, this value is set to 1, but some compact flash devices do not have a partition table and are formatted as if they were a large floppy disk. In this case, specify 0 as the partition number. Failure to get the partition number correct will lead to errors being reported by the VxWorks dosFS libraries when the drive is mounted.

The file name field of the bootline is set depending on how the System ACE is to boot the system. There are two boot methods:

1. Boot from a regular file. This is similar to network booting in that the vxWorks image resides in the SystemACE compact flash storage device instead of the host file system. The compact flash device is a DOS FAT file system partition. Build vxWorks using the Workbench tools, copy the resulting image file to the compact flash device using a USB card reader or similar tool, then specify that file in the file name field of the boot ROM. The file name must have the following syntax:

```
cf0/path to vxWorks image
```

where:

- `cf0` is the mount point
- The *path to vxWorks image* provides the complete path to the VxWorks image to boot. When being specified in this way, the bootrom will mount the drive as a FAT formatted disk, load the file into memory and begin execution.

2. Boot from an ace file. The ace file can contain HW only, SW only, or HW + SW. When booting from an ace file with HW, the FPGA is reprogrammed. If the ace file contains SW, then it is loaded into the memory, the PC of the processor is set to the entry point and released to begin fetching instructions. This boot method is flexible in that a totally different HW profile can be booted from a VxWorks bootrom. The file name must have the following syntax:

```
cfgaddr[x]
```

where `[X]` is a number between 0 and 7 that corresponds to one of the configuration directories specified in the `XILINX.SYS` file resident in the root directory of the compact flash device. If `[X]` is omitted, then the default configuration is used. The default configuration is typically selected by a rotary switch mounted somewhere on the evaluation board. The bootrom will trigger a JTAG download of the ace file pointed to by the specified config address. There should be only a single file with an `.ace` extension in the selected configuration directory.

In either boot scenario, if the ethernet device is to be started when the downloaded VxWorks starts, the "other" field of the bootline must be modified to contain the name of the network device.

### Bootrom with 10/100 Ethernet (EMAC) as the Boot Device

SDK will generate a BSP that is capable of being built as a bootrom using the EMAC as a boot device. Very little user configuration is required. The MAC address is hard coded in the source file `sysNet.c`. The BSP can be used with the default MAC as long as the target is on a private network and there is no more than one target on that network with the same default MAC address. Otherwise the designer should replace this MAC with a function to retrieve one from a non-volatile memory device on their target board.

To specify the EMAC as the boot device in the bootrom, change the *boot device* field in the bootline to **xemac**. If there is a single EMAC, set the unit number to **0**.

### Bootrom with 1 Gigabit Ethernet (GEMAC) as the Boot Device

SDK will generate a BSP that is capable of being built as a bootrom using the GEMAC as a boot device. Very little user configuration is required. The MAC address is hard coded in the source file `sysNet.c`. The BSP can be used with the default MAC as long as the target is on a private network and there is no more than one target on that network with the same default MAC address. Otherwise the designer should replace this MAC with a function to retrieve one from a non-volatile memory device on their target board.

To specify the GEMAC as the boot device in the bootrom, change the *boot device* field in the bootline to **xgemac**. If there is a single GEMAC, set the unit number to **0**.

## Bootline Examples

The following example boots from the ethernet using the Xilinx *xemac* as the boot device. The image booted is on the host file system on drive C.

```
boot device           : xemac
unit number          : 0
processor number      : 0
host name             : host
file name             : c:/WindRiver/vxworks-6.3/target/config/ml507/vxWorks
inet on ethernet (e) : 192.168.0.2
host inet (h)         : 192.168.0.1
user (u)              : xemhost
ftp password (pw)     : whatever
flags (f)             : 0x0
target name (tn)      : vxtarget
other (o)             :
```

The following example boots from a file resident on the first partition of the compact Flash device for the SystemACE. If the file booted from `/cf0/vxworks/images/vxWorks` uses the network, then the *xemac* device is initialized.

```
boot device           : sysace=1
unit number          : 0
processor number      : 0
host name             : host
file name             : /cf0/vxworks/images/vxWorks
inet on ethernet (e) : 192.168.0.2
host inet (h)         : 192.168.0.1
user (u)              : xemhost
ftp password (pw)     : whatever
flags (f)             : 0x0
target name (tn)      : vxtarget
other (o)             : xemac
```

The following example boots from an ace file resident on the first partition of the SystemACE compact flash device. The location of the ace file is set by `XILINX.SYS` located in the root directory of the compact flash device. If the ace file contains a VxWorks SW image that uses the network, then the *xemac* device is initialized for that image.

```
boot device           : sysace=1
unit number          : 0
processor number      : 0
host name             : host
file name             : cfgaddr2
inet on ethernet (e) : 192.168.0.2
host inet (h)         : 192.168.0.1
user (u)              : xemhost
ftp password (pw)     : whatever
flags (f)             : 0x0
target name (tn)      : vxtarget
other (o)             : xemac
```



## Caches

The instruction and data caches are managed by VxWorks proprietary libraries. They are enabled by modifying the following constants in `config.h` or by using the Workbench Project facility to change the constants of the same name:

- `INCLUDE_CACHE_SUPPORT`: If defined, the VxWorks cache libraries are linked into the image. If caching is not desired, then `#undef` this constant.
- `USER_I_CACHE_ENABLE`: If defined, VxWorks will enable the instruction cache at boot time. Requires `INCLUDE_CACHE_SUPPORT` be defined to have any effect.
- `USER_D_CACHE_ENABLE`: If defined, VxWorks enables the data cache at boot time. Requires `INCLUDE_CACHE_SUPPORT` be defined to have any effect.

## MMU

If the MMU is enabled, then the cache control discussed in the previous section may not have any effect. The MMU is managed by VxWorks proprietary libraries but the initial setup is defined in the BSP. To enable the MMU, the constant `INCLUDE_MMU_BASIC` should be defined in `config.h` or by using the Project Facility. The constant `USER_D_MMU_ENABLE` and `USER_I_MMU_ENABLE` control whether the instruction and/or data MMU is utilized.

VxWorks initializes the MMU based on data in the `sysPhysMemDesc` structure defined in `sysCache.c`. User-reserved memory and ED&R (when `INCLUDE_EDR_PM` is enabled) reserved memory is included in this table. Amongst other things, this table configures memory areas with the following attributes:

- Whether instruction execution is allowed
- Whether data writes are allowed
- Instruction and data cacheability attributes
- Translation offsets used to form virtual addresses.

When VxWorks initializes the MMU, it takes the definitions from `sysPhysMemDesc` and creates page table entries (PTEs) in RAM. Each PTE describes 4KB of memory area (even though the processor is capable of representing up to 16MB per PTE) Beware that specifying large areas of memory uses substantial amounts of RAM to store the PTEs. To map 4MB of contiguous memory space takes 8KB of RAM to store the PTEs.

To increase performance with the VxWorks basic MMU package for the PowerPC 405/440 processor, it might be beneficial to not enable the instruction MMU and rely on the cache control settings in the ICCR register. This strategy can dramatically reduce the number of page faults while still keeping instructions in cache. The initial setting of the ICCR is defined in the `bspname.h` header file.

Without the MMU enabled, the following rules apply to configuring memory access attributes and caching:

- There is no address translation, all effective addresses are physical.
- Cache control granularity is 128MB.
- The guarded attribute applies only to speculative instruction fetches on the PowerPC 405 processor.

## FPU

Hard floating-point unit(FPU) is supported for PowerPC 440 processor systems. To enable hard floating-point unit, select **diab** or **gnu** in generated BSP Makefile `TOOLS`. To disable hard floating-point unit, select **sfdiab** or **sfgnu** in Makefile's make variable `TOOLS`.



## Overview

One of the key embedded system development activities is the development of the BSP. The creation of a BSP can be a lengthy process that must be incurred when there is a change in the microprocessor complex which is comprised of the processor and associated peripherals. Although the management of these changes applies to any microprocessor-based project, now the changes can be accomplished more rapidly with the advent of programmable System-on-Chip (SoC) hardware.

This document describes automatic generation of a customized VxWorks 6.5 BSP for the IBM PowerPC® 405/440 microprocessor and its peripherals as defined within a Xilinx® FPGA. An automatically generated BSP enables embedded system designers to:

- Decrease the development cycles, thereby decreasing the time-to-market
- Create a customized BSP to match the hardware and the application
- Eliminate BSP design bugs (automatically created based on certified components)
- Enable application software development by eliminating the wait for BSP development

The VxWorks 6.5 BSP is generated from Software Development Kit (SDK), an IDE delivered as part of the Xilinx Embedded Development Kit (EDK) or available separately from Xilinx. SDK is used to create software applications for embedded systems within Xilinx FPGAs. The VxWorks BSP contains all the necessary support software for a system, including boot code, device drivers, and RTOS initialization. The BSP is customized based on the peripherals chosen and configured by the user for the FPGA-based embedded system.

Experienced BSP designers should readily integrate a generated BSP into their target system. Conversely, less experience users might encounter difficulties because, even though SDK can generate an operational BSP for a given set of IP hardware, there is always some additional configuration and adjustments required to produce the best performance out of the target system. It is recommended that the user have available the *Wind River VxWorks BSP Developer's Guide* and the *VxWorks Application Programmer's Guide* or consider the Wind River classes on BSP design, available at an additional cost.

## Requirements

The Wind River Workbench 2.6.1 development kit must be installed on the host computer. Because SDK generates re-locatable BSPs that are compiled and configured outside the SDK environment, the host computer need not have both the Xilinx SDK and Workbench installed.

## Microprocessor Library Definition

SDK supports a plug-in interface for 3rd party libraries and operating systems through the Microprocessor Library Definition (MLD) interface, thereby allowing 3rd party vendors to have their software available to SDK users. In addition, it provides the vendors a means for tailoring their libraries or BSPs to the FPGA-based embedded system created within Xilinx tools. Because the system can change easily, this capability is critical in properly supporting embedded systems in FPGAs.

Xilinx develops and maintains the VxWorks 6.5 MLD in its SDK releases. The MLD is used to automatically generate the VxWorks 6.5 BSP.

## Template-Based Approach

A set of VxWorks 6.5 BSP template files are released with the SDK. These template files are used during automatic generation of the BSP and appropriate modifications are made based on the makeup of the FPGA-based embedded system.

These template files could be used as a reference for building a BSP from scratch if the user chooses not to automatically generate a BSP.

## Device Drivers

A set of device driver source files are released with the SDK and reside in an installation directory. During creation of a customized BSP, device driver source code is copied from this installation directory to the BSP directory. Only the source code pertaining to the devices built into the FPGA-based embedded system are copied. This copy provides the user with a self-contained, standalone BSP directory which can be modified or relocated. If the user makes changes to the device driver source code for this BSP, then later wishes to undo the changes, the SDK tool can be used to regenerate the BSP. At that point, the device driver source files are recopied from the installation directory to the BSP.

## Generating the VxWorks 6.5 BSP

### Using SDK

SDK is available as a separately installed tool or within the EDK and is a software development environment for developing embedded software around the PowerPC® 405/440 processors or the MicroBlaze™ processor-based embedded systems. This section describes the steps needed to create a VxWorks 6.5 BSP using SDK. These steps are applicable when using Xilinx tools of release 11.1 and forward.

It is assumed that a valid hardware design has been created and exported to SDK, and SDK has been opened and pointed to the hardware design.

1. Using **File > New**, create a new Board Support Package project. In the dialog box, enter a project name, and select **vxworks6\_5** as the Board Support Package Type. Note that SDK can manage multiple projects of different BSP types.

The remaining steps pertain to the **Tools > Board Support Package Settings** dialog box, which should automatically be displayed after step 1.

Figure 1, page 3 shows the board support package settings.




Figure 1: Board Support Package Settings

2. Configure the VxWorks console device.

If a serial device such as a Uart is intended to be used as the VxWorks console, select or enter the instance name of the serial device as the STDIN/STDOUT peripheral in the Board Support Package Settings dialog box. It is important to enter the same device for both STDIN and STDOUT. Currently, only the Uart 16550/16450 and UartLite devices are supported as VxWorks console devices.

3. Integrate the device drivers.

a. **Connect to VxWorks**

There is a **connected\_periphs** dialog box available in the **Board Support Package Settings** dialog box. Peripherals have been pre-populated for user convenience. Use this dialog box to modify those peripherals to be tightly integrated with the OS, including the device that was selected as the STDIN/STDOUT peripheral. See “[Device Integration](#),” page 8 for more details on device integration.

b. **Memory Size**

This field is used to configure the BSP to match the actual hardware memory size on your board.

c. **Uart16550\_baud\_rate**

This field is used to input the baud rate for projects with the UART 16550/16450 core. It is not necessary to enter a value here for projects with the UART Lite core since the baud rate is set for a UART Lite at hardware build time.

d. **RAM\_INSTANCE**

This is a drop down menu to select the peripheral instance that is to be used as RAM in BSP. The subfields memory bank and the base address of RAM under RAM\_INSTANCE are to be configured to match the actual hardware settings.

e. **ROM\_INSTANCE**

This is a drop down menu to select the peripheral instance that is to be used as ROM in BSP. FLASH is the only ROM device supported on the Xilinx Evaluation boards. If there is no ROM in the system, the user can leave the default setting i.e. none. If there is a FLASH in the system the subfields memory bank and the base address of ROM under ROM\_INSTANCE are to be configured to match the actual hardware settings.

f. **RAM\_LOW\_ADRS\_OFFSET**

This field is used to input the address offset for the RAM base address to obtain the RAM address for vxWorks used in the BSP and is to be configured to match the hardware system settings.

g. **RAM\_HIGH\_ADRS\_OFFSET**

This field is used to input the address offset for the RAM base address to obtain the RAM address used in the BSP for boot ROM and is to be configured to match the hardware system settings.

h. **ROM\_LOW\_ADRS\_OFFSET**

This field is used to input the address offset for the ROM base address to obtain the FLASH start address used in the BSP and is to be configured to match the hardware system settings.

i. **ROM\_HIGH\_ADRS\_OFFSET**

This field is used to input the address offset for the ROM base address to obtain the FLASH end address used in the BSP and is to be configured to match the hardware system settings.

j. **ROM\_SIZE**

This field is used to configure the BSP and should match the actual hardware system settings.

k. **ROM\_TEXT\_ADRS\_OFFSET**

This field is used to input the address offset for the ROM base address to obtain the text section start address used in the BSP and is to be configured to match the hardware system settings.

l. **ROM\_WARM\_ADRS\_OFFSET**

This field is used to input the address offset for the ROM base address to obtain the warm reboot entry address used in the BSP and is to be configured to match the hardware system settings.

4. **Generate the VxWorks 6.5 BSP**

Click **OK** on the **Board Support Package Settings** dialog box to generate the BSP. The output of this invocation is shown in the SDK console window. After completion, the resulting VxWorks 6.5 BSP exists in your SDK workspace, under the project directory name you created in step 1 under the PowerPC 405/440 instance subdirectory. For example, if in the hardware design the user has named the PowerPC 405 instance, *myppc405*, the BSP resides at *<SDK workspace>/<SDK project name>/myppc405/bsp\_ppc405*.

## Backups

To prevent the inadvertent loss of changes to BSP source files, existing files in the directory location of the BSP are copied into a backup directory before being overwritten. The backup directory resides within the BSP directory and is named *backup<timestamp>*, where *<timestamp>* represents the current date and time. Because the BSP that is generated by SDK is relocatable, it is recommended to relocate the BSP from the SDK project directory to an appropriate BSP development directory as soon as the hardware platform is stable.

## The VxWorks 6.5 BSP

This section describes the VxWorks 6.5 BSP output by SDK. It is assumed that the reader is familiar with Wind River's Workbench 2.6.1 IDE.

The automatically generated BSP is integrated into the Workbench IDE. The BSP can be compiled from the command-line using the Workbench make tools, or from the Workbench Project facility (also referred to as the Workbench IDE).

After the BSP is generated, type **make vxWorks** from the command-line to compile a bootable RAM image. This assumes the Workbench environment has been previously set up, which can be done on the command-line using the *wrenv* Wind River environment utility on a Windows platform. See the Wind River Workbench Command-Line Users Guide: *Creating a Development Shell With wrenv* for more information on using the command-line utilities. If using the Workbench Project facility, you can create a project based on the newly generated BSP, then use the build environment provided through the IDE to compile the BSP.

In Workbench 2.6.1, the *diab* compiler is supported in addition to the *gnu* compiler. The VxWorks 6.5 BSP created by SDK has a Makefile that can be modified on the command-line to use the *diab* compiler instead of the *gnu* compiler. Look for the make variable named **TOOLS** and set the value to **sfdiab** instead of **sfgnu**. For PowerPC 440 processors with hard floating-point unit (FPU) systems, select **diab** or **gnu**. If using the Workbench Project facility, select the desired tool when the project is first created.

## Driver Organization

This section briefly discusses how the Xilinx drivers are compiled and linked and eventually used by Workbench makefiles to be included into the VxWorks image.

Xilinx drivers are implemented in C programming language and can be distributed among several source files unlike traditional VxWorks drivers, which consist of single C header and implementation files.

There are up to three components for Xilinx drivers:

- Driver source inclusion
- OS independent implementation
- OS dependent implementation (optional)

*Driver source inclusion* refers to how Xilinx drivers are compiled. For every driver, there is a file named *<procname>\_drv\_<dev>\_<version>.c*. Using the **#include** command includes the source file(s) (\*.c) for each driver for each given device.

This process is analogous to how the VxWorks *sysLib.c* # *include*'s source for Wind River supplied drivers. Xilinx files are not included in *sysLib.c*, as are the rest of the drivers, because of namespace conflicts and maintainability issues. If all Xilinx files were part of a single compilation unit, static functions and data are no longer private. This places restrictions on the device drivers and would negate their operating system independence.

The OS independent part of the driver is designed for use with any operating system or any processor. It provides an API that uses the functionality of the underlying hardware. The OS dependent part of the driver adapts the driver for use with VxWorks.

Such examples are SIO drivers for serial ports, or END drivers for ethernet adapters. Not all drivers require the OS dependent drivers, nor is it required to include the OS dependent portion of the driver in the VxWorks build.

## Device Driver Location

The automatically generated BSP resembles most other Workbench BSPs except for the placement of device driver code. Off-the-shelf device driver code distributed with the Workbench IDE typically resides in the `vxworks-6.5/target/src/drv` directory in the Workbench installation directory. Device driver code for a BSP that is automatically generated resides in the BSP directory itself. This minor deviation is due to the dynamic nature of FPGA-based embedded system. Since the FPGA-based embedded system can be reprogrammed with new or changed IP, the device driver configuration can change, calling for a more dynamic placement of device driver source files.

The directory tree for the automatically generated BSP is `<bsp_name>/<csp_name>_csp/xsrc`.

The top-level directory is named according to the name of the processor instance in the hardware design project. The customized BSP source files reside in this directory. There is a subdirectory within the BSP directory named according to the processor instance with `_drv_csp` as a suffix. The driver directory contains two subdirectories. The `xsrc` subdirectory contains all the device driver related source files. If building from the Workbench Project facility, the files generated during the build process reside at `$PRJ_DIR/$BUILD_SPEC`.

## Configuration

BSPs generated by SDK are configured like any other VxWorks 6.5 BSP. There is little configurability to Xilinx drivers because the IP hardware has been pre-configured in most cases. The only configuration available generally is whether the driver is included in the VxWorks build at all. The process of including/excluding drivers depends on whether the Project facility or the command-line method is being used to perform the configuration activities.

Note that simply by including a Xilinx device driver does not mean that the driver will be automatically utilized. Most drivers with VxWorks adapters have initialization code. In some cases the user may be required to add the proper driver initialization function calls to the BSP.

When using SDK to generate a BSP, the resulting BSP files may contain “TODO” comments. These comments, many of which originate from the PowerPC 405/440 BSP template provided by Wind River, provides suggestions what the user must provide to configure the BSP for the target board. The *VxWorks BSP Developer Guide* and *VxWorks Application Programmer's Guide* are very useful resources for BSP configuration.

## Command-Line Driver Inclusion/Exclusion

Within the BSP, a set of constants (one for each driver) are defined in `<procname>_drv_config.h` and follow the format:

```
#define INCLUDE_<XDRIVER>
```

This file is included near the top of `config.h`. By default all drivers are included in the build. To exclude a driver, add the following line in `config.h` after the inclusion of the `<procname>_drv_config.h` header file.

```
#undef INCLUDE_<XDRIVER>
```

This exclusion prevents the driver from being compiled and linked into the build. To re-instate the driver, remove the `#undef` line from `config.h`. Some care is required for certain drivers. For example, Ethernet might require that a DMA driver be present. Undefined the DMA driver causes the build to fail.



## Project Facility Driver Inclusion/Exclusion

The file `50<csp_name>.cdf` resides in the BSP directory and is tailored during creation of the BSP. This file integrates the Xilinx device drivers into the Workbench IDE. The Xilinx device drivers are hooked into the IDE at the `/hardware/peripherals` sub-folder of the components tab. Below this are individual device driver folders. An example of the GUI with Xilinx drivers is shown in Figure 2. To add or delete Xilinx drivers, include or exclude driver components as with any other VxWorks component.




Figure 2: Workbench 2.6.1 Project IDE - VxWorks

Note that whatever configuration has been specified in `<procname>_drv_config.h` and `config.h` are overridden by the project facility.

## Building VxWorks

The automatically generated BSPs follow the standard Workbench conventions when it comes to creating VxWorks images. Refer to Workbench documentation on how to make a VxWorks image.

### Command-Line BSP Build Extensions

The Xilinx drivers are compiled/linked with the same toolchain VxWorks with which is built. Minor additions to the Makefile were required to help Workbench find the location of driver source code files.

### Project BSP Build Extensions

The number of new files used to integrate the Xilinx device drivers into the Workbench build process can be seen in the `<bsp_name>` directory. As stated earlier, these files are automatically created by SDK. You need only be aware of that the files exist. These files are prefixed with the instance name of the processor.

## Device Integration

Devices in the FPGA-based embedded system have varying degrees of integration with the VxWorks operating system. The degree of integration is selectable by the SDK user in the Connected Peripherals dialog box of the Library/OS Parameters tab. Below is a list of currently supported devices and their level of integration.

- VxBus device driver model is supported starting from vxWorks6.5 BSP. Reference the `sysLib.c` and `hwconf.c` of the BSP to see details of this migration.
- One or two UART 16450/16550/Lite devices can be integrated into the VxWorks Serial I/O (SIO) interface. This makes a UART available for file I/O and `printf/stdio`. Only one UART device can be selected as the console, where standard I/O (`stdin`, `stdout`, and `stderr`) is directed. A UART device, when integrated into the SIO interface, must be capable of generating an interrupt. If you want more than two UART device in your BSP, the `ppc405_0.h/ppc440_0.h` file must be manually modified to change the number of SIO devices to match.
- Ethernet Lite 10/100 and 10/100/1000 Local Link Tri-speed Ethernet MAC devices can be integrated into the VxWorks Enhanced Network Driver (END) interface. This makes the device available to the VxWorks network stack and thus socket-level applications. An Ethernet device, when integrated into the END interface, must be capable of generating interrupts. You might need to modify the default bootline values in the `config.h` for the Ethernet device to be used as the boot device.
- An Interrupt controller can be connected to the VxWorks `intLib` exception handling and the PowerPC 405/440 external non-critical interrupt pin. The generated BSP does not currently handle interrupt controller integration for the critical interrupt pin of the PowerPC 405/440 processor, nor does it support direct connection of a single interrupting device (other than the `intc`) to the processor. However, the user is always able to add manually this integration in the `sysInterrupt.c` file of the BSP.
- A System ACE™ controller can be connected to VxWorks as a block device, allowing the user to attach a filesystem to the CompactFlash device connected to the System ACE controller. You must manually call the BSP functions to initialize the System ACE/CompactFlash as a block device and attach it to the DOS operating system. The function currently available to the user is `sysSystemAceMount()`. A system ACE controller, when integrated into the block device interface, must be capable of generating an interrupt. Reference the `xsysaceblkadapter.c` file in the BSP for more details. The BSP mounts the CF as a DOS FAT disk partition using the Wind River `DosFs2.0` add-on.

To get the required VxWorks libraries into the image, the following packages must be defined in `config.h` or by the Project Facility:

- `INCLUDE_DOSFS_MAIN`
- `INCLUDE_DOSFS_FAT`
- `INCLUDE_DISK_CACHE`
- `INCLUDE_DISK_PART`
- `INCLUDE_DOSFS_DIR_FIXED`
- `INCLUDE_DOSFS_DIR_VFAT`
- `INCLUDE_XBD_BLK_DEV`
- `INCLUDE_XBD_PART_LIB`



Programmatically, an application can mount the DOS file system using the following API calls:

```
FILE *fp;

if (sysSystemAceMount(0, "/cf0", 1) != OK)
{
    /* handle error */
}

fp = fopen("/cf0/myfile.dat", "r");
```

- A PCI bridge can be initialized and made available to the standard VxWorks PCI driver and configuration functions. The user is required to edit the `config.h` and `hwconf.c` BSP files to tailor the PCI memory addresses and configuration for their target system.

**Note:** PCI interrupts are not automatically integrated into the BSP.

- A USB device controller can be integrated into the USB peripheral controller interface of the VxWorks BSP components. To test the USB peripheral controller using the existing Mass Storage emulator component of VxWorks, the following changes are to be done in the VxWorks source file `usbTargMsLib.c` and in the BSP `config.h` file. These changes are to be done before the VxWorks project is created.
  - In the `usbTargMsLib.c` file, modify the `MS_BULK_OUT_ENDPOINT_NUM` constant value to **2**. This file is located at the directory `<WindRiver-Installed-Directory>/Vx-Works6.5/target/src/drv/usb/target/`.
  - After modification, the VxWorks source is compiled at this directory.

The compiler command for a PowerPC 440 processor system is:

**make CPU=PPC32**

For a PowerPC 405 processor system it is:

**make CPU=PPC405**

- USB MassStorage emulator uses the local memory for the storage area. You must provide a minimum of 4MB space (modify the `LOCAL_MEM_SIZE` constant value in the `config.h` file as `0x400000`) in the RAM. The MassStorage emulator code emulates a default storage area of 32k.
- All other devices and associated device drivers are not tightly integrated into a VxWorks interface. Instead, they are loosely integrated and access to these devices is available by directly accessing the associated device drivers from the user's application.
- User cores and associated device drivers, if included in the EDK project, are supported through the BSP generation flow. The user core device drivers are copied into the BSP in the same way the Xilinx device drivers are copied. This assumes the directory structure of the user core device driver matches the structure of the Xilinx device drivers. The `/build` sub-directories of the device driver must exist and be formatted in the same way as the Xilinx device drivers. This includes the CDF snippet and xtag files in the `/drivers/core_vxworks_v2_00_a/build` sub-directory. User device drivers are not automatically integrated into any OS interface (for example, SIO), but they are available for direct access by an application.

## Exceptions

The following list summarizes the differences between SDK generated BSPs and traditional BSPs.

- An extra directory structure is added to the root BSP directory to contain the device driver source code files.
- To keep the BSP buildable while maintaining compatibility with the Workbench Project facility, a set of files named `<procname>_drv_<driver>_<version>.c` populate the BSP directory that `#include` the source code from the driver subdirectory of the BSP.
- The BSP Makefile is modified so that the compiler can find the driver source code. The Makefile contains more information about this deviation and its implications.
- SystemACE™ tool usage as a boot device might require changes to VxWorks source code files found in the Workbench distribution directory.

## Limitations

The automatically generated BSP should be considered a good starting point, but should not be expected to meet all the needs without further configuration. Due to the potential complexities of a BSP, the variety of features that can be included in a BSP, and the support necessary for board devices external to the FPGA, the automatically generated BSP require enhancements. However, the generated BSP is compilable and contains the necessary device drivers represented in the FPGA-based embedded system. Some of the commonly-used devices are also integrated with the operating system. Specific limitations are:

- An interrupt controller connected to the PowerPC 405/440 critical interrupt pin is not automatically integrated into the VxWorks interrupt scheme. Only the external interrupt is currently supported.
- Bus error detection from bus bridges or arbiters is not supported.
- The command-line VxWorks 6.5 BSP defaults to use the GNU compiler. You must manually change the Makefile to use the DIAB compiler, or specify the DIAB compiler when creating a Workbench project based on the BSP.
- The ROM addresses in the `config.h` and Makefiles of BSP are updated based on the peripheral instance selected in the **ROM\_INSTANCE** drop down menu box of the Board Support Package settings in SDK. You must select the peripheral instance as per the hardware settings.
- PowerPC 405 caches are disabled by default. You must enable caches manually through the `config.h` file or the Workbench project menu.
- PowerPC 440 caches are enabled by default. You must disable caches manually through the `config.h` file or the Workbench project menu.
- When SystemACE is setup to download VxWorks images into RAM using JTAG, all boots are cold (no warm boots). This is because the System ACE controller resets the processor whenever it performs an ace file download. An effect of this could cause exception messages generated by VxWorks to not be printed on the console when the system is rebooted due to an exception in an ISR or a kernel panic.

**Note:** No compressed images can be used with SystemACE. This applies to standard compressed images created with Workbench such as `bootrom`. Compressed images cannot be placed on SystemACE as an ace file. SystemACE cannot decompress data as it writes it to RAM. Starting such an image leads to a system crash.

- On the PowerPC 405 or 440 processors, the reset vector is at physical address `0xFFFFFFF0`. There is a short time window where the processor attempts to fetch and execute the instruction at this address while SystemACE processes the ace file. The processor must have a command to execute during this time, even if it is a spin loop:

```
FFFFFFF0    b .
```

If block RAM occupies this address range, then the designer who creates the bitstream should place instructions here with the ELF-to-BRAM utility found in the Xilinx Integrated Software Environment (ISE®) tools.

## Booting VxWorks

### VxWorks Bootup Sequence

There are many variations of VxWorks images with some based in RAM, some in ROM. Depending on board design, not all these images are supported. The following list describes the image types:

- **ROM compressed images** - These images begin execution in ROM and decompress the BSP image into RAM, then transfer control to the decompressed image in RAM. This image type is not compatible with SystemACE because SystemACE is not aware of the the image compression and places it in RAM at an address that is overwritten by the decompression algorithm when it begins. It might be possible to use this type of image if modifications are made to the standard Workbench makefiles to handle this scenario.
- **RAM based images**—These images are loaded into RAM by a bootloader, SystemACE, or an emulator. These images are fully supported.
- **ROM based images**—These images begin execution in ROM, copy themselves to RAM then transfer execution to RAM. In designs with SystemACE as the bootloader, the image is automatically copied to RAM. The hand-coded BSP examples short-circuit the VxWorks copy operation so that the copy does not occur again after control is transferred to RAM by SystemACE (see `romInit.s`).
- **ROM resident images**—These images begin execution in ROM, copy the data section to RAM, and execution remains in ROM. In systems with only a SystemACE, this image is not supported. Theoretically, block RAM could be used as a ROM; however, the FPGAs being used in the evaluation boards might not have the capacity to store a VxWorks image which could range in size from 200KB to over 700KB.

### VxWorks Boot Sequence

This standard image is designed to be downloaded to the target RAM space by some device. After download, the processor is setup to begin execution at function `_sysInit` at address `RAM_LOW_ADRS`. (this constant is defined in the `config.h` and the Makefile). Most of the time, the device performing the download does this automatically as it can extract the entry point from the image.

1. `_sysInit` : This assembly language function running out of RAM performs low level initialization. When completed, this function sets up the initial stack and invoke the first "C" function `usrInit()`. `_sysInit` is located in the `<bspname>/sysALib.s` source file.
2. `usrInit()` : This "C" function running out of RAM sets up the "C" runtime environment and performs pre-kernel initialization. It invokes `sysHwInit()` (implemented in `sysLib.c`) to place the hardware in a quiescent state. When completed, this function calls `kernelInit()` to bring up the VxWorks kernel. This function then invokes `usrRoot()` as the first task.
3. `usrRoot()` : Performs post-kernel initialization. Hooks up the system clock, initializes the TCP/IP stack, and so forth. It invokes `sysHwInit2()` (implemented in `sysLib.c`) to attach and enable hardware interrupts. When complete, `usrRoot()` invokes user application startup code `usrAppInit()` if so configured in the BSP.

Both `usrInit()` and `usrRoot()` are implemented by Wind River. The source code files in which the functions exist differ depending on whether the command line or the Workbench Project facility is being used to compile the system.

- Under the command line interface, the functions are implemented at `$WIND_BASE/target/config/all/usrConfig.c`.
- Under the project facility, they are maintained in the user's project directory.

## bootrom\_uncmp Boot Sequence

This standard image is ROM-based but is linked to execute out of RAM addresses. While executing from ROM, this image uses relative addressing tricks to call functions for processing tasks before jumping to RAM.

1. `Power on`: Processor vectors to `0xFFFFFFFFC` where a jump instruction should be located that transfers control to the bootrom at address `_romInit`.
2. `_romInit`: This assembly language function running out of ROM notes that this is a cold boot then jumps to start. Both `_romInit` and `start` are located in source code file `<bspname>/romInit.s`.
3. `start`: This assembly language function running out of ROM sets up the processor, invalidates the caches, and prepares the system to operate out of RAM. The last operation is to invoke "C" function `romStart()` which is implemented by Wind River and is located in source code file `$WIND_BASE/target/config/all/bootInit.c`.
4. `romStart()`: This "C" function running out of ROM copies VxWorks to its RAM start address located at `RAM_HIGH_ADRS` (this constant is defined in `config.h` and `Makefile`). After copying VxWorks, control is transferred to function `usrInit()` in RAM.
5. Follows steps 2 and 3 of the vxWorks bootup sequence.

## Bootroms

The bootrom is a scaled-down VxWorks image that operates in much the same way as a PC BIOS. Its primary job is to locate and boot a full VxWorks image. The full VxWorks image might reside on disk, in flash memory, or on some host over the Ethernet. The bootrom must be compiled in such a way that it has the ability to retrieve the image:

- If the image is retrieved from an Ethernet network, then the bootrom must have the TCP/IP stack compiled in
- If the image is on disk, then the bootrom must have disk access support compiled in

The bootroms do little else than retrieve and start the full image and maintain a bootline. The bootline is a text string that set certain user characteristics such as the IP address of the target if using Ethernet, and the file path to the VxWorks image to boot.

Bootroms are not a requirement. They are typically used in a development environment then replaced with a production VxWorks image.

## Creating Bootroms

At a command shell in the BSP directory, issue the following command to create an uncompressed bootrom image:

```
make bootrom_uncmp
```

or

```
make bootrom
```

to create a compressed image suitable for placing in a flash memory array.

## Bootrom Display

Upon cycling power, if the bootroms are working correctly, output similar to the following should be seen on the console serial port:

```
VxWorks System Boot

Copyright 1984-2007 Wind River Systems, Inc.

CPU: ppc405_0 VirtexII Pro PPC405
Version: VxWorks 6.5
BSP version: 2.0/0.
Creation date: Oct 11, 2007, 16:40:32

Press any key to stop auto-boot...
3

[VxWorks Boot]:
```

Typing the **help** at this prompt lists the available commands.

## Bootline

The bootline is a text string that defines user serviceable characteristics such as the IP address of the target board and how to find a vxWorks image to boot. The bootline is maintained at runtime by the bootrom and is typically kept in some non-volatile (NVRAM) storage area of the system such as an EEPROM or flash memory. If there is no NVRAM, or an error occurs reading it, then the bootline is hard-coded with `DEFAULT_BOOT_LINE` defined in the `config.h` source file of the BSP. In new systems where NVRAM has not been initialized, the bootline might be undefined data.

The bootline can be changed if the auto-boot countdown sequence is interrupted by entering a character on the console serial port. The "**c**" command can then be used to interactively edit the bootline. Enter "**p**" to view the bootline. On a non-bootrom image, the bootline can be changed by entering the `bootChange` command at a host or target shell prompt.

The bootline fields are defined below:

- boot device : Device from which to boot. This could be Ethernet, or a local disk.  
**Note:** When changing the bootline, the unit number might be shown appended to this field ("lItemac0") when prompting for the new boot device. This number can be ignored.
- processor number : Always 0 with single processor systems.
- host name : Name as needed.
- file name : The VxWorks image to boot.
- inet on ethernet (e) : The IP internet address of the target. If there is no network interface, then this field can be left blank.
- host inet (h) : The IP internet address of the host. If there is no network interface, then this field can be left blank.
- user (u) : User name for host file system access. Your ftp server must be setup to allow this user access to the host file system.
- ftp password (pw) : Password for host file system access. Your ftp server must be setup to allow this user access to the host file system.
- flags (f) : For a list of options, enter **help** at the [VxWorks Boot]: prompt.
- target name (tn) : Name as needed. Set per network requirements.

- other (o) : This field is useful when you have a non-Ethernet device as the boot device. When this is the case, VxWorks will not start the network when it boots. Specifying an Ethernet device here enables that device at boot time with the network parameters specified in the other bootline fields.
- inet on backplane (b) : Typically left blank if the target system is not on a VME or PCI backplane.
- gateway inet (g) : Enter an IP address here if you have to go through a gateway to reach the host computer. Otherwise leave blank.
- startup script (s): Path to a file on the host computer containing shell commands to execute once bootup is complete. Leave blank if not using a script. Examples:
  - SystemACE resident script: /cf0/vxworks/scripts/myscript.txt
  - Host resident script: c:/temp/myscript.txt

### Bootrom with Local Link Tri-mode Ethernet (LLTEMAC) as the Boot Device

SDK generates a BSP that is capable of being built as a bootrom using the LLTEMAC as a boot device. Very little user configuration is required. The MAC address is hard coded in the `hwconf.c` file. The BSP can be used with the default MAC as long as the target is on a private network and there is no more than one target on that network with the same default MAC address. Otherwise, replace this MAC with a function to retrieve one from a non-volatile memory device on their target board.

To specify the LLTEMAC as the boot device in the bootrom, change the **boot device** field in the bootline to **litemac**. If there is a single LLTEMAC, set the unit number to 0.

### Bootline Examples

The following example boots from the ethernet using the Xilinx *litemac* as the boot device. The image booted is on the host file system on drive C.

```
boot device           : litemac
unit number          : 0
processor number      : 0
host name             : host
file name             : c:/WindRiver/vxworks-6.5/target/config/ml507/vxWorks
inet on ethernet (e) : 192.168.0.2
host inet (h)         : 192.168.0.1
user (u)              : xemhost
ftp password (pw)     : whatever
flags (f)             : 0x0
target name (tn)      : vxtarget
other (o)             :
```

### Caches

The instruction and data caches are managed by VxWorks proprietary libraries. They are enabled by modifying the following constants in `config.h` or by using the Workbench Project facility to change the constants of the same name:

- `INCLUDE_CACHE_SUPPORT`: If defined, the VxWorks cache libraries are linked into the image. If caching is not desired, then `#undef` this constant.
- `USER_I_CACHE_ENABLE`: If defined, VxWorks enables the instruction cache at boot time. Requires `INCLUDE_CACHE_SUPPORT` be defined to have any effect.
- `USER_D_CACHE_ENABLE`: If defined, VxWorks enables the data cache at boot time. Requires `INCLUDE_CACHE_SUPPORT` be defined to have any effect.

## MMU

If the MMU is enabled, the cache control might not have any effect. The MMU is managed by VxWorks proprietary libraries but the initial setup is defined in the BSP.

To enable the MMU, the constant `INCLUDE_MMU_BASIC` must be defined in the `config.h` or by using the Project Facility. The constant `USER_D_MMU_ENABLE` and `USER_I_MMU_ENABLE` control whether the instruction and or data MMU is utilized.

VxWorks initializes the MMU based on data in the `sysPhysMemDesc` structure defined in `sysCache.c`. User reserved memory and ED&R (when `INCLUDE_EDR_PM` is enabled) reserved memory is included in this table. Amongst other things, this table configures memory areas with the following attributes:

- Whether instruction execution is allowed
- Whether data writes are allowed
- Instruction and data cacheability attributes
- Translation offsets used to form virtual addresses

When VxWorks initializes the MMU, it takes the definitions from `sysPhysMemDesc` and creates page table entries (PTEs) in RAM. Each PTE describes 4KB of memory area (even though the processor is capable of representing up to 16MB per PTE) Beware that specifying large areas of memory uses substantial amounts of RAM to store the PTEs. To map 4MB of contiguous memory space takes 8KB of RAM to store the PTEs.

To increase performance with the VxWorks basic MMU package for the PowerPC 405 or 440 processors, it might be beneficial to not enable the instruction MMU and rely on the cache control settings in the ICCR register. This strategy can dramatically reduce the number of page faults while still keeping instructions in cache. The initial setting of the ICCR is defined in the `<bspname>.h` header file.

For PowerPC 440 processors, caches and MMU are enabled by default.

Without the MMU enabled, the following rules apply to configuring memory access attributes and caching:

- There is no address translation, all effective addresses are physical.
- Cache control granularity is 128MB.
- The guarded attribute applies only to speculative instruction fetches on the PowerPC 405 processors.

## FPU

Hard floating-point unit (FPU) is supported for PowerPC 440 processor systems. To enable hard floating-point unit, select **diab** or **gnu** in generated BSP Makefile `TOOLS`. To disable hard floating-point unit, select **sfdiab** or **sfgnu** in the Makefile make variable `TOOLS`.





## Overview

One of the key embedded system development activities is the development of the BSP. The creation of a BSP can be a lengthy and tedious process that must be incurred when there is a change in the microprocessor complex which is comprised of the processor and associated peripherals. Although the management of these changes applies to any microprocessor-based project, now the changes can be accomplished more rapidly with the advent of programmable System-on-Chip (SoC) hardware.

This document describes automatic generation of a customized VxWorks 6.7 BSP for the IBM PowerPC<sup>®</sup> 440 microprocessor and its peripherals as defined within a Xilinx FPGA.

**Note:** VxWorks 6.7 BSPs do not support PowerPC 405 processors.

An automatically generated BSP enables embedded system designers to:

- Decrease the development cycles, thereby decreasing the time-to-market
- Create a customized BSP to match the hardware and the application
- Eliminate BSP design bugs (automatically created based on certified components)
- Enable application software development by eliminating the wait for BSP development

The VxWorks 6.7 BSP is generated from the Software Development Kit (SDK), an IDE delivered as part of the Xilinx Embedded Development Kit (EDK) or available separately from Xilinx. SDK is used to create software applications for embedded systems within Xilinx FPGAs. The VxWorks BSP contains all the necessary support software for a system, including boot code, device drivers, and RTOS initialization. The BSP is customized based on the peripherals chosen and configured by the user for the FPGA-based embedded system.

Experienced BSP designers should readily integrate a generated BSP into their target system. Conversely, less experience users may encounter difficulties because even though SDK can generate an operational BSP for a given set of IP hardware, there will always be some additional configuration and adjustments required to produce the best performance out of the target system. It is recommended that the user have available the *Wind River VxWorks BSP Developer's Guide* and the *VxWorks Application Programmer's Guide* or consider the Wind River classes on BSP design, available at an additional cost.

## Requirements

The Wind River Workbench 3.1 development kit must be installed on the host computer. Because SDK generates re-locatable BSPs that are compiled and configured outside the SDK environment, the host computer need not have both the Xilinx SDK and Workbench installed.

## Microprocessor Library Definition

SDK supports a plug-in interface for 3rd party libraries and operating systems through the Microprocessor Library Definition (MLD) interface, thereby allowing 3rd party vendors to have their software available to SDK users. In addition, it provides the vendors a means for tailoring their libraries or BSPs to the FPGA-based embedded system created within Xilinx tools. Because the system can change easily, this capability is critical in properly supporting embedded systems in FPGAs.

Xilinx develops and maintains the VxWorks 6.7 MLD in its SDK releases. The MLD is used to automatically generate the VxWorks 6.7 BSP.

## Template-Based Approach

A set of VxWorks 6.7 BSP template files are released with the SDK. These template files are used during automatic generation of the BSP and appropriate modifications are made based on the makeup of the FPGA-based embedded system.

These template files could be used as a reference for building a BSP from scratch if the user chooses not to automatically generate a BSP.

## Device Drivers

A set of device driver source files are released with the SDK and reside in an installation directory. During creation of a customized BSP, device driver source code is copied from this installation directory to the BSP directory. Only the source code pertaining to the devices built into the FPGA-based embedded system are copied. This copy provides the user with a self-contained, standalone BSP directory which can be modified or relocated. If the user makes changes to the device driver source code for this BSP, then later wishes to undo the changes, the SDK tool can be used to regenerate the BSP. At that point, the device driver source files are recopied from the installation directory to the BSP.

## Generating the VxWorks 6.7 BSP

### Using SDK

SDK is available as a separately installed tool or within the EDK and is a software development environment for developing embedded software around Xilinx PowerPC 405/440 or MicroBlaze™ processor-based embedded systems. This section describes the steps needed to create a VxWorks 6.7 BSP using SDK. These steps are applicable when using The Xilinx 11.1 tools or later.

It is assumed that a valid hardware design has been created and exported to SDK, and SDK has been opened and pointed to the hardware design.

1. Using **File > New**, create a new Board Support Package project. In the dialog box, enter a project name, and select **vxworks6\_7** as the Board Support Package Type. Note that SDK can manage multiple projects of different BSP types.

The remaining steps pertain to the **Tools > Board Support Package Settings** dialog box, which should automatically be displayed after this step.

[Figure 1, page 3](#) shows the board support settings screen.




Figure 1: Board Support Package Settings

2. Configure the VxWorks console device.

If a serial device such as a Uart is intended to be used as the VxWorks console, select or enter the instance name of the serial device as the STDIN/STDOUT peripheral in the Board Support Package Settings dialog box. It is important to enter the same device for both STDIN and STDOUT. Currently, only the Uart 16550/16450 and UartLite devices are supported as VxWorks console devices.

3. Integrate the device drivers.

a. **Connect to VxWorks**

The **connected\_periphs** dialog box is available in the **Board Support Package Settings** dialog box. Peripherals have been pre-populated for user convenience. Use this dialog box to modify those peripherals to be tightly integrated with the OS, including the device that was selected as the STDIN/STDOUT peripheral. See [“Device Integration,” page 8](#) for more details on tight integration of devices.

b. **Memory Size**

This field is used to configure the BSP to match the actual hardware memory size on your board.

c. **Uart16550\_baud\_rate**

This field is used to input the baud rate for projects with the UART 16550/16450 core. It is not necessary to enter a value here for projects with the UART Lite core since the baud rate is set for a UART Lite at hardware build time.

d. **RAM\_INSTANCE**

This is a drop-down menu to select the peripheral instance that is to be used as RAM in BSP. The subfields memory bank and the base address of RAM under **RAM\_INSTANCE** are to be configured to match the actual hardware settings.

e. **ROM\_INSTANCE**

This is a drop-down menu to select the peripheral instance that is to be used as ROM in BSP. FLASH is the only ROM device supported on the Xilinx Evaluation boards. If there is no ROM in the system, the user can leave the default setting i.e. none. If there is a FLASH in the system the subfields memory bank and the base address of ROM under **ROM\_INSTANCE** are to be configured to match the actual hardware settings.

f. **RAM\_LOW\_ADRS\_OFFSET**

This field is used to input the address offset for the RAM base address to obtain the RAM address for vxWorks used in the BSP and is to be configured to match the hardware system settings.

g. **RAM\_HIGH\_ADRS\_OFFSET**

This field is used to input the address offset for the RAM base address to obtain the RAM address used in the BSP for boot ROM and is to be configured to match the hardware system settings.

h. **ROM\_LOW\_ADRS\_OFFSET**

This field is used to input the address offset for the ROM base address to obtain the FLASH start address used in the BSP and is to be configured to match the hardware system settings.

i. **ROM\_HIGH\_ADRS\_OFFSET**

This field is used to input the address offset for the ROM base address to obtain the FLASH end address used in the BSP and is to be configured to match the hardware system settings.

j. **ROM\_SIZE**

This field is used to configure the BSP and should match the actual hardware system settings.

k. **ROM\_TEXT\_ADRS\_OFFSET**

This field is used to input the address offset for the ROM base address to obtain the text section start address used in the BSP and is to be configured to match the hardware system settings.

l. **ROM\_WARM\_ADRS\_OFFSET**

This field is used to input the address offset for the ROM base address to obtain the warm reboot entry address used in the BSP and is to be configured to match the hardware system settings.

4. **Generate the VxWorks 6.7 BSP**

Click **OK** on the **Board Support Package Settings** dialog box to generate the BSP. The output of this invocation is shown in the SDK console window. After completion, the resulting VxWorks 6.7 BSP exists in your SDK workspace, under the project directory name you created in step 1, under the PowerPC 440 instance subdirectory. For example, if in the hardware design, the PowerPC 440 instance is name, `myppc440`, the BSP resides at `SDK workspace/SDK project name/myppc440/bsp_ppc440`.

## Backups

To prevent the inadvertent loss of changes made by the user to BSP source files, existing files in the directory location of the BSP will be copied into a backup directory before being overwritten. The backup directory resides within the BSP directory and is named *backuptimestamp*, where *timestamp* represents the current date and time. Because the BSP that is generated by SDK is re-locatable, it is recommended to relocate the BSP from the SDK project directory to an appropriate BSP development directory as soon as the hardware platform is stable.

## The VxWorks BSP

This section describes the VxWorks 6.7 BSP output by SDK. It is assumed that the reader is familiar with Wind River's Workbench 3.1 IDE.

The automatically generated BSP is integrated into the Workbench IDE. The BSP can be compiled from the command-line using the Workbench make tools, or from the Workbench Project facility (also referred to as the Workbench IDE). After the BSP is generated, type

```
make vxWorks
```

from the command-line to compile a bootable RAM image. This assumes the Workbench environment has been previously set up, which can be done on the command-line using the *wrenv* Wind River environment utility on a Windows platform. See the Wind River Workbench Command-Line Users Guide: *Creating a Development Shell With wrenv* for more information on using the command-line utilities. If using the Workbench Project facility, create a project based on the newly-generated BSP, then use the build environment provided through the IDE to compile the BSP.

In Workbench 3.1, the *diab* compiler is supported in addition to the *gnu* compiler. The VxWorks 6.7 BSP created by SDK has a Makefile that can be modified on the command-line to use the *diab* compiler instead of the *gnu* compiler. Look for the make variable named `TOOLS` and set the value to `sfdiab` instead of `sfgnu`. For PowerPC 440 processors with hard floating-point unit(FPU) systems, select **diab** or **gnu**. If using the Workbench Project facility, the user can select the desired tool when the project is first created.

## Driver Organization

This section briefly discusses how the Xilinx drivers are compiled and linked and eventually used by Workbench makefiles to be included into the VxWorks image.

Xilinx drivers are implemented in C programming language and can be distributed among several source files unlike traditional VxWorks drivers, which consist of single C header and implementation files.

There are up to three components for Xilinx drivers:

- Driver source inclusion
- OS independent implementation
- OS dependent implementation (optional)

*Driver source inclusion* refers to how Xilinx drivers are compiled. For every driver, there is a file named *procname\_drv\_dev\_version.c*. Using the **#include** command includes the source file(s) (\*.c) for each driver for each given device.

This process is analogous to how the VxWorks *sysLib.c* # include source for Wind River supplied drivers. Xilinx files are not included in *sysLib.c*, as are the rest of the drivers, because of namespace conflicts and maintainability issues. If all Xilinx files were part of a single compilation unit, static functions and data are no longer private. This places restrictions on the device drivers and would negate their operating system independence.

The OS independent part of the driver is designed for use with any operating system or any processor. It provides an API that uses the functionality of the underlying hardware.



The OS dependent part of the driver adapts the driver for use with VxWorks. Such examples are SIO drivers for serial ports, or IPNET drivers for ethernet adapters. Not all drivers require the OS dependent drivers, nor is it required to include the OS dependent portion of the driver in the VxWorks build.

### Device Driver Location

The automatically generated BSP resembles most other Workbench BSPs except for the placement of device driver code. Off-the-shelf device driver code distributed with the Workbench IDE typically resides in the `vxworks-6.7/target/src/drv` directory in the Workbench installation directory. Device driver code for a BSP that is automatically generated resides in the BSP directory itself. This minor deviation is due to the dynamic nature of FPGA-based embedded system. Since the FPGA-based embedded system can be reprogrammed with new or changed IP, the device driver configuration can change, calling for a more dynamic placement of device driver source files.

The directory tree for the automatically generated BSP is `bsp_name/csp_name_csp/xsrc`.

The top-level directory is named according to the name of the processor instance in the hardware design project. The customized BSP source files reside in this directory. There is a subdirectory within the BSP directory named according to the processor instance with a suffix of `_drv_csp`. The `/driver` directory contains two subdirectories. The `/xsrc` subdirectory contains all the device driver related source files. If building from the Workbench Project facility, the files generated during the build process reside at `$PRJ_DIR/$BUILD_SPEC`.

### Configuration

BSPs generated by SDK are configured like any other VxWorks 6.7 BSP. There is little configurability to Xilinx drivers because the IP hardware has been pre-configured in most cases. The only configuration available generally is whether the driver is included in the VxWorks build at all. The process of including/excluding drivers depends on whether the Project facility or the command-line method is being used to perform the configuration activities.

Including a Xilinx device driver does not mean that the driver is automatically used. Most drivers with VxWorks adapters have initialization code. In some cases, you might need to add the proper driver initialization function calls to the BSP.

When using SDK to generate a BSP, the resulting BSP files might contain `TODO` comments. These comments, many of which originate from the PowerPC 440 BSP template provided by Wind River, provide suggestions about what you must provide to configure the BSP for the target board. The *VxWorks BSP Developer Guide* and *VxWorks Application Programmer's Guide* are very useful resources for BSP configuration.

### Command-Line Driver Inclusion/Exclusion

Within the BSP, a set of constants (one for each driver) are defined in `procname_drv_config.h` and follow the format:

```
#define INCLUDE_XDRIVER
```

This file is included near the top of `config.h`. By default all drivers are included in the build. To exclude a driver, add the following line in `config.h` after the inclusion of the `procname_drv_config.h` header file.

```
#undef INCLUDE_XDRIVER
```

This exclusion will prevent the driver from being compiled and linked into the build. To re-instate the driver, remove the `#undef` line from `config.h`. Some care is required for certain drivers. For example, Ethernet may require that a DMA driver be present. Undefined the DMA driver will cause the build to fail.

## Project Facility Driver Inclusion/Exclusion

The file `50csp_name.cdf` resides in the BSP directory and is tailored during creation of the BSP. This file integrates the Xilinx device drivers into the Workbench IDE. The Xilinx device drivers are hooked into the IDE at the `hardware/peripherals` sub-folder of the components tab. Below this are individual device driver folders.

An example of the GUI with Xilinx drivers is shown in Figure 2. To add or delete Xilinx drivers, include or exclude driver components as with any other VxWorks component.




Figure 2: Workbench 3.1 Project IDE - VxWorks

**Note:** The configuration specified in `procname_drv_config.h` and `config.h` is overridden by the project facility.

## Building VxWorks

The automatically-generated BSPs follow the standard Workbench conventions when it comes to creating VxWorks images. Refer to Workbench documentation on how to make a VxWorks image.

### Command-Line BSP Build Extensions

The Xilinx drivers are compiled/linked with the same toolchain VxWorks is built with. Minor additions to the Makefile were required to help Workbench find the location of driver source code files.

## Project BSP Build Extensions

The number of new files used to integrate the Xilinx device drivers into the Workbench build process can be seen in the `<bsp_name>` directory. These files are automatically created by SDK. The user need only be aware of that the files exist. These files are prefixed with the instance name of the processor.

## Device Integration

Devices in the FPGA-based embedded system have varying degrees of integration with the VxWorks operating system. The degree of integration is selectable by the SDK user in the Connected Peripherals dialog box of the Library/OS Parameters tab. Below is a list of currently supported devices and their level of integration.

- VxBus device driver model is supported starting from VxWorks6.5 BSP. Reference the `sysLib.c` and `hwconf.c` of the BSP to see details of this migration.
- One or two UART 16450/16550/Lite devices can be integrated into the VxWorks Serial I/O (SIO) interface. This makes a UART available for file I/O and printf/stdio. Only one UART device can be selected as the console, where standard I/O (`stdin`, `stdout`, and `stderr`) is directed. A UART device, when integrated into the SIO interface, must be capable of generating an interrupt. If the user wants more than two UART device in their BSP, the `ppc440_0.h` file must be manually modified to change the number of SIO devices to match.
- Ethernet Lite 10/100 and 10/100/1000 Local Link Tri-speed Ethernet MAC devices can be integrated into the VxWorks IPNET interface. This makes the device available to the VxWorks network stack and thus socket-level applications. An Ethernet device, when integrated into the IPNET interface, must be capable of generating interrupts. You might need to modify the default bootline values in `config.h` for the Ethernet device to be used as the boot device.
- An Interrupt controller can be connected to the VxWorks intLib exception handling and the PowerPC 440 external non-critical interrupt pin. The generated BSP does not currently handle interrupt controller integration for the critical interrupt pin of the PowerPC 440, nor does it support direct connection of a single interrupting device (other than the intc) to the processor. However, the user is always able to add manually this integration in the `sysInterrupt.c` file of the BSP.
- A System ACE™ controller can be connected to VxWorks as a block device, allowing the user to attach a filesystem to the CompactFlash device connected to the System ACE controller. The user must call manually the BSP functions to initialize the System ACE/CompactFlash as a block device and attach it to the DOS operating system. The function currently available to the user is `sysSystemAceMount()`. A system ACE controller, when integrated into the block device interface, must be capable of generating an interrupt. Reference the file `xsysaceblkadapter.c` in the BSP for more details. The BSP will mount the CF as a DOS FAT disk partition using the Wind River DosFs2.0 add-on. To get the required VxWorks libraries into the image, the following packages must be defined in `config.h` or by the Project Facility:

```
- INCLUDE_DOSFS_MAIN
- INCLUDE_DOSFS_FAT
- INCLUDE_DISK_CACHE
- INCLUDE_DISK_PART
- INCLUDE_DOSFS_DIR_FIXED
- INCLUDE_DOSFS_DIR_VFAT
- INCLUDE_XBD_BLK_DEV
- INCLUDE_XBD_PART_LIB
```



Programmatically, an application can mount the DOS file system using the following API calls:

```
FILE *fp;

if (sysSystemAceMount(0, "/cf0", 1) != OK)
{
    /* handle error */
}
fp = fopen("/cf0/myfile.dat", "r");
```

- A PCI bridge can be initialized and made available to the standard VxWorks PCI driver and configuration functions. The user is required to edit the `config.h` and `hwconf.c` BSP files to tailor the PCI memory addresses and configuration for their target system. Note that PCI interrupts are not automatically integrated into the BSP.
- A USB device controller can be integrated into the USB peripheral controller interface of the VxWorks BSP components. To test the USB peripheral controller using the existing Mass Storage emulator component of VxWorks, the following changes are to be done in the VxWorks source file `usbTargMsLib.c` and in the BSP file `config.h`. These changes are to be done before the VxWorks project is created.
  - Modify the `MS_BULK_OUT_ENDPOINT_NUM` constant value as **2** in `usbTargMsLib.c` file. This file is located at the directory *WindRiver-Installed-Directory/Vx-Works6.7/target/src/drv/usb/target/*.
  - After the modification, the VxWorks source is to be compiled at this directory. The compiler command for a PowerPC 440 processor based system is **make CPU=PPC32**.
  - USB MassStorage emulator uses the local memory for the storage area. The user needs to provide a minimum of 4MB space (modify the `LOCAL_MEM_SIZE` constant value in the `config.h` file as `0x400000`) in the RAM. The MassStorage emulator code emulates a default storage area of 32k.
- All other devices and associated device drivers are not tightly integrated into a VxWorks interface. Instead, they are loosely integrated and access to these devices is available by directly accessing the associated device drivers from the user's application.
- User cores and associated device drivers, if included in the EDK project, are supported through the BSP generation flow. The user core device drivers will be copied into the BSP in the same way the Xilinx device drivers are copied. This assumes the directory structure of the user core device driver matches the structure of the Xilinx device drivers. The */build* sub-directories of the device driver must exist and be formatted in the same way as the Xilinx device drivers. This includes the CDF snippet and xtag files in the */drivers/core\_vxworks\_v2\_00\_a/build* sub-directory. User device drivers are not automatically integrated into any OS interface (for example, SIO), but they are available for direct access by an application.

## Deviations

The following list summarizes the differences between SDK generated BSPs and traditional BSPs.

- An extra directory structure is added to the root BSP directory to contain the device driver source code files.
- To keep the BSP buildable while maintaining compatibility with the Workbench Project facility, a set of files named `procname_drv_driver_version.c` populate the BSP directory that `#include` the source code from the driver subdirectory of the BSP.
- The BSP Makefile has been modified so that the compiler can find the driver source code. The Makefile contains more information about this deviation and its implications.

- SystemACE usage as a boot device may require changes to VxWorks source code files found in the Workbench distribution directory. These changes are out of scope of this document.

## Limitations

The automatically generated BSP should be considered a good starting point for the user, but should not be expected to meet all the user's needs right out of the box. Due to the potential complexities of a BSP, the variety of features that can be included in a BSP, and the support necessary for board devices external to the FPGA, the automatically generated BSP will likely require enhancements by the user. However, the generated BSP will be compilable and will contain the necessary device drivers represented in the FPGA-based embedded system. Some of the commonly used devices are also integrated with the operating system. Specific limitations are listed below.

- An interrupt controller connected to the PowerPC 440 critical interrupt pin is not automatically integrated into the VxWorks interrupt scheme. Only the external interrupt is currently supported.
- Bus error detection from bus bridges or arbiters is not supported.
- The command-line VxWorks 6.7 BSP defaults to use the GNU compiler. The user must manually change the Makefile to use the DIAB compiler, or specify the DIAB compiler when creating a Workbench project based on the BSP.
- The ROM addresses in the `config.h` and Makefiles of BSP are updated based on the peripheral instance selected in the `ROM_INSTANCE` drop down menu box of the Board Support Package settings of SDK. The user must select the peripheral instance as per the hardware settings. In case of wrong selection, the BSP files will be updated with wrong values.
- PowerPC 440 caches are enabled by default. The user must disable caches manually through the `config.h` file or the Workbench project menu.
- When the SystemACE™ controller is setup to download VxWorks images into RAM using JTAG, all boots are cold (no warm boots). This is because the System ACE controller resets the processor whenever it performs an ace file download. An effect of this could cause exception messages generated by VxWorks to not be printed on the console when the system is rebooted due to an exception in an ISR or a kernel panic.

**Note:** No compressed images can be used with SystemACE. This applies to standard compressed images created with Workbench such as `bootrom`. Compressed images cannot be placed on SystemACE as an ace file. SystemACE cannot decompress data as it writes it to RAM. Starting such an image will lead to a system crash.

- On the PowerPC 440 processor, the reset vector is at physical address `0xFFFFFFF0`. There is a short time window where the processor will attempt to fetch and execute the instruction at this address while SystemACE processes the ace file. The processor needs to be given something to do during this time even if it is a spin loop:

```
FFFFFFF0    b .
```

If block RAM occupies this address range, then the designer who creates the bitstream should place instructions here with the ELF to block RAM utility found in the Xilinx Integrated Software Environment (ISE®) tools.

## Booting VxWorks

### VxWorks Bootup Sequence

There are many variations of VxWorks images with some based in RAM, some in ROM. Depending on board design, not all these images are supported. The following list discusses various image types:

- **ROM compressed images**—These images begin execution in ROM and decompress the BSP image into RAM, then transfer control to the decompressed image in RAM. This image type is not compatible with SystemACE because SystemACE doesn't know the image is compressed and will dutifully place it in RAM at an address that will be overwritten by the decompression algorithm when it begins. It may be possible to get this type of image to work if modifications are made to the standard Workbench makefiles to handle this scenario.
- **RAM based images**—These images are loaded into RAM by a bootloader, SystemACE, or an emulator. These images are fully supported.
- **ROM based images**—These images begin execution in ROM, copy themselves to RAM then transfer execution to RAM. In designs with SystemACE as the bootloader, the image is automatically copied to RAM. The hand-coded BSP examples short-circuit the VxWorks copy operation so that the copy does not occur again after control is transferred to RAM by SystemACE (see `romInit.s`).
- **ROM resident images**—These images begin execution in ROM, copy the data section to RAM, and execution remains in ROM. In systems with only a SystemACE, this image is not supported. Theoretically BRAM could be used as a ROM; however, the FPGAs being used in the evaluation boards might not have the capacity to store a VxWorks image which could range in size from 200KB to over 700KB.

### VxWorks Boot Sequence

This standard image is designed to be downloaded to the target RAM space by some device. Once downloaded, the processor is setup to begin execution at function `_sysInit` at address `RAM_LOW_ADRS`. (this constant is defined in `config.h` and `Makefile`). Most of the time, the device performing the download will do this automatically as it can extract the entry point from the image.

1. `_sysInit`: This assembly language function running out of RAM performs low level initialization. When completed, this function will setup the initial stack and invoke the first C function `usrInit()`. `_sysInit` is located in source code file `bspname/sysALib.s`.
2. `usrInit()`: This C function running out of RAM sets up the C runtime environment and performs pre-kernel initialization. It invokes `sysHwInit()` (implemented in `sysLib.c`) to place the hardware in a quiescent state. When completed, this function will call `kernelInit()` to bring up the VxWorks kernel. This function will in turn invoke `usrRoot()` as the first task.
3. `usrRoot()`: Performs post-kernel initialization. Hooks up the system clock, initializes the TCP/IP stack, etc. It invokes `sysHwInit2()` (implemented in `sysLib.c`) to attach and enable HW interrupts. When complete, `usrRoot()` invokes user application startup code `usrAppInit()` if so configured in the BSP.

Both `usrInit()` and `usrRoot()` are implemented by Wind River. The source code files they exist in are different depending on whether the command line or the Workbench Project facility is being used to compile the system. Under the command line interface, they are implemented at `$WIND_BASE/target/config/all/usrConfig.c`. Under the project facility, they are maintained in your project directory.

### bootrom\_uncmp Boot Sequence

This standard image is ROM based but in reality it is linked to execute out of RAM addresses. While executing from ROM, this image uses relative addressing tricks to call functions for processing tasks before jumping to RAM.

1. Power on. Processor vectors to `0xFFFFFFFFC` where a jump instruction should be located that transfers control to the bootrom at address `_romInit`.
2. `_romInit`: This assembly language function running out of ROM notes that this is a cold boot then jumps to start. Both `_romInit` and `start` are located in source code file `bspname/romInit.s`.
3. `start`: This assembly language function running out of ROM sets up the processor, invalidates the caches, and prepares the system to operate out of RAM. The last operation is to invoke C function `romStart()` which is implemented by Wind River and is located in source code file `$WIND_BASE/target/config/all/bootInit.c`.
4. `romStart()`: This C function running out of ROM copies VxWorks to its RAM start address located at `RAM_HIGH_ADRS` (this constant is defined in `config.h` and `Makefile`). After copying VxWorks, control is transferred to function `usrInit()` in RAM.
5. Follows steps 2 and 3 of the “VxWorks Bootup Sequence,” page 11.

### Bootroms

The bootrom is a scaled down VxWorks image that operates in much the same way a PC BIOS does. Its primary job is to find and boot a full VxWorks image. The full VxWorks image may reside on disk, in flash memory, or on some host via the Ethernet. The bootrom must be compiled in such a way that it has the ability to retrieve the image. If the image is retrieved from an Ethernet network, then the bootrom must have the TCP/IP stack compiled in, if the image is on disk, then the bootrom must have disk access support compiled in, and so forth. The bootroms retrieve and start the full image and maintain a bootline. The bootline is a text string that set certain user characteristics such as the target's IP address if using Ethernet and the file path to the VxWorks image to boot.

Bootroms are not a requirement. They are typically used in a development environment then replaced with a production VxWorks image.

### Creating Bootroms

At a command shell in the BSP directory, issue the following command to create an uncompressed bootrom image:

```
make bootrom_uncmp
```

or

```
make bootrom
```

to create a compressed image suitable for placing in a flash memory array.

## Bootrom Display

Upon cycling power, if the bootroms are working correctly, output similar to the following should be seen on the console serial port:

```
VxWorks System Boot

Copyright 1984-2008 Wind River Systems, Inc.

CPU: Xilinx Virtex5 ppc440x5
Version: VxWorks 6.7
BSP version: 2.0/0.
Creation date: July 11, 2009, 16:40:32

Press any key to stop auto-boot...
3

[VxWorks Boot]:
```

Typing **help** at this prompt lists the available commands.

## Bootline

The bootline is a text string that defines user serviceable characteristics such as the IP address of the target board and how to find a vxWorks image to boot. The bootline is maintained at runtime by the bootrom and is typically kept in some non-volatile (NVRAM) storage area of the system such as an EEPROM or flash memory. If there is no NVRAM, or an error occurs reading it, then the bootline is hard-coded with `DEFAULT_BOOT_LINE` defined in the `config.h` source code file of the BSP. In new systems where NVRAM has not been initialized, the bootline may be undefined data.

The bootline can be changed if the auto-boot countdown sequence is interrupted by entering a character on the console serial port. The **c** command can then be used to interactively edit the bootline. Enter **p** to view the bootline. On a non-bootrom image, the bootline can be changed by entering the `bootChange` command at a host or target shell prompt.

The bootline fields are defined below:

- **boot device**—Device to boot from. This could be Ethernet, or a local disk. Note that when changing the bootline, the unit number can be shown appended to this field (`l1temac0`) when prompting for the new boot device. This number can be ignored.
- **processor number**—Always 0 with single processor systems.
- **host name**—Name as needed.
- **file name**—The VxWorks image to boot.
- **inet on ethernet (e)**—The IP internet address of the target. If there is no network interface, then this field can be left blank.
- **host inet (h)**—The IP internet address of the host. If there is no network interface, then this field can be left blank.
- **user (u)**—User name for host file system access. Your FTP server must be setup to allow this user access to the host file system.
- **ftp password (pw)**—Password for host file system access. Your FTP server must be setup to allow this user access to the host file system.
- **flags (f)**—For a list of options, enter the **help** command at the [VxWorks Boot]: prompt.
- **target name (tn)**—Name as needed. Set per network requirements.

- **other (o)**—This field is useful when you have a non-ethernet device as the boot device. When this is the case, VxWorks will not start the network when it boots. Specifying an Ethernet device here will enable that device at boot time with the network parameters specified in the other bootline fields.
- **inet on backplane (b)**—Typically left blank if the target system is not on a VME or PCI backplane.
- **gateway inet (g)**—Enter an IP address here if you have to go through a gateway to reach the host computer. Otherwise leave blank.
- **startup script (s)**—Path to a file on the host computer containing shell commands to execute once bootup is complete. Leave blank if not using a script. Examples:

Host resident script: `c:/temp/myscript.txt`

### Bootrom with Local Link Tri-mode Ethernet (LLTEMAC) as the Boot Device

SDK will generate a BSP that is capable of being built as a bootrom using the LLTEMAC as a boot device. Very little user configuration is required. The MAC address is hard coded in the source file `hwconf.c`. The BSP can be used with the default MAC as long as the target is on a private network and there is no more than one target on that network with the same default MAC address. Otherwise the designer should replace this MAC with a function to retrieve one from a non-volatile memory device on their target board.

To specify the LLTEMAC as the boot device in the bootrom, change the boot device field in the bootline to **litemac**. If there is a single LLTEMAC, set the unit number to **0**.

The following example boots from the ethernet using the Xilinx `litemac` as the boot device. The image booted is on the host file system on drive C.

```
boot device           : litemac
unit number          : 0
processor number      : 0
host name             : host
file name             : c:/WindRiver/vxworks-6.7/target/config/ml507/vxWorks
inet on ethernet (e) : 192.168.0.2
host inet (h)         : 192.168.0.1
user (u)              : xemhost
ftp password (pw)     : whatever
flags (f)             : 0x0
target name (tn)      : vxtarget
other (o)             :
```

### Caches

The instruction and data caches are managed by VxWorks proprietary libraries. They are enabled by modifying the following constants in `config.h` or by using the Workbench Project facility to change the constants of the same name:

- `INCLUDE_CACHE_SUPPORT`: If defined, the VxWorks cache libraries are linked into the image. If caching is not desired, then `#undef` this constant.
- `USER_I_CACHE_ENABLE`: If defined, VxWorks will enable the instruction cache at boot time. Requires `INCLUDE_CACHE_SUPPORT` be defined to have any effect.
- `USER_D_CACHE_ENABLE`: If defined, VxWorks will enable the data cache at boot time. Requires `INCLUDE_CACHE_SUPPORT` be defined to have any effect.

## MMU

If the MMU is enabled, then the cache control discussed in the previous section may not have any effect. The MMU is managed by VxWorks proprietary libraries but the initial setup is defined in the BSP. To enable the MMU, the constant `INCLUDE_MMU_BASIC` should be defined in `config.h` or by using the Project Facility. The constant `USER_D_MMU_ENABLE` and `USER_I_MMU_ENABLE` control whether the instruction and/or data MMU is utilized.

VxWorks initializes the MMU based on data in the `sysPhysMemDesc` structure defined in `sysCache.c`. User reserved memory and ED&R (when `INCLUDE_EDR_PM` is enabled) reserved memory is included in this table. Amongst other things, this table configures memory areas with the following attributes:

- Whether instruction execution is allowed
- Whether data writes are allowed
- Instruction and data cache attributes
- Translation offsets used to form virtual addresses

When VxWorks initializes the MMU, it takes the definitions from `sysPhysMemDesc` and creates page table entries (PTEs) in RAM. Each PTE describes 4KB of memory area (even though the processor is capable of representing up to 16MB per PTE.) Beware that specifying large areas of memory uses substantial amounts of RAM to store the PTEs. To map 4MB of contiguous memory space takes 8KB of RAM to store the PTEs.

To increase performance with the VxWorks basic MMU package for the PowerPC 440 processor, it may be beneficial to not enable the instruction MMU and rely on the cache control settings in the ICCR register. This strategy can dramatically reduce the number of page faults while still keeping instructions in cache. The initial setting of the ICCR is defined in the `bspname.h` header file.

For PowerPC 440 processors, caches and MMU are enabled by default.

Without the MMU enabled, the following rules apply to configuring memory access attributes and caching:

- There is no address translation, all effective addresses are physical.
- Cache control granularity is 128MB.

## FPU

Hard Floating-Point Unit (FPU) is supported for PowerPC 440 processor systems. To enable hard floating-point unit, please select `diab` or `gnu` in generated BSP Makefile `TOOLS`. To disable hard floating-point unit, select `sfdiab` or `sfgnu` in the `TOOLS` make variable of the Makefile.

